

Qalitrack — Installation Guide

Version: katani br
Keep this document on

⚠ Qalitrack Manned only. This guide covers Qalitrack Manned. Qalitrack Unmanned has its own installation guide.

WHAT IS IN THE DEPLOYMENT FOLDER

install.bat	Double-click to install the backend
install.ps1	Called automatically by install.bat
docker-compose.yml	Backend service definitions
.env	Secrets file – provided by Qalitrack team
QalitrackHardware.exe	Hardware client (weighbridge, camera, RFID)
QalitrackFrontend.exe	Web frontend desktop app

PREREQUISITES

Docker Desktop and WSL2 are installed automatically by the script. If a restart is required mid-install, the script will say so — restart the PC and double-click `install.bat` again to continue.

PART 1 — BACKEND SERVICES

- 1 Confirm Docker Desktop is running (whale icon in taskbar).
- 2 Place the `.env` file provided for this site inside the `Deployment` folder (same level as `install.bat`).
- 3 Double-click **install.bat**. Click **Yes** on the UAC prompt. The script clones the source code, builds all service images, and starts everything. *First run takes 5–15 minutes.*
- 4 When the window shows the green success banner, open a browser and verify:

Service	URL
Gateway	<code>http://localhost:7000</code>
User Service	<code>http://localhost:7001</code>
Master Data	<code>http://localhost:7002</code>
Backup	<code>http://localhost:7003</code>
Transactions	<code>http://localhost:7004</code>

The backend restarts automatically after every reboot — no action needed.

Qalitrack — Installation Guide

Version: katani br
Keep this document on

PART 2 — HARDWARE CLIENT

Collects weighbridge data, camera feed, RFID and NFC reads.

- 1 Right-click **QalitrackHardware.exe** → *Run as administrator*.
- 2 Fill in the setup wizard:
 - **Weighbridge** — TCP (IP + port, default 3002) or Serial (COM port + baud rate from the weighbridge manual)
 - **Camera** — IP, RTSP port (554), path, username/password
 - **RFID** — tick if installed, enter IP + port (2022)
 - **NFC** — tick if installed, select COM port
- 3 Click **Install Service**. The service starts automatically and survives reboots.
- 4 Verify at `http://localhost:5000`.

Update: run the new `QalitrackHardware.exe` as Administrator — the wizard pre-fills the existing config and the button reads *Update & Reinstall*.

PART 3 — FRONTEND

The Qalitrack web application desktop client.

- 1 Double-click **QalitrackFrontend.exe**.
- 2 Follow the on-screen installation steps and accept the defaults.
- 3 Launch the application from the desktop shortcut created by the installer.

Update: run the new `QalitrackFrontend.exe` — the installer upgrades in place.

TROUBLESHOOTING

Symptom	Fix
install.bat says "restart required"	Restart the PC, then double-click <code>install.bat</code> again. This happens once when WSL2 or Docker Desktop is installed for the first time.
install.bat reports Docker not running	Open Docker Desktop manually, wait for the whale icon to be solid, then re-run <code>install.bat</code> .
install.bat reports .env not found	Place the <code>.env</code> file in the same folder as <code>install.bat</code> and re-run.
install.bat reports WSL not installed	Run <code>wsl --install</code> in PowerShell as Administrator, restart the PC, re-run <code>install.bat</code> .
Services show unhealthy after install	Wait 60 seconds — databases take time on first boot. Open a browser and check the URLs again.
Hardware: "Installation Failed"	Right-click <code>QalitrackHardware.exe</code> → <i>Run as administrator</i> . Administrator rights are required.
Weighbridge shows no data (TCP)	Confirm IP and port with the site engineer. Test: <code>ping <ip></code> in PowerShell.
Weighbridge shows no data (Serial)	Confirm COM port in Device Manager. Check baud rate against the weighbridge manual.
Camera not connecting	Test the RTSP stream in VLC: Media → Open Network Stream → <code>rtsp://user:pass@ip:554/path</code> . The service retries automatically.

UPDATING THE BACKEND

Re-run `install.bat` — it pulls the latest code and rebuilds the images. Existing data is preserved.