

## Archive — Technical Training Autodesk Topobase Administrator




## **Disclaimers**

This course was created for Autodesk Topobase 2009. The contents of this course are not intended for other versions of Autodesk Topobase.

We may make statements regarding planned or future development efforts for our existing or new products and services. These statements are not intended to be a promise or guarantee of future delivery of products, services or features but merely reflect our current plans, which may change. Purchasing decisions should not be made based upon reliance on these statements.

The Company assumes no obligation to update these forward-looking statements to reflect events that occur or circumstances that exist or change after the date on which they were made.



Autodesk\*

## **Chapter Overview**

- Chapter teaches how to use Autodesk Topobase 2008 to export project data in different formats:
  - Easily share data throughout your organization and beyond.
  - Even with people who don't have Topobase or AutoCAD Map 3D 2008.

## **Reports and Data Export**

## **Chapter Objectives**


By the end of this chapter, you will be able to:

- Explain how data can be distributed throughout an organization.
- Generate a report.
- Export a document.
- Export data to other formats.

## 8.2 Reports Designer

- Open the Simrose water network with land base workspace.
- Select Document

   ATWATER in
   the Administrator
   tree explorer,
   select Document
   menu > Report
   Designer....



## 8.2.1 Creating a Report


Select Report menu > New > Blank report

#### OR


Select Report > New >
 Wizard to create a new report

#### OR


Click the Create a new
 Report ( ) icon




## 8.2.1 Creating a Report +



## **8.2.2 Layout Components**



## 8.2.3 Displaying Data



## 8.2.3 Displaying Data +


#### Group - SQL property

• The Sql property has the following SQL created by default:

```
select * from WA_HYDRANT_STATUS_TBD a where
{Parameter.Filter}
```

#### Controls – DB column vs. Text control


To add new database columns, select the option Add > DB Column.



• If you want to add a label, you have to choose Add > Text.




## 8.2.4 Adding Report Detail Query—Child **Groups**




#### 8.2.5 DB Column and Form Control

 If you select Add > DB Column to add database columns, you will get the list of columns of the Hydrant (WA\_HYDRANT) feature class.




To add a form control, select
 Add > Form Control from the menu.




#### 8.2.6 SQL Control

- The SQL controls are used to insert queries to select values from related tables.
- To browse existing SQL controls, select Add > Sql > Manage.




#### **8.2.7 Function Control**

To browse existing Function controls, select Add > Function > Manage.




## **8.2.8 Special Controls**




## **8.2.9 Other Components**

- To enhance the look and feel of the report, you can add pictures or lines.
- Select Add > Picture or Add > Line or Add > Page or Add > Zone.




#### 8.2.10 Parameters

 If you select Add > Parameter > Manage, the list of parameters is displayed.



## 8.2.11 Adding a Report to a Feature Class Form

- To be able to call a report from a feature class form, add it to the form.
- Open the Hydrant Status domain table form, click the printer icon in the toolbar.
- The Report dialog is shown, right-click in blank space and select
   Add > Topobase Report.




## 8.2.12 Printing a Report from Topobase Client

 You can generate reports directly from the Output tab, Reports and Profiles pane. Select Open Report.



## 8.3.1 Exporting a Document

- Export document data to an Oracle dump file:
  - Back up data.
  - Share with other users.
- Export document settings to xml:



## 8.3.2 Exporting Attributes to an ASCII File

Right-click anywhere in feature class form.


- Select:
  - Export > Ascii File (Direct).
  - Export > Ascii File (Form Data).



74288,3860,2,4907279,715892↓ 74289,3861,2,4907254,715947\u00f3 74290,3862,2,4907182,715913\psi 74291,3863,2,4907195,715960↓ 74292,3864,2,4907153,715966\u2214 74293,6370,2,4906692,715965↓ 74294,6371,2,4906768,7159434 74295,6372,2,4906743,715986↓ 74296,6373,2,4906795,715980\u2214 74297,6374,2,4906846,715974 74298,6375,2,4906898,715967\u00f3 74299,6376,2,4906950,715961↓ 74300,6377,2,4907002,715955↓ 74301,6378,2,4906824,715954\ 74302,6379,2,4906894,715946↓ 74303,6380,2,4906930,715939\ 74304,6381,2,4906963,715933\psi 74305,6382,2,4907081,715921\psi 74306,6386,2,4906603,716030\psi 74307,6532,1,4907304,715819V 74308,6533,1,4907279,715866\u00f3 74309,6534,2,4907428,715740\u2214 74310,6535,1,4910325,715297\u00f3 74311,6536,1,4910348,715355\


## 8.3.3 Exporting Attributes to XML

- Right-click anywhere in feature class form.
- Select:
  - Export > Xml.
- In the Save As dialog box, enter the relevant details.



## 8.3.4 Exporting Attributes to SQL Statements


- The main advantage: You can export a subset of attributes from a feature class into a single SQL script.
- Others use this script to import data into their own databases.
- Right-click the feature class form and select Export > SQL.
- Export options include:
  - Oracle Sql.
  - Oracle Sql Loader.
  - Oracle PostGre Sql.



# Autodesk

## 8.3.5 Exporting Attributes to Mail Merge

- In a feature class form:
  - Click the Add Filter tool and select records.
- Right-click and select:
  - Export > Word Serial Letter.
- Set up a Word document template.
- Use the document template.



## 8.3.6 Exporting Attributes to Excel

Right-click anywhere in feature class form.

- Select:
  - Export > Excel (Direct).
  - Export > Excel (Form Data).



## 8.5 Chapter Summary

You should now be able to:

- Explain how data can be distributed throughout an organization.
- Generate a report.
- Export a document.
- Export data to other formats.

## Autodesk