

EEL 4742 – Embedded Systems

Module 3 – Embedded System Design and Timer

Hadi Kamali

Department of Electrical and Computer Engineering (ECE)
University of Central Florida


Office Location/phone: HEC435 – (407) 823-0764
webpage: <https://www.ece.ucf.edu/~kamali/>
e-mail: kamali@ucf.edu

HAVEN Research Group
<https://haven.ece.ucf.edu/>



Embedded System Design

- From the software point of view
 - Dealing with both **functional** and **non-functional** attributes of the system






Embedded System Design

- From the software point of view
 - Dealing with both **functional** and **non-functional** attributes of the system
- What are non-functional requirements?
 - Environmental requirements (The impact of user/environment on the system)
 - Reactions, inputs of sensors, inputs of users, etc.
 - Can happen at any time (there is no prediction for that)
 - Execution requirements (The impact of outputs generated by the system)
 - An operation as a consequence of a check/computation

Predictability in Embedded System Design


- The challenge: To build time-deterministic systems
- Predictable properties
 - What output the systems produce?
 - Expected based on the data sheets and user guides
 - When does the program provide the output?
 - Expected based on the data sheets and user guides






Predictability in Embedded System Design

- The challenge: To build time-deterministic systems
- Embedded systems are mostly built on platforms that are inherently **unpredictable**.
- Sources of non-determinism
 - Input non-determinism
 - Unobservable implementation non-determinism
 - Don't care non-determinism
 - Observable implementation non-determinism




Predictability in Embedded System Design

- The challenge: To build time-deterministic systems
- Embedded systems are mostly built on platforms that are inherently **unpredictable**.
- Sources of non-determinism
 - **Input non-determinism**
 - The environment is unpredictable
 - Possible solution – timed input-output streams – each input and output event has a time stamp (e.g., FSM)
 - Unobservable implementation non-determinism
 - Don't care non-determinism
 - Observable implementation non-determinism



Predictability in Embedded System Design

- The challenge: To build time-deterministic systems
- Embedded systems are mostly built on platforms that are inherently **unpredictable**.
- Sources of non-determinism
 - Input non-determinism
 - **Unobservable implementation non-determinism**
 - Arbitrary decisions in the implementation that are not visible at the output
 - e.g. order of sorting the input list does not affect the output
 - Don't care non-determinism
 - Observable implementation non-determinism





Predictability in Embedded System Design


- The challenge: To build time-deterministic systems
- Embedded systems are mostly built on platforms that are inherently **unpredictable**.

- Sources of non-determinism
 - Input non-determinism
 - Unobservable implementation non-determinism
 - **Don't care non-determinism**
 - States w/ no action (no change to output)
 - Observable implementation non-determinism

Motion detected	Temp. < 70° F	Functionality	Resource Consumption
True	True	Turn on heater	
True	False	Turn off heater	
False	True	Don't care	
False	False	Don't care	

Predictability in Embedded System Design

- The challenge: To build time-deterministic systems
- Embedded systems are mostly built on platforms that are inherently **unpredictable**.
- Sources of non-determinism
 - Input non-determinism
 - Unobservable implementation non-determinism
 - Don't care non-determinism
 - **Observable implementation non-determinism**
 - Arbitrary decisions in the implementation that are visible at the output
 - E.g. a pick and place robot – order matters – pick, move, place, move
 - Order of scheduling tasks



Predictability in Real Time Systems

- A real-time system requires timing correctness in addition to functional correctness.
 - Non-functional reaction requirement
 - *Response time ≤ Deadline*

Hard real-time system

Missing a deadline is a system failure.
e.g. Pulses generated by a pacemaker




Soft real-time system

Undesirable to miss too many deadlines.
e.g. Updates in the gauge cluster



Characteristic	Hard Real Time	Soft Real Time
Response Time	hard	soft
Peak-Load	perform.predictable	degraded
Error Detection	system	user
Safety	critical	non-critical
Redundancy	active	standby
Time Granularity	millisecond	second
Data Files	small/medium	large



Timer: Counting CLK Pulses

- Recap: LED flashing lab/lecture and the delay function we add manually in it.


The red LED is mapped to Port 1 Bit 0!

The green LED is mapped to Port 1 Bit 7!

e.g., each loop counts take 1us. How many times ON per second?

$$20,000 \times 10^{-6} = 2 \times 10^4 \times 10^{-6} = 2 \times 10^{-2} \text{ s} \rightarrow \text{for each toggle}$$

clock period = time of each flash (half cycle on and half cycle off)



```

BIT0=00000001 // Code that flashes the red LED
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    volatile unsigned int i;
    // initialization (reset watchdog, GPIO high-z, etc.
    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    for(;;) {
        // Delay loop
        for(i=0; i<20000; i++)
        P1OUT ^= redLED; // Toggle the LED
    }
}

```



Timer: Counting CLK Pulses

- Recap: LED flashing lab/lecture and the delay function we add manually in it.

The red LED is mapped to Port 1 Bit 0!

The green LED is mapped to Port 1 Bit 7!

**For having delay more
(slower flashing)**

```
BIT0=00000001 // Code that flashes the red LED
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    volatile unsigned int i;
    // initialization (reset watchdog, GPIO high-z, etc.
    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    for(;;) {
        // Delay loop
        for(i=0; i<20000; i++)
        P1OUT ^= redLED; // Toggle the LED
    }
}
```

- Nested loop
- Using 32-bit variables
- Delay cycle function;




Timer: Counting CLK Pulses

- Recap: LED flashing lab/lecture and the delay function we add manually in it.

```
BIT0=00000001 // Code that flashes the red LED
BIT7=10000000
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    volatile unsigned int i;
    // initialization (reset watchdog, GPIO high-z, etc.
    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    for(;;) {
        // Delay loop
        for(i=0; i<20000; i++)
        P1OUT ^= redLED; // Toggle the LED
    }
}
```

*What's the issue with this manual delay
(using loops or _delay() function)?*





Timer: Counting CLK Pulses

- Alternative: Using Timer

*What's the issue with this manual delay
(using loops or _delay() function)?*

**This keeps the CPU 'busy' while
doing a trivial task!**

*Such timing related operations can be
implemented using the peripheral Timer.*

```
BIT0=00000001 // Code that flashes the red LED
BIT7=10000000 #include <msp430fr6989.h>
                #define redLED BIT0 // Red LED at P1.0
                void main(void)
                {
                    volatile unsigned int i;
                    // initialization (reset watchdog, GPIO high-z, etc.
                    P1DIR |= redLED; // Direct pin as output
                    P1OUT &= ~redLED; // Turn LED Off
                    for(;;) {
                        // Delay loop
                        for(i=0; i<20000; i++)
                        P1OUT ^= redLED; // Toggle the LED
                    }
                }
```



Timer: Counting CLK Pulses

- Alternative: Using Timer

```
BIT0=00000001 // Code that flashes the red LED
BIT7=10000000 #include <msp430fr6989.h>
                #define redLED BIT0 // Red LED at P1.0
                void main(void)
                {
                    // Initialization code here:
                    TAOCTL = TASSEL_1 | ID_0 | MC_2 | TACLR;
                    // Initialization (reset watchdog, GPO1 high-z, etc.
                    P1DIR |= redLED; // Direct pin as output
                    P1OUT &= ~redLED; // Turn LED Off
                    for(;;) {
                        if((TAOCTL & TAIFG) != TAIFG){
                            TCCR0A = ~TCCR0A; // Toggle the LED
                            P1OUT ^= redLED; // Turn LED On
                        }
                        // Do other things!
                    }
                }
```


Initialization and enabling the timer ←

Check on timer (status) ←

Such timing related operations can be implemented using the peripheral Timer.

Timer: Counting CLK Pulses


- Timer
 - Counting the clock pulses (clock ticks)
 - For the measurement of elapsed time (elapsed clock pulses)



Timer: Counting CLK Pulses

- Timer
 - Counting the clock pulses (clock ticks)
 - For the measurement of elapsed time (elapsed clock pulses)

*MSP430 devices might have other timers like **Timer_B0**, **Timer_A1**, etc.*





Timer: Counting CLK Pulses

- Timer

- Counting the clock pulses (clock ticks)
 - For the measurement of elapsed time (elapsed clock pulses)


- Asynchronous 16-bit timer/counter with four operating modes
- Selectable and configurable clock source
- Up to seven configurable capture/compare registers
- Configurable outputs with pulse width modulation (PWM) capability
- Asynchronous input and output latching
- Interrupt vector register for fast decoding of all Timer_A interrupts




Timer – Clock Source

- Clock signals are generated in multiple ways
 - Crystals
 - RC Circuits
- In MSP430 (Oscillators)
 - Internal oscillator – provided inside the chip
 - DCO (Digitally Controlled Oscillator)
 - VLO (Very-low-power Low-frequency Oscillator)
 - External oscillator – provided externally
 - LFXT (Low frequency oscillator) KHz range
 - HFXT (High frequency oscillator) MHz range

(HFXT is not available in all MSP430 devices, only some devices support it. It is not available in MSP430FR6989 either.)



32.768 KHz Crystal




MSP430FR6989 development board

Timer – Clock Source

- Clock signals are generated in multiple ways
 - Crystals
 - RC Circuits
- In MSP430 (Oscillators)
 - Internal oscillator – provided inside the chip
 - **DCO (Digitally Controlled Oscillator)**
 - VLO (Very-low-power Low-frequency Oscillator)
 - External oscillator – provided externally
 - LFXT (Low frequency oscillator) KHz range
 - HFXT (High frequency oscillator) MHz range

(HFXT is not available in all MSP430 devices, only some devices support it. It is not available in MSP430FR6989 either.)




The DCO's frequency can be adjusted digitally via software!

- **Wide frequency range:** Typically from a few hundred kHz to several MHz.
- **Fast start-up time:** The DCO can start up quickly from a low-power mode, making it ideal for power-sensitive applications.
- **Digital control:** The frequency can be precisely controlled through software, allowing dynamic adjustment based on the application's needs.

Timer – Clock Source

- Clock signals are generated in multiple ways
 - Crystals
 - RC Circuits
- In MSP430 (Oscillators)
 - Internal oscillator – provided inside the chip
 - DCO (Digitally Controlled Oscillator)
 - **VLO (Very-low-power Low-frequency Oscillator)**
 - External oscillator – provided externally
 - LFXT (Low frequency oscillator) KHz range
 - HFXT (High frequency oscillator) MHz range

(HFXT is not available in all MSP430 devices, only some devices support it. It is not available in MSP430FR6989 either.)



It operates at a very low frequency, typically around 10 kHz!

- **Low power consumption:** As the name suggests, it is optimized for low power, which is crucial in energy-constrained applications.
- **Low frequency:** Typically around 10 kHz, making it suitable for tasks that do not require high-speed processing, such as keeping track of time in a low-power mode.

Timer – Clock Source


- Clock signals are generated in multiple ways

- Crystals
- RC Circuits

- In MSP430 (Oscillators)

- Internal oscillator – provided inside the chip
 - DCO (Digitally Controlled Oscillator)
 - VLO (Very-low-power Low-frequency Oscillator)
- External oscillator – provided externally
 - **LFXT (Low frequency oscillator) KHz range**
 - **HFXT (High frequency oscillator) MHz range**

(HFXT is not available in all MSP430 devices, only some devices support it. It is not available in MSP430FR6989 either.)




In the kilohertz (kHz) range, typically at 32.768 kHz → RTC

- **High accuracy:** Provides a stable and precise clock signal, important for time-sensitive applications.
- **Commonly used with crystal oscillators:** The LFXT typically works with an external 32.768 kHz crystal, which offers excellent accuracy and stability.
- **Low power consumption:** Since it operates at a low frequency, it consumes minimal power, making it suitable for always-on clocking in low-power applications.

Timer – Clock Source

- Clock signals are generated in multiple ways
 - Crystals
 - RC Circuits
- In MSP430 (Oscillators)
 - Internal oscillator – provided inside the chip
 - DCO (Digitally Controlled Oscillator)
 - VLO (Very-low-power Low-frequency Oscillator)
 - External oscillator – provided externally
 - LFXT (Low frequency oscillator) KHz range
 - HFXT (High frequency oscillator) MHz range

(HFXT is not available in all MSP430 devices, only some devices support it. It is not available in MSP430FR6989 either.)




In the megahertz (MHz) range used for high-speed clocking!

- **High frequency:** Typically operates in the MHz range, which provides the necessary clock speed for demanding applications.
- **Stable and precise:** Offers accurate timing and clock signals, which are critical for applications that require precise timing, such as communication protocols.


Timer - Clock Source

- Clock Selection



Timer - Clock Source

- Clock Selection



Timer_A Configuration in MSP430

- Clock Selection & Initialization

- The timer clock can be sourced from ACLK, SMCLK, or externally from TAxCLK or INCLK

- Selection will be done using TASSEL.


- Directly or Divided

- divided by 2, 4, or 8, using the ID bits

- Shifting-based ($\sim Q$ connected to D)

- divided by 2, 3, 4, 5, 6, 7, or 8 using the TAIDEX bits


- Counting-based (e.g., mod 3 counter)



Timer_A Configuration in MSP430

- Clock Selection & Initialization

- The timer clock can be sourced from ACLK, SMCLK, or externally from TAxCLK or INCLK
 - Selection will be done using TASSEL.
- Directly or Divided
 - divided by 2, 4, or 8, using the ID bits
 - Shifting-based ($\sim Q$ connected to D)
 - divided by 2, 3, 4, 5, 6, 7, or 8 using the TAIDEX bits
 - Counting-based (e.g., mod 3 counter)





Timer_A Configuration in MSP430

- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRO
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRO and back down to zero


What should be the size of TAOCRC?

Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TA0CCR0
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TA0CCR0 and back down to zero

TA0CCR0 is a 16-bit register. TA0CCR0 stands for timer_A 0 capture/compare register for channel 0.




Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRO
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRO and back down to zero

• Up mode

- The timer period must be different from OFFFFh
- Counting to TAxCRO
- Resetting to Zero



Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)


MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRCR0
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRCR0 and back down to zero

- Up mode

- The timer period must be different from OFFFFh
- Counting to TAxCRCR0
- Resetting to Zero

The TAIFG interrupt flag is set when the timer counts from TAxCRCR0 to zero

CCIFG interrupt flag is set when the timer counts to the TAxCRCR0 value




Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRC0
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRC0 and back down to zero

- Up mode

- The timer period must be different from OFFFFh
- Counting to TAxCRC0
- Resetting to Zero



What will happen if we change CCR0 at runtime?


Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRC0
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRC0 and back down to zero

- Up mode

- The timer period must be different from OFFFFh
- Counting to TAxCRC0
- Resetting to Zero



What will happen if we change CCR0 at runtime?

For greater period → The timer counts up to the new period.


For less period → The timer rolls to zero (immediately or after one clock).

Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG
	15	14	13	12	11	10	9	8	7	6	5	4	3

- Up mode




Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRO
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRO and back down to zero

- Continuous mode

- The timer period is OFFFFh
- The timer repeatedly counts up to OFFFFh and restarts from zero Resetting to Zero
- No CCIFG (no TAxCRO)




can be used to generate independent time intervals and output frequencies

Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)
- Continuous mode

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRO
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRO and back down to zero




Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG
	15	14	13	12	11	10	9	8	7	6	5	4	3

- Continuous mode



Timer_A Counting Modes


- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRCRO
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRCRO and back down to zero

- Up/down mode

- The timer period must be different from OFFFFh

- and if symmetrical pulse generation is needed
- Counts up to CCR0 and back down to zero




Timer_A Counting Modes

- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRO
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRO and back down to zero

- Up/down mode

- The timer period must be different from OFFFFh
 - and if symmetrical pulse generation is needed
 - Counts up to CCR0 and back down to zero
- The count direction is latched
 - Can be restarted using TACLR



What will happen if we change CCR0 at runtime?

Timer_A Counting Modes


- Timer Mode Control
 - Controlled using MC (2 bits)

MC	Mode	Description
00	Stop	The timer is halted.
01	Up	The timer repeatedly counts from zero to the value of TAxCRC0
10	Continuous	The timer repeatedly counts from zero to OFFFFh (cycling with no stop)
11	Up/down	The timer repeatedly counts from zero up to the value of TAxCRC0 and back down to zero

- Up/down mode

- The timer period must be different from OFFFFh
 - and if symmetrical pulse generation is needed
 - Counts up to CCR0 and back down to zero
- The count direction is latched
 - Can be restarted using TACLR

What will happen if we change CCR0 at runtime?



count down
count up
count up

The timer continues counting down to zero. After zero, new CCR0 will be used.

For greater period → The timer counts up to the new period (before counting down).

For less period → The timer begins counting down to zero (immediately or after one clock).



Timer Exercise 1

- Configure timer_A

- in up mode, $TAOCTL$
- with ACLK as the clock source
- And TAIFG flag is set very 0.5 seconds.

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0



Timer Exercise 1

- Configure timer_A

- in up mode, $TAOCTL$

- with ACLK as the clock source

- And TAIFG flag is set very 0.5 seconds.

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

- Solution

ACLK is 32768 KHz

$$\begin{aligned} 32768 \text{ clock cycles} &= 1 \text{ second} \\ x \text{ clock cycles} &= 0.5 \text{ second} \end{aligned}$$

$$0.5 * 32768$$

$$x = \frac{0.5 * 32768}{1} = 16384 \text{ clock cycles}$$



Timer Exercise 1

- Configure timer_A

- in up mode, **TAOCTL**
- with ACLK as the clock source
- And TAIFG flag is set very 0.5 seconds.

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

- Solution

ACLK is 32768 KHz

32768 clock cycles = 1 second
x clock cycles = 0.5 second

$$x = \frac{0.5 * 32768}{1} = 16384 \text{ clock cycles}$$

```
// Code that flashes the red LED using timer
#include <msp430fr6989.h>
#define redLED BIT0
void main(void)
{
    WDTCLTC = WDTPW | WDTHOLD;
    PM5CTL0 &= ~LOCKLPM5; // stop watchdog timer
                           // clear Low Power

    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    TAOCTL = TASSEL_1 | ID_0 | MC_1; // One extra cycle to set TAIFG
    TA0CCR0 = 16384 - 1;
    TAOCTL |= TACLR;

    for(;;) {
        while((TAOCTL & TAIFG) != TAIFG){}
        P1OUT ^= redLED; // delay
                           // toggle redLED
        TAOCTL &= ~TAIFG;
    }
    return;
}
```



Timer Exercise 2

- Configure timer_A

- Timer source is ACLK
- Divider is /4
- Operation mode is continuous
- Clear the TA0R register

TAOCTL

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0



Timer Exercise 2

- Configure timer_A

- Timer source is ACLK
- Divider is /4
- Operation mode is continuous
- Clear the TA0R register

TAOCTL

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

- Solution

TAOCTL = TASSEL_1 | ID_2 | MC_2 | TACLR;



Timer Exercise 3

- Can we use the timer instead of the for loop delay?
- How do we do that?

TAOCTL

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0



Timer Exercise 3

- Can we use the timer instead of the for loop delay?
- How do we do that?
- Solution

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

```
while((TAOCTL & TAIFG) != TAIFG)  
{};
```



Timer Exercise 4

- Recall 32.768 KHz crystal?
Write a snippet code
that creates
LED flashing
every 2 seconds.

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

- Solution



Timer Exercise 4

- Recall 32.768 KHz crystal?
Write a snippet code that creates LED flashing every 2 seconds.

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

```
// Code that flashes the red LED using timer
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    WDTCLTC = WDTPW | WDTHOLD; // stop watchdog timer
    PM5CTL0 &= ~LOCKLPM5; // clear Low Power

    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    TAOCTL = TASSEL_1 | ID_0 | MC_2;
    TAOCTL |= TACLR;

    for(;;) {
        while((TAOCTL & TAIFG) != TAIFG){} // delay
        P1OUT ^= redLED; // toggle redLED
        TAOCTL &= ~TAIFG;
    }
    return;
}
```



Timer Exercise 4

- Recall 32.768 KHz crystal?
Write a snippet code that creates LED flashing every 2 seconds.

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

```
// Code that flashes the red LED using timer
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    WDTCLTC = WDTPW | WDTHOLD; // stop watchdog timer
    PM5CTL0 &= ~LOCKLPM5; // clear Low Power

    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    TAOCTL = TASSEL_1 | ID_0 | MC_2; // Set up timer
    TAOCTL |= TACLR; // Clear TAIFG

    for(;;) {
        while((TAOCTL & TAIFG) != TAIFG){} // delay
        P1OUT ^= redLED; // toggle redLED
        TAOCTL &= ~TAIFG;
    }
    return;
}
```

Decode this line? What's the meaning of it?



Timer Exercise 4

- Recall 32.768 KHz crystal?
Write a snippet code that creates LED flashing every 2 seconds.

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

```
// Code that flashes the red LED using timer
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    WDTCLTC = WDTPW | WDTHOLD; // stop watchdog timer
    PM5CTL0 &= ~LOCKLPM5; // clear Low Power

    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    TAOCTL = TASSEL_1 | ID_0 | MC_2; // ACLK is selected with no dividers and in continuous mode
    TAOCTL |= TACLR;

    for(;;) {
        while((TAOCTL & TAIFG) != TAIFG){} // delay
        P1OUT ^= redLED; // toggle redLED
        TAOCTL &= ~TAIFG;
    }
    return;
}
```



Timer Exercise 4

- Recall 32.768 KHz crystal?
Write a snippet code that creates LED flashing every 2 seconds.

TAOCTL	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

```
// Code that flashes the red LED using timer
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    WDTCLTC = WDTPW | WDTHOLD; // stop watchdog timer
    PM5CTL0 &= ~LOCKLPM5; // clear Low Power

    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    TAOCTL = TASSEL_1 | ID_0 | MC_2;
    TAOCTL |= TACLR;

    for(;;) {
        while((TAOCTL & TAIFG) != TAIFG){} // delay
        P1OUT ^= redLED; // toggle redLED
        TAOCTL &= ~TAIFG;
    }
    return;
}
```

ACLK is selected with no dividers and in continuous mode

1 clk tick = 1/32768 second

time taken for TAOR to count from 0x0000 → 0xffff = 65536 clk ticks

(it is equal to the time until TAIFG becomes 1!)

Timer Exercise 4

- Recall 32.768 KHz crystal?
- Write a snippet code that creates LED flashing every 2 seconds.

<i>TAOCTL</i>	rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG
	15	14	13	12	11	10	9	8	7	6	5	4	3

```

// Code that flashes the red LED using timer
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    WDTCLTC = WDTPW | WDTHOLD; // stop watchdog timer
    PM5CTL0 &= ~LOCKLPM5; // clear Low Power

    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    TAOCTL = TASSEL_1 | ID_0 | MC_2;
    TAOCTL |= TACLR;

    for(;;) {
        while((TAOCTL & TAIFG) != TAIFG){} // delay
        P1OUT ^= redLED; // toggle redLED
        TAOCTL &= ~TAIFG;
    }
}

```

ACLK is selected with no dividers and in continuous mode

1 clk tick = 1/32768 second

time taken for TAOR to count from 0x0000 → 0xffff = 65536 clk ticks

(it is equal to the time until TAIFG becomes 1!)

65536 clk ticks / 32768 = 2 seconds (for toggling – flashing LED)



Timer Exercise 5

- LED with a delay of 50ms.
- Timer_A in up mode
- Using SMCLK (1MHz)
 - Divider is 8

TAOCTL

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0



Timer Exercise 5

- LED with a delay of 50ms.

- Timer_A in up mode

- Using SMCLK (1MHz)

- Divider is 8

TAOCTL

rsvd.						TASSEL	ID	MC	rsvd.	TACLR	TAIE	TAIFG			
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

- Solution

```
// Code that flashes the red LED using timer
#include <msp430fr6989.h>
#define redLED BIT0 // Red LED at P1.0
void main(void)
{
    WDTCLTC = WDTPW | WDTHOLD; // stop watchdog timer
    PM5CTL0 &= ~LOCKLPM5; // clear Low Power

    P1DIR |= redLED; // Direct pin as output
    P1OUT &= ~redLED; // Turn LED Off
    TAOCTL = TASSEL_2 | MC_1 | ID_3;
    TA0CCR0 = 6250;

    for(;;) {
        while((TAOCTL & TAIFG) != TAIFG){} // delay
        P1OUT ^= redLED; // toggle redLED
        TAOCTL &= ~TAIFG;
    }
    return;
}
```



Timer Exercise 6

- If Timer_A is configured in Continuous Mode with the SMCLK set to 8 MHz and no additional prescaler, how long does it take for Timer_A to overflow (reach 0xFFFF and reset)?



Timer Exercise 6

- If Timer_A is configured in Continuous Mode with the SMCLK set to 8 MHz and no additional prescaler, how long does it take for Timer_A to overflow (reach 0xFFFF and reset)?

After reaching 0xFFFF, it overflows back to 0x0000

$$\text{No prescaler} \rightarrow 1 \text{ timer tick} = \frac{1}{8,000,000} \text{ seconds} = \mathbf{125 \text{ ns}}$$

Total counts per overflow = 65,536

$$T_{\text{overflow}} = 65,536 \times 125 \text{ ns}$$

$$= \mathbf{0.008192 \text{ s}}$$



Timer for Lab 3

- Focusing on Timer_A
 - Two modes will be investigated

- Up mode

Family User's Guide (slau367o)

- Continuous mode

- Setup for the clock source

Using ACLK (32.768 KHz)

By default, ACLK is set to a built-in RC oscillator (37.5KHz).

We need to select 32.768 KHz, that can be done using this function:

chip's data sheet (page 123)

```
*****  
// Configures ACLK to 32.768 KHz crystal  
void config_ACLK_to_32KHz_crystal() {  
    // By default, ACLK is on LFMODCLK at 4.8MHz/128 = 37.5 KHz  
    // Reroute pins to LFXIN/LFXOUT functionality  
    PJSEL1 &= ~BIT4;  
    PJSELO |= BIT4;  
    // Wait until the oscillator fault flags remain cleared (settling)  
    CSCTL0 = CSKEY;                                // Unlock CS registers  
    do {  
        CSCTL5 &= ~LFXTOFFG;                      // Local fault flag  
        SFRIFG1 &= ~OFIFG;                          // Global fault flag  
    } while((CSCTL5 & LFXTOFFG) != 0);  
    CSCTL0_H = 0;                                  // Lock CS registers  
    return;  
}
```



Timer for Lab 3

- Focusing on Timer_A

- Two modes will be investigated

- Up mode

Family User's Guide (slau367o)

- Continuous mode

- Setup for the clock source

Using ACLK (32.768 KHz)

By default, ACLK is set to a built-in RC oscillator (37.5KHz).

We need to select 32.768 KHz, that can be done using this function:

chip's data sheet (page 123)

Enable the crystal oscillator

Wait for stabilization

Without calling this function, the default ACLK will be 37.5 KHz

```
*****  
// Configures ACLK to 32.768 KHz crystal  
void config_ACLK_to_32KHz_crystal() {  
    // By default, ACLK is on LFMODCLK at 4.8MHz/128 = 37.5 KHz  
    // Reroute pins to LFXIN/LFXOUT functionality  
    PJSEL1 &= ~BIT4;  
    PJSELO |= BIT4; ━━━━> ACLK source selection  
    // Wait until the oscillator fault flags remain cleared (settling)  
    CSCTL0 = CSKEY; ━━━━> // Unlock CS registers  
    do {  
        CSCTL5 &= ~LFXTOFFG; ━━━━> // Local fault flag  
        SFRIFG1 &= ~OFIFG; ━━━━> // Global fault flag  
    } while((CSCTL5 & LFXTOFFG) != 0);  
    CSCTL0_H = 0; ━━━━> // Lock CS registers  
    return;  
}
```

Timer for Lab 3

- **Signal Repeater**

- Whatever you push (and hold) – the duration - using push button S1
 - will be replayed on redLED!
- If you exceed a maximum time (64K cycle or 2 seconds)
 - An error flag will be shown on greenLED!
- Once error flag is raised
 - not working anymore until reset is pushed by push button S2.
- *Counter in continuous mode*
- *Once push button is pressed → counter starts to count.*
- *Once push button is released → counter will be stopped (TAOR will be recorded).*
- *If TAOR < 0xffff → the redLED will be toggled on for the same amount of count.*
- *If TAOR > 0xffff (TAIFG is triggered) → greenLED will be ON. Waiting for S2 to rst.*



Thank You!

Questions?

Email: hadi.mardanikamali@ucf.edu
UCF HEC 435 (407) 823 - 0764
<https://www.ece.ucf.edu/~kamali/>

HAVEN Research Group
<https://haven.ece.ucf.edu/>

