Free Modular

Output

The Output module lets you take a stereo audio signal out of your Eurorack case and pass it to other audio gear, an audio interface, speakers, or headphones. It provides a balanced line level output and a dedicated stereo headphone output with independent volume controls for both and a VU meter to measure your output levels.

Line Out Volume


Controls the volume of the line level output. At full clockwise, the module will convert a typical 10v peak-topeak Eurorack audio signal to 7dBu for a sign wave (or 10dBu for a square wave), so a slight boost above "line level" at 4dBu. At full CCW, the signal is silenced.

VU Meter

These LEDs indicate peak level on the line output. This is not a true VU meter; it shows peak amplitude instead of dBu (RMS). The printed numbers indicate the equivalent dBu assuming a sine wave. If the output is a more compressed wave, the true output might be a few dBu higher than indicated.

Line Out

Balanced 1/4 in. TRS jacks output line level signal for both left and right channels. The output impedance is 100Ω , although that can be changed.



Headphone Volume

Controls the volume of the stereo headphone output.

Input

Accepts the Eurorack audio output from the rest of your system. AC-coupled. Left and right are each normalled to each other, so plugging into either will output the mono signal on both channels.

Headphone Output

1/4 in. TRS jack outputs headphone signal. This output should have enough power to drive studio headphones with minimal distortion. It can easily be stepped down to a 3.5mm jack with an insert adapter for consumer headphones.