Anatomy of the Quirkbot

FRONT

Horn

ON/OFF Switch

Right Eye = Ground

Left Eye = Power

Right Arm

Left Arm

Right Eye LED

Left Eye LED

Right Mounth LED

Left Mounth LED

Charge Indicator LED

USB

Right Leg

Left Leg

BACK

Registration Slot

Backpack Connections

BP1
BP2
BP3
BP4
BP5
BP6

+ Power
± Ground
⊓ SCK
← MOSI
→ MISO
↺ Reset

*Advanced users can find a complete documentation with shematics and a full list of all the pins and their functions at: forum.quirkbot.com