
$\textbf{King Slide}^* - 2X^*A7 \quad (X^*=2A/2B/2C/2D \ ; \ The \ drawings \ below \ are \ for \ assembling \ only. \ The \ real \ object \ should \ be \ considered \ as \ final.)$


Before installation, check the Cable Management Arm (CMA) installation direction and switch the CMA connector.

- 1.Press "PUSH" button.
- 2.Spin 180 degree to change the direction.




Cable Management Arm Installation

1. Install the inner member. Install (A) onto (B).




2.Install the outer member Install (C) onto (D).




3.Install the outer member Install (E) onto (F).







- B = CMA connector base on inner member
- C = CMA connector
- D = CMA connector base on outer member
- E = CMA connector beside the center CMA body
- F = CMA connector base on outer member




CAUTION!


Loop strap must be tied to the CMA crossbar. This is a transportation accessory; Remove the loop strap after the system arrives at the final destination.

Cable Management Arm Release

(1) Release the outer member Press the "PUSH" button on the CMA plug-in part



- (2) Release the outer member
 - (A)Turn CMA 90 degree to the right hand side to maintain the chassis or resume the removal.
 - (B)Press the "PUSH" button on the CMA plug-in part to draw it out.



(3) Release the inner member

Press the "PUSH" button on the CMA plug-in part to draw it out.

