

# Εθνικό Μετσόβιο Πολυτεχνείο

## Σχολή Ηλεκτρολόγων Μηχανικών & Μηχανικών Υπολογιστών

# 6° Εξάμηνο Συστήματα Μικροϋπολογιστών

2η ΟΜΑΔΑ ΑΣΚΗΣΕΩΝ

Χατζή Ήβη

#### Ασκήσεις προσομοίωσης

#### 1η ΑΣΚΗΣΗ

```
IN 10H
              ;numbers 0-255 in A
  MVI A,00H
 LXI B,0000H ; number of binary ones in B
 MVI D,00H ; numbers 10H-60H in D LXI H,0900H ; addresses
NUMBER:
               ; save number A in memory
 MOV M, A
 MOV M, A
MOV E, A
                ; save number A in E cause we edit A in ONES loop
ONES:
  CPI 00H
                ; when A is all zeros, stop checking
  JZ CONTINUE
  STC
  CMC
                ; set carry to 0
  RAR
                ; put each bit in carry and check
  JNC ONES
  INX B
                ;found a one
  JMP ONES
CONTINUE:
  MOV A, E
                ;restore number in A
  CPI 10H
  JC NEXT
                ; A<10H, check next number
  CPI 60H
  JC ADD
                ;A<60H
  JNZ NEXT
                ;A>60H, check next number
ADD:
  INR D
                ;10H<=A<=60H so increase D
NEXT:
 INR A
               ; next number
 INX H
                ; next space in memory
  CPI 00H
                ; when A reaches 256 it rolls back to 00H
  JZ FINISH
  JMP NUMBER
FINISH:
  END
```

#### 2η ΑΣΚΗΣΗ

```
LXI B,00C8H
             ;delay 200ms=C8H
SET:
 MVI A, FFH
 STA 3000H
 MVI D,64H
                ;timer 20s=200ms*100, 100=64H
START:
 LDA 2000H
                 ;input
                 ;msb in carry
 RAL
 CALL DELB
                ;delay 200ms
 JC OFF1
                ;msb is off
 JMP START
OFF1:
 LDA 2000H
               get input;
 RAL
                 ;check msb
 CALL DELB
                 ; delay 200ms
 JNC OFF1
                 ; msb is off
ON1:
               ;get input
 LDA 2000H
 RAL
                 ; check msb
 CALL DELB
               ;delay 200ms
 JC ON1
                ;msb is on
OFF2:
 MVI A,00H
 STA 3000H
                ;light LEDS
 CALL DELB
                ;delay 200ms
             get input;
 LDA 2000H
                 ; check msb
 RAL
 JC ON2
                ;msb is on
 DCR D
                 ;decrease timer
 MOV A, D
 CPI 00H
                ;check if timer reached 0
                ;timer not 0, keep lighting
 JNZ OFF2
 JMP SET
                ;timer reached 0, reset
ON2:
 DCR D
                 ; decrease timer
 MOV A, D
 CPI 00H
                 ; check if timer reached 0
  JZ SET
                 ;timer reached 0, reset
 LDA 2000H
                ; get input
                 ; check msb
  JC RESETTIMER
                 ;msb is off, reset timer
 MVI A,00H
 STA 3000H
                 ;light LEDS
 CALL DELB
                 ;delay 200ms
```

```
JMP ON2

RESETTIMER:

MVI D,64H

JMP OFF2
```

END

#### 3η ΑΣΚΗΣΗ

#### i.

```
START:
     LDA 2000H
     MOV B, A ; put input in B
     MVI C,00H ;C is counter
     MVI D,01H ;set D to 00000001
LOOP1:
     INR C
     MOV A, B
     ANI 01H
                  ;lsb=1?
     JNZ LIGHT ; found rightmost 1, light LEDs
     MOV A, B
     RRC
                ; move to check next bit
     MOV B, A
     MOV A, D
     RAL
               ; rotate D (D holds LED that will light)
     MOV D, A
     MOV A, C
     CPI 08H
                ; checked all bits, loop again
     JNZ LOOP1
LIGHT:
     MOV A, D
     CMA
     STA 3000H
     JMP START
END
```

#### ii.

```
START:
 CALL KIND ; input at A
 CPI 09H ;if A>=9 get input again
 JNC START
 CPI 00H
           ;if A=0 get input again
 JZ START
 MOV B, A ; put input in B
 MVI D, FFH ; D=11111111
LOOP2:
 DCR B
 MOV A, D
 RAL ; rotate D and pad with 0
 MOV D,A
 MOV A, B
 CPI 00H ;if B>0 keep looping
 JNZ LOOP2
 MOV A, D
            ; rotate D once to the right cause we have done one extra
 RAR
rotation
            ;set MSB=1
 ORI 80H
 CMA
 STA 3000H
 JMP START
END
```

```
iii.
```

```
IN 10H
     LXI H, OA30H ; output at OA30H, far from program data
     MVI M, 10H ; 10H means print nothing
                ;store output at OA30H-OA35H
     INX H
     MVI M,10H
     INX H
     MVI M, 10H
               ; OA30H to OA33H digits 1-3 print nothing
     MVI M, 10H
START:
LINE 0:
     MVI A, FEH ; FEH = 111111110, select line 0
     STA 2800H ;store in 2800H
     LDA 1800H ; read column
     ANI 07H ;3 lsb have the info
     MVI C,86H ;set C=INSTR STEP
     CPI 06H
                ; if A=00000110 then button from column 1 is pressed
     JZ DISPLAY ; go to display it
     MVI C,85H ;C=FETCH PC
     CPI 05H
             ; if A=00000101 then button from column 2 is pressed
     JZ DISPLAY
     MVI C, F7H ; C=HRDWR STEP
     CPI 03H ;if A=00000011 then button from column 3 is pressed
     JZ DISPLAY
LINE 1:
     MVI A, FDH
     STA 2800H
     LDA 1800H
     ANI 07H
     MVI C,84H
     CPI 06H
               ; RUN
     JZ DISPLAY
     MVI C,80H
     CPI 05H
               ; FETCH REG
     JZ DISPLAY
     MVI C,82H
     CPI 03H
               ; FETCH ADRS
     JZ DISPLAY
LINE 2:
     MVI A, FBH
     STA 2800H
     LDA 1800H
     ANI 07H
     MVI C,00H
     CPI 06H
               ; 0
     JZ DISPLAY
     MVI C,83H
     CPI 05H
               ;STORE/INCR
     JZ DISPLAY
     MVI C,81H
```

```
CPI 03H ; DECR
     JZ DISPLAY
LINE 3:
     MVI A, F7H
     STA 2800H
     LDA 1800H
     ANI 07H
     MVI C,01H
     CPI 06H ;1
     JZ DISPLAY
     MVI C,02H
               ; 2
     CPI 05H
     JZ DISPLAY
     MVI C,03H
     CPI 03H
               ; 3
     JZ DISPLAY
LINE 4:
     MVI A, EFH
     STA 2800H
     LDA 1800H
     ANI 07H
     MVI C,04H
     CPI 06H
              ; 4
     JZ DISPLAY
     MVI C,05H
     CPI 05H
               ; 5
     JZ DISPLAY
     MVI C,06H
               ;6
     CPI 03H
     JZ DISPLAY
LINE 5:
     MVI A, DFH
     STA 2800H
     LDA 1800H
     ANI 07H
     MVI C,07H
     CPI 06H
     JZ DISPLAY
     MVI C,08H
     CPI 05H
               ;8
     JZ DISPLAY
     MVI C,09H
     CPI 03H
               ;9
     JZ DISPLAY
LINE 6:
     MVI A, BFH
     STA 2800H
     LDA 1800H
     ANI 07H
     MVI C, OAH
     CPI 06H
               ; A
     JZ DISPLAY
     MVI C, OBH
```

```
CPI 05H ;B
     JZ DISPLAY
     MVI C, OCH
     CPI 03H
             ; C
     JZ DISPLAY
LINE 7:
     MVI A,7FH
     STA 2800H
     LDA 1800H
     ANI 07H
     MVI C, ODH
     CPI 06H
               ; D
     JZ DISPLAY
     MVI C, OEH
     CPI 05H
             ; E
     JZ DISPLAY
     MVI C, OFH
     CPI 03H
               ; F
     JZ DISPLAY
     JMP START ; if no button is pressed, check again
DISPLAY:
     LXI H, OA34H
     MOV A,C ;C has output
     ANI OFH
               ; isolate the 4 LSBs
     MOV M,A ;store them to 0A30H(first digit from left)
     INX H
               ; HL++
     MOV A, C
     ANI FOH ; isolate the 4 MSBs
               ; shift them to the 4 LSBs
     RRC
     RRC
     RRC
     RRC
     MOV M,A ; store them to 0A31(second digit from left)
                    ; move the block OA30 to OA35 to the memory
     LXI D, OA30H
     CALL STDM ; where the DCD routine reads
               ;print
     CALL DCD
     JMP START
     END
```

#### 4η ΑΣΚΗΣΗ


```
START:
     MVI D,00H
     LDA 2000H
     ANI 80H
                ; isolate msb to get A3
                ; shift and store in B
     RRC
     MOV B, A
     LDA 2000H
     ANI 40H
               ; isolate bit 01000000 to get B3
     ANA B
                ; A3 AND B3
     RRC
                ; shift twice for the OR with (A2 AND B2)
     RRC
     MOV C, A
                ; shift again to get X3 and store in D
     RRC
     MOV D, A
     LDA 2000H
     ANI 20H ; isolate bit 00100000 to get A2
     RRC
                ; shift and store in B
     MOV B, A
     LDA 2000H
     ANI 10H ; isolate bit 00010000 to get B2
     ANA B
               ; A2 AND B2
     ORA C
                ; (A1 AND B1) OR (A2 AND B2)
     RRC
                ;shift twice to put in X2
     RRC
     ORA D
                ;update D
     MOV D.A
     LDA 2000H
     ANI 08H
               ; isolate bit 00001000 to get A1
     RRC
                ; shift for XOR and store in B
     MOV B, A
     LDA 2000H
     ANI 04H
               ; isolate bit 00000100 to get B1
     XRA B
                ; A1 XOR B1
                ; shift twice for the XOR with (AO XOR BO) and store in C
     RRC
     RRC
     MOV C, A
                ; shift to put in X1
     RLC
     ORA D
                ;update D
     MOV D, A
     LDA 2000H
     ANI 02H
                ; isolate bit 00000010 for A0
     RRC
                ; shift for XOR with BO and store in B
     MOV B, A
     LDA 2000H
     ANI 01H
                ; isolate bit 00000001 for B0
     XRA B
                ; AO XOR BO
                ; (A0 XOR B0) XOR X1
     XRA C
     ORA D
                ;update D
     CMA
     STA 3000H
     JMP START
     END
```

#### Θεωρητικές Ασκήσεις

#### 5<sup>η</sup> AΣKHΣH:

Η μνήμη SRAM 256x4 bit μπορεί να δεχθεί 256 λέξεις μεγέθους 4 bit η καθεμία. Τη χωρίζουμε σε 4 τμήματα μεγέθους 256 bits, ώστε στο καθένα να βρίσκεται ένα bit της λέξης. Για κάθε τμήμα διαστάσεις 16x16. Επομένως, για την επιλογή της στήλης χρειαζόμαστε  $\log_2 16 = 4$  ακροδέκτες διεύθυνσης A0-A3 και τέσσερις πολυπλέκτες 16-σε-1, ενώ για την επιλογή της γραμμής χρειαζόμαστε  $\log_2 16 = 4$  ακροδέκτες διεύθυνσης A4-A7 και έναν αποκωδικοποιητή 4-σε-16. Οι ακροδέκτες D0-D3 αποτελούν τους ακροδέκτες εισόδου/εξόδου. Τα σήματα CS, WE, WR, καθορίζουν ποια λειτουργία (εγγραφή/ανάγνωση) θα επιτελεστεί ενεργοποιώντας ή απενεργοποιώντας τους κατάλληλους τρισταθείς buffers.

Παρουσιάζουμε της εσωτερική οργάνωση της μνήμης SRAM 256x4 bit.



#### Παράδειγμα: λειτουργία ανάγνωσης:

Έστω ότι θέλουμε να διαβάζουμε τη λέξη που βρίσκεται στη θέση μνήμης με διεύθυνση 00101100.

Για να ενεργοποιηθεί η λειτουργία μνήμης πρέπει να εφαρμοστεί ένας αρνητικός παλμός στον ακροδέκτη CS. Η λειτουργία ανάγνωσης (και η αποτροπή εγγραφής) σηματοδοτείται με την εφαρμογή αρνητικού παλμού στον ακροδέκτη RD και θετικού παλμού στον ακροδέκτη WS. Με αυτόν τον τρόπο η έξοδος της κάτω πύλης AND γίνεται 1, επιτρέποντας τη διέλευση δεδομένων από τους τρισταθείς buffers που μεταφέρουν τα δεδομένα από τους πολυπλέκτες προς τα D0-D3, ενώ η έξοδος τις άνω πύλης AND γίνεται 0 θέτοντας σε κατάσταση υψηλής αντίστασης τους buffers που μεταφέρουν δεδομένα από τα D0-D3 προς τους πολυπλέκτες, δηλαδή αποτρέποντας τη διέλευση από αυτούς.

Η διεύθυνση από την οποία θέλουμε να διαβάσουμε τίθεται ως είσοδος στους ακροδέκτες ΑΟ-Α7. Μέσω των Α4-Α7 και του αποκωδικοποιητή επιλέγεται η γραμμή που αντιστοιχεί στο 0010 (2 στο δεκαδικό). Μέσω των Α0-Α3 επιλέγεται και περνάει στην έξοδο κάθε πολυπλέκτη το bit που βρίσκεται στη στήλη που αντιστοιχεί στο 1100 (12 στο δεκαδικό). Στη συνέχεια τα bits αυτά διέρχονται από τους buffers και οδηγούνται στις εξόδους D0-D3.

Δηλαδή, με αυτόν τον τρόπο διαβάζουμε 4 bits, ένα από κάθε τμήμα μνήμης. Καθένα βρίσκεται στη 2<sup>η</sup> γραμμή και 12<sup>η</sup> στήλη του αντίστοιχου τμήματος.

#### Παράδειγμα: λειτουργία εγγραφής:

Έστω ότι θέλουμε να εγγράψουμε τη λέξη 0110 στη διεύθυνση 10111101.

Για να ενεργοποιηθεί η λειτουργία μνήμης πρέπει να εφαρμοστεί ένας αρνητικός παλμός στον ακροδέκτη CS. Η λειτουργία εγγραφής (και η αποτροπή ανάγνωσης) σηματοδοτείται με την εφαρμογή θετικού παλμού στον ακροδέκτη RD και αρνητικού παλμού στον ακροδέκτη WS. Με αυτόν τον τρόπο η έξοδος της άνω πύλης AND γίνεται 1, επιτρέποντας τη διέλευση δεδομένων από τους τρισταθείς buffers που μεταφέρουν τα δεδομένα από τα D0-D3 προς τους πολυπλέκτες, ενώ η έξοδος τις άνω πύλης AND γίνεται 0 θέτοντας σε κατάσταση υψηλής αντίστασης τους buffers που μεταφέρουν δεδομένα από τους πολυπλέκτες προς τα D0-D3, δηλαδή αποτρέποντας τη διέλευση από αυτούς.

Κάθε bit της προς εγγραφή λέξης εφαρμόζεται στον αντίστοιχο ακροδέκτη εισόδου D0-D3 και φτάνει μέσω του buffer στον αντίστοιχο πολυπλέκτη. Η διεύθυνση εγγραφής τίθεται ως είσοδος στους ακροδέκτες A0-A7. Μέσω των A4-A7 και του αποκωδικοποιητή επιλέγεται η γραμμή που αντιστοιχεί στο 1011 (11 στο δυαδικό). Μέσω A0-A3 κάθε bit που φτάνει στους πολυπλέκτες οδηγείται στη στήλη που αντιστοιχεί στο 1101 (13 στο δυαδικό) του αντίστοιχου τμήματος μνήμης.

Δηλαδή, με αυτόν τον τρόπο το bit της λέξης που τίθεται στον D0 εγγράφεται στο πρώτο εξ αριστερών τμήμα μνήμης στην 11<sup>η</sup> γραμμή και 13<sup>η</sup> στήλη, το bit της λέξης που τίθεται στον D1 εγγράφεται στο δεύτερο τμήμα μνήμης στην 11<sup>η</sup> γραμμή και 13<sup>η</sup> στήλη, κοκ.

Σε περίπτωση που σταλεί αρνητικός παλμός ταυτόχρονα στα WE και WD όλοι οι buffers τίθενται σε κατάσταση υψηλής αντίστασης αποτρέποντας τη διέλευση δεδομένων, προστατεύοντας με αυτόν τον τρόπο την πληροφορία.


6η ΑΣΚΗΣΗ

Χάρτης μνήμης (2KB page, 6 pages):


Memory	Address	15 14 <b>13 12</b>	11 10 9 8	7654	3210
ROM1	0000	0000	0000	0000	0000
2K	07FF	0000	0111	1111	1111
ROM2	0800	0000	1000	0000	0000
2K	OFFF	0000	1111	1111	1111
ROM3	1000	0001	0000	0000	0000
4K	1FFF	0001	1111	1111	1111
SRAM1	2000	0010	0000	0000	0000
2K	27FF	0010	0111	1111	1111
SRAM2	2800	0010	1000	0000	0000
2K	2FFF	0010	1111	1111	1111

## Λογικά διαγράμματα:

## (α) Με αποκωδικοποιητή:



## (β) Μόνο με πύλες:



**7º ΑΣΚΗΣΗ** Χάρτης μνήμης (4KB page, 7 pages):

Memory	Address	15 14 13 12	11 10 9 8	7654	3210
ROM1	0000	0000	0000	0000	0000
12K	2FFF	0010	1111	1111	1111
RAM1	3000	0011	0000	0000	0000
4K	3FFF	0011	1111	1111	1111
RAM2	4000	0100	0000	0000	0000
4K	4FFF	0100	1111	1111	1111
RAM3	5000	0101	0000	0000	0000
4K	5FFF	0101	1111	1111	1111
ROM2	6000	0110	0000	0000	0000
4K	6FFF	0110	1111	1111	1111

## Λογικό διάγραμμα:

