


- Not to Scale -



Connection Table

P1	P5	Description	Color	Connections
-	1	Power	Red	fuseholder, J3-3R
-	4	Ignition	White	fuseholder, J4-1
12	-	OUT_0 (Buzzer)	Brown	J4-2
3	-	IN_3 (Panic / Privacy Switch)	Yellow	J3-1
-	2	Ground	Black	GND Lead, J3-2
14	-	OUT_2 (Switch LED)	White	J3-4
11	-	1BB Ground	Black	J2-2
10	-	1BB Data (ID Reader)	Grey	J2-1