Optical Fibers




Instructor: Prof. Bishakh Bhattacharya

Dept. of Mechanical Engineering

IIT Kanpur

India

E-mail : bishakh@iitk.ac.in



Content


- Introduction
- Basic components of Optical fiber
- Principle of operation
- Types of Optical fiber
- Wavelength, Attenuation and Bandwidth
- Applications

Optical Fibers




- Medium for carrying information from one point to another in the form of light.
- Fiber optics is not electrical in nature unlike copper form of transmission.
- It has been calculated that it would **require 30,000 kg of copper** to transmit the same amount of information as only **0.1 kg of optical fiber** material.

Optical Fiber Communications System



- The information (i.e., telephone conversation) in electronic form is first **digitized** into bits, that is, 1's and 0's; this is accomplished in the **encoder**.
- Then electrical signal is converted into an optical (photonic) one using the electrical-tooptical converter which is normally a semiconductor laser.
- Laser emits monochromatic and coherent light (infrared region, low absorption losses).
- The output converter is in the form of **pulses of light**; a binary "1" (high-power pulse), and a "0" (low-power pulse).
- Pulse signals are then fed into and carried through the fiber-optical cable.
- At receiving end reverse process takes place.





Reference: W.D Callister, 7 Ed.

Optical Fiber Components

It includes:-

- ☐ Core Signal passes through the core.
- ☐ Cladding Constrains the light rays to travel within the core.
- ☐ Coating Protects core and cladding from damage.





Basics


Refractive Index

Refractive Index,
$$n = \frac{Speed\ of\ light\ in\ a\ vacuum}{Speed\ of\ light\ in\ a\ Medium}$$


- The *Refractive Index* of a vacuum by definition has a value of 1.
- The larger the refractive index, the more slowly light travels in that medium.

Total Internal Reflection

When a light ray traveling in one material hits a different material and **reflects** back into the original material without any loss of light, total internal reflection occurs.



Principle – Total Internal Reflection (TIR)



- The refractive index of Core (n_1) is **greater** than cladding (n_2) since core and cladding are constructed from **different compositions** of **silica glass**.
- Using Snell's law


$$n_1 sin heta_1 = n_2 sin heta_2$$
 For $heta_1$ = $heta_c$ = Critical angle $, heta_2$ = 90°,

 For angle of incidence greater than critical angle total internal reflection takes place.



Acceptance Cone

- Electrical signals are converted to light signals before they enter an optical fiber.
- To ensure that the signals reflect and travel correctly through the core, the light must enter the core through an imaginary acceptance cone.
- The size of this acceptance cone is a function of the refractive index difference between the core and the cladding.




Light Ray A: Entered acceptance cone; transmitted through the core by TIR

Light Ray B: Did not enter acceptance core; signal lost

Optical Fiber Designs

Internal reflection is accomplished by varying the index of refraction of the core and cladding glass materials.

Step-index Optical Fiber




- The index of refraction of the cladding (1.46) is slightly lower than that of the core (1.48).
- The main problem with this design is that different light rays follow slightly different trajectories and will therefore reach the **output at different times**.
- Hence, the output pulse is broader than the input pulse Not desirable (limits the data rate of digital communication)



Reference: W.D Callister, 7 Ed.

Graded-index Optical Fiber



- Impurities such as boron oxide (B_2O_3) or germanium dioxide (GeO_2) are added to the silica glass such that the **index of refraction** is made to **vary parabolically** across the cross section.
- Now, waves which travel in the outer regions, do so in a lower refractive index material and their velocity is higher (v = c/n).
- Therefore, they travel both *further* and *faster* as a result, they arrive at the output at almost the same time as the waves with shorter trajectories

Types of Fiber


- Impossible to distinguish between single-mode and multimode fiber with the naked eye.
- No difference in outward appearance, only in core size.


Single-mode (SM) fiber

- ✓ Allows only one pathway, or mode, of light to travel within the fiber.
- ✓ The core size is typically 8.3 μ m.
- ✓ Used in applications where low signal loss and high data rates are required.

Multimode (MM) fiber

- ✓ Allows more than one mode of light.
- ✓ Common Multimode core sizes are 50 μm and 62.5 μm.
- ✓ Better suited for shorter distance applications.





Wavelength

- Optical fiber transmission uses wavelengths which are above the visible light spectrum, and thus undetectable to the unaided eye.
- Typical optical transmission wavelengths are 850 nanometers (nm), 1310 nm, and 1550 nm.
- Both lasers and LEDs (light-emitting diodes) are used to transmit light through optical fiber.
- Lasers are usually used for 1310 or 1550 nanometer, single-mode applications.
- LEDs are used for 850 or 1300 nanometer multimode applications.

Attenuation


- ✓ Attenuation is the loss of optical power as light travels down a fiber.
- ✓ It is measured in decibels (dB/km).
- ✓ Over a set distance, a fiber with a lower attenuation will allow more power to reach its receiver than a fiber with higher attenuation.

Two types

- ☐ Intrinsic Attenuation
- ☐ Extrinsic Attenuation

Intrinsic Attenuation

- It is caused by impurities in the glass during the manufacturing process.
- Technological advances have caused attenuation to decrease dramatically since the first optical fiber in 1970.
- When a light signal hits an impurity in the fiber, one of two things will occur: it will scatter or it will be absorbed.




a) Scattering

Rayleigh Scattering

- Accounts for the majority (about 96%) of attenuation in optical fiber.
- The light waves elastically collide with the atoms, and light is scattered.
- If the light is scattered at an angle that does not support internal reflection, the light is diverted out of the core and attenuation occurs.

b) Absorption

- Second type of intrinsic attenuation.
- Absorption accounts for 3-5% of fiber attenuation.
- This phenomenon causes a light signal to be absorbed by natural impurities in the glass, and converted to vibrational energy or some other form of energy.
- Absorption can be limited by controlling the amount of impurities during the manufacturing process.




Extrinsic Attenuation

- Caused by two external mechanisms: Macro-bending and Micro-bending.
- Both causes a reduction in optical power.


Macro-bending

- Large-scale bend that is visible.
- For example, a fiber wrapped around a person's finger.
- This loss is generally reversible once bends are corrected.
- To prevent macrobends, all optical fiber (and optical fiber cable) has a <u>minimum bend radius</u> specification that should not be exceeded.




Micro-bending

- Micro-bending is very localized, and the bend may not be clearly visible upon inspection.
- May be related to temperature, tensile stress, or crushing force.
- With bare fiber, microbending may be reversible;
- But when many fibers are bundled in the form of cables, it may not be reversible.




Dispersion

- "Spreading" of a light pulse as it travels down a fiber.
- As the pulses spread, or broaden, they tend to overlap, and are no longer distinguishable by the receiver as 0s and 1s.
- Light pulses launched close together (high data rates) that spread too much (high dispersion) result in errors and loss of information.
- Dispersion is significant in multimode applications, where the various modes of light traveling down the fiber arrive at the receiver at different times, causing a spreading effect.
- Dispersion limits how fast, or how much, information can be sent over an optical fiber.




Bandwidth


- Bandwidth is the amount of information a fiber can carry so that every pulse is distinguishable by the receiver at the end.
- The spreading of these light pulses causes them to merge together. At a certain distance and frequency, the pulses become unreadable by the receiver.
- The multiple pathways of a multimode fiber cause this overlap to be much greater than for single-mode fiber.
- These different paths have different lengths, which cause each mode of light to arrive at a different time.



Applications

- Optical fiber **experiences geometrical** (size, shape) and **optical** (refractive index, mode conversion) **changes** depending upon the nature and the magnitude of the **perturbation**.
- So the **optical fibre** serves as a **transducer** and **converts measurands** like temperature, stress, strain, rotation or electric and magnetic currents into a corresponding **change in the optical radiation**.
- Since light is characterized by intensity, phase, frequency and polarization, any one or more of these parameters may undergo a change.





Intrinsic Sensors: use the fiber itself as the transducer.

Extrinsic Sensors: Use fiber to supply light to a sensing device and return signal light to a detection system.