
# M2VA4 Procedure




## M2VA4 – Audio – Component Removal

IC9 is required for system operation (reset circuit, reference voltage)




### M2VA4 – Audio Components Removed

Note: the "C" and "X" pads on the 3BP are interchangeable. The gain is the same (300/210), so connecting the 3BP "CL" pad to the Genesis "XL" pad and vise versa has no impact.



# M2VA4 – Video – Component Removal & CVBS Restore Points



#### M2VA4 – 3BP Jumpers

- Solder the following jumpers:
  - 3
  - D-Right
  - S75 if NOT restoring CVBS (V2A/V2+)

### M2VA4 Routing Complete

 If routing under the cart slot, it is recommended to solder the RGB wires to the 3BP first, then pull the other end through the cart slot pins.

