# **RF62X-SDK Documentation**

Выпуск 2.0.0

**Vladislav Kuzmin** 

сент. 15, 2021

# Подготовка к работе

1	Под	готовка к работе	3					
	1.1	Введение	3					
	1.2	Целевые платформы и совместимость	4					
	1.3		5					
	1.4	1 19	6					
	1.5	· ·	9					
2	Созд	Создание проекта						
	2.1	Создание проекта С/С++	1					
	2.2	Создание проекта С#	8					
	2.3		9					
3	Компиляция SDK 2 <sup></sup>							
	3.1	Компиляция «ядра»	1					
	3.2	Компиляция «обёртки» на С	0					
	3.3	Компиляция «обёртки» на С++	.1					
	3.4	Компиляция «обёртки» на С#	.2					
4	Опи	сания АРІ	-5					
	4.1	Интерфейс «обёртки» на С	.5					
	4.2	Интерфейс «обёртки» на С++	6					
	4.3	Интерфейс «обёртки» на С#	39					
5	При	меры использования 15	9					
	5.1	Примеры для С	59					
	5.2	Примеры для C++	<b>7</b> 4					
		Downers and C#						



Подготовка к работе

# 1.1 Введение

#### 1.1.1 Общее описание

**RF62X-SDK** - набор средств разработки, который позволяет специалистам создавать собственное программное обеспечение для работы с лазерными сканерами серии **RF62X** (*RF627 v20.x.x.x, RF627 v2.x.x, RF629 v2.x.x*) производства компании РИФТЭК.

# 1.1.2 Архитектура библиотеки

RF62X-SDK состоит из двух частей:

- RF62X-Core основная библиотека («Ядро») с базовым набором функций и типов для работы с лазерными сканерами серии RF62X. Библиотека написана на языке программирования СИ в соответствии со стандартом С99 (ISO/IEC 9899:1999) и является кросс-платформенной. Для использования данной библиотеки необходима реализация платформозависимых функций (работа с памятью, работа с сетью, функции ввода/вывода).
- RF62X-Wrappers библиотеки-«обёртки», в которых уже реализованы платформозависимые функции «Ядра» для конкретной платформы. Использование библиотек-«обёрток» упрощает процесс разработки приложений на следующих языках программирования: C, C++, C#, Python, LabVIEW, MatLab.

## 1.1.3 Принципы использования

Разработчики, которые при создании собственных приложений планируют использовать RF62X-SDK в виде **статических или динамических программных библиотек**, могут скачать готовый архив библиотек необходимой версии или собрать библиотеку RF62X-SDK самостоятельно из исходников (см.подробнее: компиляция библиотек RF62X-SDK из исходников).

Разработчики, которые предпочитают при создании собственных приложений использовать библиотеку RF62X-SDK в виде файлов исходного кода, должны скачать проект библиотеки RF62X-SDK (инструкции по скачиванию исходников см. *Скачивание проекта*) и включить необходимые файлы библиотеки в свой проект.

**Примечание:** Более подробно о использовании библиотеки RF62X-SDK в качестве файлов исходного кода или в качестве статической/динамической программной библиотеки при создании собственных приложений смотрите в разделе: *Создание проекта* 

# 1.1.4 Основной функционал

Методы работы со канером:

- Поиск сканеров серии RF62X (RF627 v20.x.x.x, RF627 v2.x.x, RF629 v2.x.x).
- Получение результатов измерений.
- Получение кадров видео с матрицы сканера
- Получение/установка параметров.
- Запись/скачивание дампа профилей.
- Программный запуск/остановка измерений.
- Запись/сохранение калибровочной таблицы.
- Перезагрузка/сброс сканера/матрицы.
- Отправка/получение данных при работе с периферией.

Поддерживаемые протоколы информационного обмена со сканерами:

- RF627-Protocol (UDP). Актуально для сканеров серии RF627 v20.x.x.x
- RF62X-Protocol (UDP). Актуально для сканеров серии RF627/RF629 v2.x.x

#### 1.1.5 Что нового

- Запись/скачивание дампа профилей.
- Программный запуск/остановка измерений.
- Перезагрузка/сброс сканера/матрицы.
- Отправка/получение данных при работе с периферией.

# 1.2 Целевые платформы и совместимость

#### 1.2.1 Языки программирования

Основная программная библиотека RF62X-Core («Ядро») написана на языке СИ стандарта С99 (ISO/IEC 9899:1999) без использования сторонних программных модулей и зависимых от операционной системы или процессора функций.

# 1.2.2 Целевые платформы

Достигнута совместимость с любыми операционными системами семейства Windows и Linux, поддерживающими компиляторы языка СИ стандарта С99 (ISO/IEC 9899:1999). Библиотека компилируется из исходных кодов и может быть использована с любыми типами процессоров (x86, ARM, RISC-V и др.).

# 1.2.3 Поддерживаемые компиляторы

- GCC 5.х или новее в Linux
- XCode 8.0 или новее в OS X
- MSVC2017 или новее в Windows

#### 1.2.4 Ссылки

Этот проект использует git для управления исходным кодом и GitHub для размещения исходного кода.

- Репозиторий проекта: https://github.com/RIFTEK-LLC/RF62X-SDK
- Документация: RF62X-SDK.ru.pdf, RF62X-SDK.en.pdf
- Форум: https://bustezeu.beget.tech/index.php

# 1.3 Предустановка и настройка системы

## 1.3.1 Установка программного обеспечения

Есть несколько вариантов построения библиотеки RF62X-SDK. Все варианты поддерживаются и должны работать одинаково корректно для:

- IDE Visual Studio 2017 и выше
- IDE Qt Creator 4.11.0 и выше
- CMake 3.13 и выше

**Примечание:** Если вы знакомы с CMake, то вы также можете самостоятельно создавать(открыть) проект библиотеки для любой поддерживающей CMake среды.

Если возникли сложности с установкой или настройкой сред разработки, ниже приведены более подробные инструкции:

- IDE Visual Studio 2019 (дополнительная информация доступна на оффициальном сайте docs.microsoft.com )
- IDE Qt Creator ( дополнительная информация доступна на оффициальном сайте qt.io )
- СМаке ( дополнительная информация доступна на оффициальном сайте cmake.org)

# 1.4 Скачивание проекта

#### 1.4.1 Git-клиент

Для разработчиков, которые хотят скачать библиотеку из исходников с помощью Git-клиента, следует выполнить следующие инструкции:

- Установите git-клиент на свой локальный компьютер (если ещё не установлен)
  - B Linux используйте команду терминала: sudo apt install git
  - Ha MacOS используйте команду терминала: brew install git
  - Для других платформ смотрите документацию по установке git-клиента.
- Откройте командную строку/терминал на вашем компьютере
  - В Linux щелкните панель запуска и найдите terminal
  - B OS X нажмите command-space и найдите terminal
  - B Windows нажмите меню «Пуск» и найдите «командную строку» cmd.
- Клонируйте репозиторий с помощью следующих команд:

```
git clone https://github.com/RIFTEK-LLC/RF62X-SDK.git cd RF62X-SDK git submodule update --init --recursive
```

#### 1.4.2 Git B Qt Creator


Для разработчиков, которые хотят скачать и собрать библиотеку из исходников с помощью Git, встроенного в IDE Qt Creator, следует выполнить следующие инструкции:


- 1. Нажмите File > New File or Project
- 2. Выберите опцию Import Project > Git Clone, как показано ниже.
- 3. Введите url-адрес SDK https://github.com/RIFTEK-LLC/RF62X-SDK.git, выберите опцию «Recursive», а затем нажмите Next.
- 4. После загрузки откройте файл CMakeLists.txt необходимого вам проекта через File > Open File or Project, выберите компилятор (*MinGW, MSVC, Clang*) и нажмите Configure Project
- 5. Запустите компиляцию проекта


## 1.4.3 Git B Visual Studio


Для разработчиков, которые хотят скачать и собрать библиотеку из исходников с помощью Git, встроенного в IDE Visual Studio, следует выполнить следующие инструкции:

- 1. Откройте Visual Studio 2019.
- 2. В стартовом окне выберите Клонирование или извлечение кода.
- 3. Введите url-адрес SDK https://github.com/RIFTEK-LLC/RF62X-SDK.git, выберите или введите местоположение хранилища, а затем нажмите **Клонировать**.









- 4. После чего Visual Studio загрузит проект из удаленного репозитория и откроет его.
- 5. Выберите один из необходимых вам проектов и запустите его сборку.

**Примечание:** Перед использованием Git-клиента в Visual Studio необходимо убедиться в установке дополнительного компонента C++ CMake tools для Windows.

# 1.5 Запуск примеров

Для быстрого старта, а также проверки базового функционала SDK (поиск устройств, получение профилей/кадров, установка/получение параметров, скачивание дампа и др.), разработчику предоставляется возможность открыть один из имеющихся примеров проектов на одном из доступных языков программирования (C/C++, C#, Python) и запустить его выполнение.

# 1.5.1 Запуск примеров на С/С++

#### **Qt Creator**

- 1. Откройте файл CMakeLists.txt из папки RF62X-SDK/Examples/Cpp через File > Open File or Project (укажите файл *CMakeLists.txt*)
- 2. Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project.
- 3. Скомпилируйте и запустите один из примеров

#### **Visual Studio:**

1. В папке с примерами RF62X-SDK/Examples/Cpp откройте «командную строку» или «терминал» и введите следующую команду для создания Visual Studio проекта:

```
mkdir build && cd build cmake ..
```

- 2. Otkpoйte созданный проект RF62XSDK-EXAMPLES.sln в папке build
- 3. Скомпилируйте и запустите один из примеров

## 1.5.2 Запуск примеров на С#

- 1. Используя Visual Studio откройте один из имеющихся проектов (*RF627\_smart*, *RF627\_old*, *RF62X\_WinForms*) в папке RF62X—SDK/Examples/CSharp.
- 2. Укажите целевую платформу **x64 Debug** или **x64 Release**
- 3. Скомпилируйте один из примеров
- 4. Перед запуском скачайте архив библиотек для C# (смотреть последние выпуски RF62X-SDK библиотек) и скопируйте из архива в папке Dependencies все файлы с именем libRF62X-SDK в папку к исполняемому файлу проекта (../bin/x64/Debug/или ../bin/x64/Release/)

5. Запустите пример

# 1.5.3 Запуск примеров на Python

- 1. Используя Visual Studio Code (или иное IDE с поддержкой Python) откройте один из имеющихся проектов (*RF627\_SMART*, *RF627\_OLD*) в папке RF62X-SDK/Examples/Python.
- 2. Скачайте архив библиотек для Python (смотреть последние выпуски RF62X-SDK библиотек) и скопируйте из архива в папке Dependencies все файлы с именем libRF62X-SDK в папку к исполняемому файлу проекта.
- 3. Запустите пример

Создание проекта

В данном разделе приведены примеры создания проектов на языках C++, C# и Python с использованием проекта RF62X-SDK в качестве файлов исходного кода и в качестве статической или динамической программной библиотеки.

# 2.1 Создание проекта С/С++

# 2.1.1 Qt Creator + CMake + RF62X-SDK в качестве библиотеки

Для создания нового CMake проекта в Qt Creator с использованием динамической/статической линковки SDK необходимо выполнить следующий порядок действий:

- В Qt Creator создайте новый проект открыв в меню File > New File or Project, укажите Qt Console Application и нажмите кнопку Choose
- Введите имя проекта в поле **Project Name** и укажите путь к папке с проектом в поле **Project Location**, после ввода нажмите кнопку **Next**
- Выберите **CMake** в качестве системы постояние проекта и нажмите кнопку **Next** дважды
- Выберите компилятор (*MinGW*, *MSVC*, *Clang*), нажмите кнопку **Next** и завершите настройку проекта
- Скачайте архив библиотек для C/C++ (смотреть последние выпуски RF62X-SDK библиотек)
- Измените файл CMakeLists.txt вашего проекта в соответствии с приведенным ниже примером:

cmake_minimum_required(VERSION 3.14)	
######################################	ŧ

```
## name and version
project (RF62X_Search_Example LANGUAGES CXX)
## SETTINGS
## basic project settings before use
set (CMAKE INCLUDE CURRENT DIR ON)
set (CMAKE_CXX_STANDARD 11)
set (CMAKE_CXX_STANDARD_REQUIRED ON)
# creating output directory architecture in accordance with GNU guidelines
set (BINARY_DIR "${CMAKE_BINARY_DIR}")
set (CMAKE RUNTIME OUTPUT DIRECTORY "${BINARY DIR}/bin")
set (CMAKE LIBRARY OUTPUT DIRECTORY "${BINARY DIR}/lib")
## TARGET
## create target and add include path
# create glob files for *.h, *.cpp
file (GLOB H_FILES ${CMAKE_CURRENT_SOURCE_DIR}/*.h)
file (GLOB CPP_FILES ${CMAKE_CURRENT_SOURCE_DIR}/*.cpp)
# concatenate the results (glob files) to variable
set (SOURCES ${CPP_FILES} ${H_FILES})
# create executable from src
add_executable(${PROJECT_NAME} ${SOURCES})
## FIND PACKEGE AND LINK LIBRARIES
## linking all dependencies
SET (RF62X SDK LIBRARY TYPE "STATIC")
if (MSVC)
  find package (RF62X-SDK PATHS "../RF62X-SDK cpp/MSVC2019 64bit/CMake")
elseif (MINGW)
  find_package(RF62X-SDK PATHS "../RF62X-SDK_cpp/MinGW_64bit/CMake")
else()
  find_package(RF62X-SDK PATHS "../RF62X-SDK_cpp/GCC_64bit/CMake")
endif()
target_link_directories(${PROJECT_NAME} PUBLIC ${RF62X_SDK_LIBRARY_DIRS})
target_link_libraries(${PROJECT_NAME} PUBLIC ${RF62X_SDK_LIBRARIES})
target_include_directories(${PROJECT_NAME} PUBLIC ${RF62X_SDK_INCLUDE_DIRS})
```

**Примечание**: Для работы с динамической библиотекой RF62X-SDK необходимо установить параметр *RF62X\_SDK\_LIBRARY\_TYPE* в значение *SHARED* (SET (RF62X\_SDK\_LIBRARY\_TYPE "SHARED")) и скопировать библиотеку RF62X-SDK.dll(\*.so) в каталог к исполняемому файлу проекта (PROJECT\_BINARY\_DIR)

• Измените файл main.cpp вашего проекта в соответствии с приведенным ниже примером:

```
#include <string>
#include <iostream>
```

```
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
using namespace SDK::SCANNERS::RF62X;
int main()
  #" << std::endl;
  std::cout << "#
                                                     #" << std::endl;
  std::cout << "#
                        Search Example v2.x.x
                                                     #" << std::endl;
  std::cout << "#
  // Initialize sdk library
  sdk init();
  // Print return rf62X sdk version
  std::cout << "SDK version: " << sdk_version()</pre>
                                                           << std::endl;
  std::cout << "========"""
                                                           << std::endl;
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search(500);
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: " << list.size()<< " RF627-Smart" << std::endl;</pre>
  std::cout << "-----" << std::endl;
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared ptr<hello info> info = list[i]->get info();
     std::cout << "\n\nID scanner's list: " << i</pre>
                                                           << std::endl;
     std::cout << "-----" << std::endl;
     std::cout << "Device information: "</pre>
                                                           << std::endl;
     std::cout << "* Name \t: " << info->device_name()
std::cout << "* Serial\t: " << info->serial_number()
std::cout << "* IP Addr\t: " << info->ip_address()
std::cout << "* MAC Addr\t: " << info->mac_address()
                                                           << std::endl;
                                                           << std::endl;
                                                            << std::endl;
                                                            << std::endl;
     std::cout << "\nWorking ranges: "</pre>
                                                            << std::endl;
     std::cout << "* Zsmr, mm\t: " << info->z_smr()
                                                           << std::endl;
     std::cout << "* Zmr , mm\t: " << info->z mr()
                                                           << std::endl;
     std::cout << "* Xsmr, mm\t: " << info->x_smr()
                                                           << std::endl;
     std::cout << "* Xemr, mm\t: " << info->x_emr()
                                                           << std::endl;
     std::cout << "\nVersions: "</pre>
                                                            << std::endl;
     std::cout << "* Firmware\t: " << info->firmware_version() << std::endl;</pre>
     std::cout << "* Hardware\t: " << info->hardware_version() << std::endl;</pre>
     std::cout << "-----" << std::endl;
  }
  // Cleanup resources allocated with sdk_init()
```

```
sdk_cleanup();
}
```

• Выберите тип сборки **Debug** или **Release** и запустите построение проекта.

# 2.1.2 Qt Creator + CMake + RF62X-SDK в качестве файлов исходного кода

Для создания нового CMake проекта в Qt Creator с использованием файлов исходного кода SDK необходимо выполнить следующий порядок действий:

- В Qt Creator создайте новый проект открыв в меню File > New File or Project, укажите Qt Console Application и нажмите кнопку Choose
- Введите имя проекта в поле **Project Name** и укажите путь к папке с проектом в поле **Project Location**, после ввода нажмите кнопку **Next**
- Выберите **CMake** в качестве системы постояние проекта и нажмите кнопку **Next** дважды
- Выберите компилятор (*MinGW*, *MSVC*, *Clang*), нажмите кнопку **Next** и завершите настройку проекта
- Скачайте **RF62X-SDK** проект (для получения дополнительной информации о шагах загрузки проекта см. *Скачивание проекта*)
- Измените файл CMakeLists.txt вашего проекта в соответствии с приведенным ниже примером и установите в параметре RF62XSDK\_DIR на путь к папке RF62X-Wrappers/Cpp в соответствии с расположением скачанного проекта RF62X-SDK

```
cmake_minimum_required(VERSION 3.14)
## EXECUTABLE-PROJECT
## name and version
project (RF62X_Search_Example LANGUAGES CXX)
## SETTINGS
## basic project settings before use
set (CMAKE_INCLUDE_CURRENT_DIR ON)
set (CMAKE_CXX_STANDARD 11)
set (CMAKE_CXX_STANDARD_REQUIRED ON)
# creating output directory architecture in accordance with GNU quidelines
set(BINARY DIR "${CMAKE BINARY DIR}")
set (CMAKE RUNTIME OUTPUT DIRECTORY "${BINARY DIR}/bin")
set (CMAKE LIBRARY OUTPUT DIRECTORY "${BINARY DIR}/lib")
## TARGET
## create target and add include path
# create glob files for *.h, *.cpp
file (GLOB H_FILES
           ${CMAKE_CURRENT_SOURCE_DIR}/*.h)
```

• Измените файл main.cpp вашего проекта в соответствии с приведенным ниже примером:

```
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
using namespace SDK::SCANNERS::RF62X;
int main()
  #" << std::endl;
  std::cout << "#
  std::cout << "#
                                                 #"
                                                    << std::endl;
                      Search Example v2.x.x
                                                 #" << std::endl;
  std::cout << "#
  std::cout << "#################################\n"<< std::endl;
  // Initialize sdk library
  sdk_init();
  // Print return rf62X sdk version
  std::cout << "SDK version: " << sdk_version()</pre>
                                                       << std::endl;
  std::cout << "==========""
                                                      << std::endl;
  // Create value for scanners vector's type
  std::vector<std::shared ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search(500);
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: " << list.size()<< " RF627-Smart" << std::endl;</pre>
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared ptr<hello info> info = list[i]->get info();
```

```
std::cout << "\n\nID scanner's list: " << i</pre>
                                                      << std::endl;
                                    -----" << std::endl;
     std::cout << "-----
     std::cout << "Device information: "</pre>
                                                       << std::endl;
     std::cout << "* IP Addr\t: " << info->ip_address() << std::endl;
     std::cout << "* MAC Addr\t: " << info->mac_address()
                                                      << std::endl;
     std::cout << "\nWorking ranges: "</pre>
                                                      << std::endl;
     std::cout << "* Zsmr, mm\t: " << info->z_smr()
                                                      << std::endl;
     std::cout << "* Zmr , mm\t: " << info->z_mr()
                                                      << std::endl;
     std::cout << "* Xsmr, mm\t: " << info->x_smr()
                                                       << std::endl;
     std::cout << "* Xemr, mm\t: " << info->x_emr()
                                                       << std::endl;
     std::cout << "\nVersions: "</pre>
                                                       << std::endl;
     std::cout << "* Firmware\t: " << info->firmware version() << std::endl;</pre>
     std::cout << "* Hardware\t: " << info->hardware version() << std::endl;</pre>
     std::cout << "-----" << std::endl;
  // Cleanup resources allocated with sdk_init()
  sdk_cleanup();
}
```

• Выберите тип сборки **Debug** или **Release** и запустите построение проекта.

#### 2.1.3 Visual Studio + RF62X-SDK в качестве библиотеки

Для создания нового проекта в Visual Studio с использованием динамической/статической линковки SDK необходимо выполнить следующий порядок действий:

- Откройте Visual Studio и выберите Create a new project, затем выберите Empty Project и нажмите кнопку Next
- Введите имя проекта в поле **Project Name** и укажите путь к папке с проектом в поле Project Location, после ввода нажмите кнопку Next
- Скачайте архив библиотек для C/C++ (смотреть последние выпуски RF62X-SDK библиотек)
- Добавьте файл main.cpp в проект и измените его, как показано ниже:

```
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
using namespace SDK::SCANNERS::RF62X;
int main()
  std::cout << "#
                                           # "
                                               << std::endl;
                                           #" << std::endl;
  std::cout << "#
                   Search Example v2.x.x
                                           #" << std::endl;
  std::cout << "#
```

```
// Initialize sdk library
sdk_init();
// Print return rf62X sdk version
std::cout << "SDK version: " << sdk_version()</pre>
                                               << std::endl;
std::cout << "==========""
                                               << std::endl;
// Create value for scanners vector's type
std::vector<std::shared_ptr<rf627smart>> list;
// Search for rf627smart devices over network
list = rf627smart::search(500);
// Print count of discovered rf627smart in network by Service Protocol
std::cout << "Was found\t: " << list.size()<< " RF627-Smart" << std::endl;</pre>
std::cout << "-----" << std::endl;
for (size_t i = 0; i < list.size(); i++)</pre>
  std::shared_ptr<hello_info> info = list[i]->get_info();
  std::cout << "\n\nID scanner's list: " << i</pre>
                                                << std::endl;
  std::cout << "-----" << std::endl;
  std::cout << "Device information: "</pre>
                                                << std::endl;
  std::cout << "\nWorking ranges: "</pre>
                                               << std::endl;
  std::cout << "* Xemr, mm\t: " << info->x_emr()
                                                << std::endl;
  std::cout << "\nVersions: "</pre>
                                                << std::endl;
  std::cout << "* Firmware\t: " << info->firmware_version() << std::endl;</pre>
  std::cout << "* Hardware\t: " << info->hardware_version() << std::endl;</pre>
  std::cout << "-----" << std::endl;
// Cleanup resources allocated with sdk_init()
sdk_cleanup();
```

- Выберите тип (*Debug* или *Release*) и разрядность (*x64* или *x86*) целевой платформы.
- Скопируйте файлы из скаченного архива в папке include в каталог проекта.
- Откройте **Project > Properties**, выберите **Configuration Properties > VC++ Directories** и добавьте пути к загруженным файлам заголовков и библиотекам в **Include Directories** и **Library Directories** соответственно.
- Скомпилируйте проект.
- Скопируйте библиотеки из скаченного архива в каталог к исполняемому файлу проекта

```
(../bin/x64/Debug/или ../bin/x64/Release/).
```

• Запустите проект.

# 2.2 Создание проекта С#

#### 2.2.1 Visual Studio + RF62X-SDK в качестве библиотеки

Для создания нового проекта в Visual Studio с использованием динамической библиотеки SDK необходимо выполнить следующий порядок действий:

- Откройте Visual Studio и выберите **Create a new project**, затем выберите **Empty Project** и нажмите кнопку **Next**
- Введите имя проекта в поле **Project Name** (например RF627\_search) и укажите путь к папке с проектом в поле **Project Location**, после ввода нажмите кнопку **Next**
- Измените файл Program.cs проекта, как показано ниже:

```
using System;
using System.Collections.Generic;
using SDK.SCANNERS;
namespace RF627_search
  class Program
     static void Main(string[] args)
        Console.WriteLine("#################################");
        Console.WriteLine("#
                                                                #");
                                                                #");
        Console.WriteLine("#
                                   Search Example v2.x.x
        Console.WriteLine("#
                                                                #");
        Console.WriteLine("################################");
        // Initialize sdk library
        RF62X.SdkInit();
        // Print return rf62X sdk version
        Console.WriteLine("SDK version: {0}", RF62X.SdkVersion());
        Console.WriteLine("=========");
        // Search for RF627smart devices over network
        List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
        // Print count of discovered rf627smart in network
        Console.WriteLine("Was found\t: {0} RF627-Smart", list.Count);
        Console.WriteLine("==========");
        for (int i = 0; i < list.Count; i++)</pre>
            RF62X.HelloInfo info = list[i].GetInfo();
            Console.WriteLine("\n\nID scanner's list: {0}", i);
            Console.WriteLine("-----
            Console.WriteLine("Device information: ");
            Console.WriteLine("* Name\t: {0}", info.device_name);
```

```
Console.WriteLine("* Serial\t: {0}", info.serial_number);
         Console.WriteLine("* IP Addr\t: {0}", info.ip_address);
         Console.WriteLine("* MAC Addr\t: {0}", info.mac_address);
         Console.WriteLine("\nWorking ranges: ");
         Console.WriteLine("* Zsmr, mm\t: {0}", info.z_smr);
         Console.WriteLine("* Zmr , mm\t: {0}", info.z_mr);
         Console.WriteLine("* Xsmr, mm\t: {0}", info.x_smr);
         Console.WriteLine("* Xemr, mm\t: {0}", info.x_emr);
         Console.WriteLine("\nVersions: ");
         Console.WriteLine("* Firmware\t: {0}", info.firmware_version);
         Console.WriteLine("* Hardware\t: {0}", info.hardware_version);
         Console.WriteLine("-----");
     }
     // Cleanup resources allocated with SdkInit()
     RF62X.SdkCleanup();
}
```

- Выберите тип (Debug или Release) и разрядность (x64 или x86) целевой платформы.
- Скачайте архив библиотек для С# (смотреть последние выпуски RF62X-SDK библиотек)
- Откройте **Project > Add References**, нажмите кнопку **Browse...** и подключите библиотеку **RF62X-SDK.dll** из скачанного архива в проект.
- Скомпилируйте проект.
- Скопируйте библиотеки из скаченного архива в папке Dependencies в каталог к исполняемому файлу проекта (../bin/x64/Debug/или ../bin/x64/Release/).
- Запустите проект.

# 2.3 Создание проекта Python

## 2.3.1 Visual Studio Code + RF62X-SDK в качестве библиотеки

Для создания нового Python проекта в Visual Studio Code с использованием динамической библиотеки СДК необходимо выполнить следующий порядок действий:

- Создайте каталог проекта и откройте его в Visual Studio Code
- Добавьте новый ру-файл (например, demo.py) в этот каталог проекта
- Скачайте архив библиотек для Python (смотреть последние выпуски RF62X-SDK библиотек)
- Разархивируйте файлы скачанного архива в каталог с проектом
- Измените ру-файл проекта (например, demo.py) в соответствии с примером ниже:

```
from PYSDK_SMART import *
if __name__ == '__main__':
print("##################")
print("#
                                            #")
print("#
               Search Example v2.x.x
                                            #")
print("#
print("##############")
# Initialize sdk library
sdk_init()
# Print return rf627 sdk version
print('SDK version', sdk_version())
print ("========"")
# Create value for scanners vector's type
list_scanners=search(500)
print("Was found\t:", len(list_scanners), "RF627-Smart")
print ("========"")
# Iterate over all available network adapters in the current operating
# system to send "Hello" requests.
i = 0
for scanner in list_scanners:
  info = get_info(scanner, kSERVICE)
  # Print short information about the scanner
  print("\n\nID scanner's list:", i)
  print("----")
  print("Device information:")
  print("* Name\t\t: ", info['user_general_deviceName'])
  print("* Serial\t: ", info['fact_general_serial'])
print("* IP Addr\t: ", info['user_network_ip'])
  print("* MAC Addr\t: ", info['fact_network_macAddr'])
  print("\nWorking ranges: ")
  print("* Zsmr, mm\t: ", info["fact_general_smr"])
  print("* Zmr, mm\t: ", info["fact_general_mr"])
  print("* Xsmr, mm\t: ", info["fact_general_xsmr"])
  print("* Xemr, mm\t: ", info["fact general xemr"])
  print("\nVersions: ")
  print("* Firmware\t: ", info["firmware_version"])
  print("* Hardware\t: ", info["hardware_version"])
# Cleanup resources allocated with sdk_init()
sdk_cleanup()
```

• Запустите проект.

Компиляция SDK

# 3.1 Компиляция «ядра»

# 3.1.1 Как скомпилировать

**RF62X-Core** может быть скомпилирован при помощи консоли или среды разработки (Visual Studio, Qt Creator).

Во-первых, вы должны загрузить проект (если не сделали этого ранее).

**Примечание:** Для получения дополнительной информации о шагах загрузки проекта см. *Скачивание проекта* 

# **CMake**

Находясь в папке проекта **RF62X-SDK** для построения RF62X-Core введите следующую команду в консоль (терминал):

```
cd RF62X-Core
mkdir build && cd build
cmake ..
cmake --build .
```

#### **Qt Creator**

Для построения RF62X-Core с использованием IDE Qt Creator:

- Загрузите файл CMakeLists.txt из папки RF62X-Core через File > Open File or Project (выберите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project

• Скомпилируйте проект

#### **Visual Studio**

Находясь в папке проекта **RF62X-SDK** для построения **RF62X-Core** введите следующую команду в консоль (терминал):

```
cd RF62X-Core
mkdir build && cd build
cmake ..
```

- Откройте полученное решение RF62X-Core.sln в Visual Studio
- Скомпилируйте проект

#### 3.1.2 Как использовать

Для использования библиотеки **RF62X-Core** вместо имеющихся библиотек-«обёрток» разработчику необходимо будет самостоятельно реализовать платформозависимую часть «ядра».

# Обзор платформозависимых функций

В **RF62X-Core** платформозависимые функции (работа с памятью, работа с сетью, функции ввода/вывода) представлены в виде указателей на функции.

Указатели на платформозависимые функции объявлены в файлах, memory\_platform.h, network\_platform.h и iostream\_platform.h.

#### calloc\_t

Прототип: typedef void\* (\*calloc\_t)(rfSize num, rfSize size);

Описание: Указатель на функцию calloc\_t выделяет блок памяти для массива размером num элементов, каждый из которых занимает size байт. В результате выделяется блок памяти размером number \* size байт, причём весь блок заполнен нулями.

#### Параметры:

- num Количество элементов массива, под который выделяется память.
- size Размер одного элемента в байтах.

Возвращаемое значение: Указатель на выделенный блок памяти. Тип данных на который ссылается указатель всегда void\*, поэтому это тип данных может быть приведен к желаемому типу. Если функции не удалось выделить требуемый блок памяти, возвращается нулевой указатель.

#### Пример в коде:

```
/** @file memory_platform.h */

/**
    * @brief Allocates an array in memory with elements initialized to 0.
    *
    * @param num Number of elements to allocate.
    * @param size Size of each element.
    *
    * @return
    * - On success: returns a pointer to the allocated space.
    * - On error: NULL
    */
typedef void* (*calloc_t) (rfSize num, rfSize size);
```

#### malloc\_t

Прототип: typedef void\* (\*malloc\_t)(rfSize size);

**Описание:** Указатель на функцию malloc\_t выделяет блок памяти размером size байт и возвращает указатель на начало блока. Содержание выделенного блока памяти не инициализируется, оно остается с неопределенными значениями.

#### Параметры:

• size - Размер выделяемого блока памяти в байтах.

Возвращаемое значение: Указатель на выделенный блок памяти. Тип данных на который ссылается указатель всегда void\*, поэтому это тип данных может быть приведен к желаемому типу. Если функции не удалось выделить требуемый блок памяти, возвращается нулевой указатель.

#### Пример в коде:

```
/** @file memory_platform.h */
/**
    * @brief malloc_t - ptr to function whish allocates memory block
    * Allocates a block of size bytes of memory, returning a pointer
    * to the beginning of the block.
    *
    * @param size Size of the memory block, in bytes.
    *
    * @return
    * - On success: returns a pointer to the allocated space.
    * - On error: NULL.
    */
typedef void* (*malloc_t) (rfSize size);
```

#### realloc\_t

Прототип: typedef void\* (\*realloc\_t)(void \*ptr, rfSize newsize);

Описание: Указатель на функцию realloc\_t выполняет перераспределение блоков памяти. Размер блока памяти, на который ссылается параметр ptr изменяется на newsize байтов. Блок памяти может уменьшаться или увеличиваться в размере.

Эта функция может перемещать блок памяти на новое место, в этом случае функция возвращает указатель на новое место в памяти. Содержание блока памяти сохраняется даже если новый блок имеет меньший размер, чем старый. Отбрасываются только те данные, которые не вместились в новый блок. Если новое значение newsize больше старого, то содержимое вновь выделенной памяти будет неопределенным.

В случае, если ptr равен NULL, функция ведет себя именно так, как функция  $malloc_t$ , т. е. выделяет память и возвращает указатель на этот участок памяти.

В случае, если newsize равен 0, ранее выделенная память будет освобождена, как если бы была вызвана функция free t, и возвращается нулевой указатель.

## Параметры:

- ptr Указатель на блок ранее выделенной памяти функциями malloc\_t , calloc\_t или realloc\_t для перемещения в новое место. Если этот параметр NULL, просто выделяется новый блок, и функция возвращает на него указатель.
- newsize Новый размер, в байтах, выделяемого блока памяти. Если newsize равно 0, ранее выделенная память освобождается и функция возвращает нулевой указатель, ptr устанавливается в 0.

Возвращаемое значение: Указатель на перераспределенный блок памяти, который может быть либо таким же, как аргумент ptr \*или ссылаться на новое место.

Тип данных возвращаемого значения всегда void\*, который может быть приведен к любому другому.

Если функции не удалось выделить требуемый блок памяти, возвращается нулевой указатель, и блок памяти, на который указывает аргумент ptr остается неизменным.

## Пример в коде:

```
/** @file memory_platform.h */

/**
 * @brief realloc_t - ptr to function whish reallocates memory block
 * Changes the size of the memory block pointed to by ptr. The function
 * may move the memory block to a new location (whose address is
 * returned by the function).
 *

 * @param ptr Pointer to a memory block previously allocated.
 * @param newsize New size for the memory block, in bytes.
 *

 * @return A pointer to the reallocated memory block, which may be either
 * the same as ptr or a new location.
 */
typedef void* (*realloc_t) (void *ptr, rfSize newsize);
```

# free t

**Прототип:** typedef void (\*free\_t)(void\* data);

Описание: Указатель на функцию free\_t освобождает место в памяти. Блок памяти, ранее выделенный с помощью вызова malloc\_t , calloc\_t или realloc\_t освобождается.

Обратите внимание, что эта функция оставляет значение data неизменным, следовательно, он по-прежнему указывает на тот же блок памяти, а не на нулевой указатель.

#### Параметры:

• data - Указатель на блок памяти, ранее выделенный функциями malloc\_t, calloc\_t или realloc\_t, которую необходимо высвободить. Если в качестве аргумента передается нулевой указатель, никаких действий не происходит.

Возвращаемое значение: Функция не имеет возвращаемое значение.

#### Пример в коде:

```
/** @file memory_platform.h */

/**
    * @brief Deallocates or frees a memory block.
    *
    * @param data Previously allocated memory block to be freed.
    */
typedef void (*free_t)(void* data);
```

### memset t

**Прототип:** typedef void\* (\*memset\_t)(void\* memptr, rflnt val, rfSize num);

Описание: Указатель на функцию  $memset_t$  заполняет num байтов блока памяти, через указатель memptr. Код заполняемого символа передаётся в функцию через параметр val.

#### Параметры:

- memptr Указатель на блок памяти для заполнения.
- val Передается целое число, но функция заполняет блок памяти символом, преобразуя это число в символ
- num Количество байт, которые необходимо заполнить указанным символом.

Возвращаемое значение: Функция возвращает указатель на блок памяти.

#### Пример в коде:

```
/** @file memory_platform.h */

/**

* @brief memset_t - ptr to function whish fills block of memory

* Sets the first num bytes of the block of memory pointed by ptr to the

* specified value (interpreted as an unsigned rfChar).

*

* @param memptr Pointer to the block of memory to fill.

* @param val Value to be set.

* @param num Number of bytes to be set to the value.

* rfSize is an unsigned rfIntegral type.
```

```
*
 * @return ptr is returned.
 */
typedef void* (*memset_t) (void* memptr, rfInt val, rfSize num);
```

#### memcpy t

**Прототип:** typedef void\* (\*memcpy\_t)(void\* destination, const void\* source, rfSize num);

Описание: Указатель на функцию memset\_t копирует num байтов первого блока памяти, на который ссылается указатель source, во второй блок памяти, на который ссылается указатель destination.

#### Параметры:

- destination Указатель на блок памяти назначения (куда будут копироваться байты данных).
- source Указатель на блок памяти источник (т. е., откуда будут копироваться байты данных).
- num Количество копируемых байтов.

Возвращаемое значение: Указатель на блок памяти назначения.

# Пример в коде:

```
/** @file memory_platform.h */

/**

* @brief memcpy_t - ptr to function whish copies block of memory

* Copies the values of num bytes from the location pointed to by source

* directly to the memory block pointed to by destination.

*

* @param destination Pointer to the destination array where the content is to

* be copied, type-casted to a pointer of type void*.

* @param source Pointer to the source of data to be copied, type-casted to a

* pointer of type const void*.

* @param num Number of bytes to copy. rfSize is an unsigned rfIntegral type.

*

* @return destination is returned.

*/

typedef void* (*memcpy_t) (void* destination, const void* source, rfSize num);
```

#### memcmp t

Прототип: typedef rfInt (\*memcmp\_t)(const void\* ptr1, const void\* ptr2, rfSize num );

Описание: Указатель на функцию memcmp\_t сравнивает первые num байтов блока памяти указателя ptr1 с первыми num байтами блока памяти ptr2. Возвращаемое значение 0 если блоки равны, и значение отличное от 0, если блоки не равны.

#### Параметры:

• ptr1 - Указатель на первый блок памяти.

- ptr2 Указатель на второй блок памяти.
- num Количество байтов для сравнения.

Возвращаемое значение: Возвращает значение, информирующее о результате сравнения содержимого блоков памяти. Нулевое значение указывает, что содержимое обоих блоков памяти равны. Значение больше нуля говорит о том, что первый блок памяти — ptr1 больше, чем блок памяти — ptr2, и значение меньше нуля свидетельствует об обратном

#### Пример в коде:

```
/** @file memory platform.h */
/**
* @brief memcmp_t - ptr to function whish compare two blocks of memory
* Compares the first num bytes of the block of memory pointed by ptr1 to the
* first num bytes pointed by ptr2, returning zero if they all match or a
* value different from zero representing which is greater if they do not.
* @param ptr1 Pointer to block of memory.
* @param ptr2 Pointer to block of memory.
* @param num Number of bytes to compare.
* @return
* 0 - if the contents of both memory blocks are equal,
\star <0 - if the first byte that does not match in both memory blocks has a
* lower value in ptr1 than in ptr2.
* > 0 - if the first byte that does not match in both memory blocks has a
* greater value in ptr1 than in ptr2.
typedef rfInt (*memcmp_t)(const void* ptr1, const void* ptr2, rfSize num);
```

#### hton long t, ntoh long t, hton short t, ntoh short t

#### Прототип:

- typedef rfUint32 (\*hton\_long\_t) (rfUint32 hostlong);
- typedef rfUint32 (\*ntoh long t) (rfUint32 netlong);
- typedef rfUint16 (\*hton short t)(rfUint16 hostshort);
- typedef rfUint16 (\*ntoh short t)(rfUint16 netshort);

Описание: Указатели на функции hton\_long\_t , ntoh\_long\_t , hton\_short\_t , ntoh\_short\_t необходимы для преобразования многобайтовых целочисленных типов из байтового порядка хоста в сетевой порядок байтов и наоборот.

#### Параметры:

- hostlong/hostshort 32/16-битное число в байтовом порядке хоста.
- netlong/netshort 32/16-битное число в сетевом порядке байтов.

Возвращаемое значение: Функция возвращает значение в сетевом/обратном порядке байтов.

# Пример в коде:

```
/** @file network_platform.h */
* @brief The hton_long_t function converts a u_long from host to network byte
* order (which is big-endian).
 * @param hostlong A 32-bit number in host byte order.
 * Greturn The function returns the value in network byte order.
typedef rfUint32 (*hton_long_t) (rfUint32 hostlong);
/**
* @brief The ntoh_long_t function converts a u_long from network order to
* host byte order (which is little-endian on rfIntel processors).
* @param netlong A 32-bit number in network byte order.
^{\star} @return: The function returns the value supplied in the netlong parameter
* with the byte order reversed.
typedef rfUint32 (*ntoh_long_t) (rfUint32 netlong);
/**
* @brief The hton_short_t function converts a u_short from host to network
 * byte order (which is big-endian).
* @param hostlong A 16-bit number in host byte order.
 * @return The modbusHtoN_short_t function returns the value in network
* byte order.
typedef rfUint16 (*hton_short_t) (rfUint16 hostshort);
/**
* @brief The ntoh_short_t function converts a u_short from network byte order
* to host byte order
 * @param netshort A 16-bit number in network byte order.
 * @return The function returns the value in host byte order.
typedef rfUint16 (*ntoh_short_t)(rfUint16 netshort);
```

# create\_udp\_socket\_t

Прототип: typedef void\* (\*create\_udp\_socket\_t)();

Описание: Указатель на функцию create\_udp\_socket\_t создает несвязанный UDP сокет

Возвращаемое значение: После успешного завершения create\_udp\_socket\_t должен вернуть указатель на дескриптор сокета. В противном случае должно быть возвращено значение NULL и вызвана ошибка создания сокета.

#### Пример в коде:

```
/** @file network_platform.h */
/**
  * @brief Pointer to UDP socket creation function
  *
  * @param af The address family specification.
  * @param type The type specification for the new socket.
  * @param protocol The protocol to be used.
  *
  * @return
  * - On success: A descriptor referencing the new socket
  * - On error: NULL
  */
typedef void* (*create_udp_socket_t)();
```

```
set_broadcast_socket_option_t,
set_socket_recv_timeout_t
```

set\_reuseaddr\_socket\_option\_t,

# Прототип:

- typedef rfInt8 (\*set\_broadcast\_socket\_option\_t)(void\* socket);
- typedef rfInt8 (\*set\_reuseaddr\_socket\_option\_t)(void\* socket);
- typedef rfInt8 (\*set\_socket\_recv\_timeout\_t)(void\* socket, rfInt32 msec);

Описание: Указатели на функции set\_broadcast\_socket\_option\_t , set\_reuseaddr\_socket\_option\_t , set\_socket\_recv\_timeout\_t , необходимы для вкючение в UDP сокетах таких сетевых настроек как: broadcast (позволяет отправлять или получать широковещательные пакеты), reuseaddr (позволяет сокету принудительно связываться с портом, используемым другим сокетом), recv\_timeout (время, в течение которого сокет ожидает, пока данные станут доступными для чтения).

#### Параметры:

- socket Указатель дескриптора сокета
- msec (только для set\_socket\_recv\_timeout\_t) Время ожидания в миллисекундах.

**Возвращаемое значение:** После успешного завершения везвращается 0. В противном случае должно быть возвращено значение -1.

#### Пример в коде:

```
/** @file network_platform.h */
/**
    * @brief Pointer to the function that sets a broadcast socket option.
    *
    * @param socket A descriptor that identifies a socket.
    *
    * @return
    * - On success: 0
    * - On error: -1
    */
typedef rfInt8 (*set_broadcast_socket_option_t) (void* socket);
```

## set\_socket\_option\_t

Прототип: typedef rfInt8 (\*set\_socket\_option\_t)(void\* socket, rfInt32 level, rfInt32 optname, const rfChar\* optval, rfInt32 optlen);

**Описание:** Указатель на функцию set\_socket\_option\_t устанавливает параметр сокета.

# Параметры:

- socket Указатель дескриптора сокета
- level Уровень, на котором определена опция (например, SOL SOCKET).
- optname Параметр сокета, для которого должно быть установлено значение (например, SO\_BROADCAST)
- optval Указатель на буфер, в котором указано значение запрошенной опции.
- optlen Размер в байтах буфера, на который указывает параметр optval

**Возвращаемое значение:** *Если ошибок не происходит,* set\_socket\_option\_t возвращает ноль. В противном случае возвращается значение RF\_SOCKET\_ERROR

#### Пример в коде:

```
/** @file network_platform.h */

/**
    * @brief Pointer to the function that sets a socket option.
    *
    * @param socket A descriptor that identifies a socket.
    * @param level The level at which the option is defined.
```

# socket\_connect\_t

Прототип: typedef rfInt8 (\*socket\_connect\_t)(void\* socket, rfUint32 dst\_ip\_addr, rfUint16 dst\_port);

Описание: Указатель на функцию socket\_connect\_t устанавливает соединение с указанным сокетом.

# Параметры:

- socket Указатель дескриптора сокета
- dst\_ip\_addr IP-адрес назначения, с которым должно быть установлено соединение.
- dst\_port Порт назначения, к которому должно быть установлено соединение.

**Возвращаемое значение:** *Если ошибок не происходит,* socket\_connect\_t *возвращает ноль. В противном случае возвращается значение* RF\_SOCKET\_ERROR

## Пример в коде:

#### socket bind t

Прототип: typedef rfInt (\*socket\_bind\_t)(void\* socket, rfUint32 host\_ip\_addr, rfUint16 host\_port);

Описание: Указатель на функцию socket bind t связывает локальный адрес с сокетом.

#### Параметры:

- socket Указатель дескриптора сокета
- dst\_ip\_addr IP-адрес, с которым должен быть связан сокет.
- dst\_port Порт, с которым должен быть связан сокет.

Возвращаемое значение: Если ошибок не происходит, socket bind t возвращает ноль. В противном случае возвращается значение RF\_SOCKET\_ERROR

#### Пример в коде:

```
/** @file network_platform.h */
* @brief Pointer to the function that associates a local address with
 * a socket.
 * @param socket A descriptor identifying an unconnected socket.
 * @param host_ip_addr Host IP Addr to which the connection should be bind.
 * @param host_port Host port to which the connection should be bind.
 * @return
 * - On success: 0
 \star - On error: -1
typedef rfInt (*socket_bind_t)(
        void* socket, rfUint32 host ip addr, rfUint16 host port);
```

#### socket listen t

**Прототип:** typedef rfInt8 (\*socket\_listen\_t)(void\* socket, rfInt32 backlog);

Описание: Указатель на функцию socket\_listen\_t переводит сокет в состояние, в котором он ожидает входящее соединения.

#### Параметры:

- socket Указатель дескриптора сокета
- backlog Максимальная длина очереди ожидающих подключений.

Возвращаемое значение: Если ошибок не происходит, socket\_listen\_t возвращает ноль. В противном случае возвращается значение RF\_SOCKET\_ERROR

#### Пример в коде:

```
/** @file network_platform.h */
/** @brief Pointer to the function that places a socket in a state in which
 * it is listening for an incoming connection.
                                                                 (continues on next page)
```

```
*
 * @param socket A descriptor identifying a bound, unconnected socket.
 * @param backlog The maximum length of the queue of pending connections.
 *
 * @return
 * - On success: 0
 * - On error: -1
 */
typedef rfInt8 (*socket_listen_t) (void* socket, rfInt32 backlog);
```

# socket\_accept\_t

Прототип: typedef void\* (\*socket\_accept\_t)(void\* socket, rfUint32\* srs\_ip\_addr, rfUint16\* srs\_port);

**Описание:** Указатель на функцию socket\_accept\_t разрешает попытку входящего подключения к сокету.

## Параметры:

- socket Указатель дескриптора сокета
- srs\_ip\_addr Указатель на IP-адрес входящего соединения.
- srs\_port Указатель на порт входящего соединения.

**Возвращаемое значение:** *Если ошибок не происходит,* socket\_accept\_t возвращает указатель на дескриптор принятого сокета. В противном случае возвращается нулевой указатель.

#### Пример в коде:

```
/** @file network_platform.h */
/**
    * @brief Pointer to the function that permits an incoming connection attempt
    * on a socket.
    *
    * @param socket A descriptor that identifies a socket that has been placed in
    * a listening state with the modbusSocketListen_t function.
    * The connection is actually made with the socket that is returned by accept.
    * @param srs_ip_addr Pointer to the IP address of the incoming connection.
    * @param srs_port Pointer to the port of the incoming connection.
    *
    * @return
    * On success: value is a handle for the socket
    * On error : NULL
    */
typedef void* (*socket_accept_t)(
        void* socket, rfUint32* srs_ip_addr, rfUint16* srs_port);
```

# close\_socket\_t

Прототип: typedef rfInt8 (\*close\_socket\_t)(void\* socket);

Описание: Указатель на функцию close\_socket\_t закрывает существующий сокет.

## Параметры:

• socket - Указатель дескриптора сокета

**Возвращаемое значение:** *Если ошибок не происходит,* close\_socket\_t *возвращает ноль.* В противном случае возвращается значение RF\_SOCKET\_ERROR

## Пример в коде:

```
/** @file network_platform.h */

/**
    * @brief Pointer to the function that closes an existing socket.
    *
    * @param socket A descriptor identifying the socket to close.
    *
    * @return
    * - On success: 0
    * - On error: -1
    */
typedef rfInt8 (*close_socket_t) (void* socket);
```

## send tcp data t

Прототип: typedef rflnt (\*send tcp data t)(void\* socket, const void \*buf, rfSize len);

Описание: Указатель на функцию send\_tcp\_data\_t отправляет данные в подключенный TCP сокет.

#### Параметры:

- socket Указатель дескриптора сокета
- buf Указатель на буфер, содержащий данные для передачи.
- len Длина в байтах данных в буфере, на который указывает параметр buf

Возвращаемое значение: Если ошибок не происходит, send\_tcp\_data\_t возвращает общее количество отправленных байтов, которое может быть меньше количества, запрошенного для отправки в параметре len . В противном случае возвращается значение -1.

#### Пример в коде:

```
*/
typedef rfInt (*send_tcp_data_t) (void* socket, const void *buf, rfSize len);
```

# send\_udp\_data\_t

Прототип: typedef rfInt (\*send\_udp\_data\_t)(void\* socket, const void \*data, rfSize len, rfUint32 dest\_ip\_addr, rfUint16 dest\_port);

**Описание:** Указатель на функцию send\_udp\_data\_t отправляет данные по UDP в определенное место назначения.

## Параметры:

- socket Указатель дескриптора сокета
- data Указатель на буфер, содержащий данные для передачи.
- len Длина в байтах данных в буфере, на который указывает параметр data
- dest\_ip\_addr IP-адрес, на который данные должны быть отправлены.
- dest port Порт, на который данные должны быть отправлены.

Возвращаемое значение: Если ошибок не происходит, send\_udp\_data\_t возвращает общее количество отправленных байтов, которое может быть меньше количества, запрошенного для отправки в параметре len . В противном случае возвращается значение -1.

#### Пример в коде:

```
/** @file network_platform.h */
/**
* @brief Pointer to the send function that sends data on a UDP socket
* @param socket A descriptor identifying a socket.
* @param buf A pointer to a buffer containing the message to be sent.
* @param len The size of the message in bytes.
* @param dest_addr Points to a sockaddr_in structure containing the
* destination address.
* @param addrlen Specifies the length of the sockaddr_in structure pointed
* to by the dest_addr argument.
* @return
* - On success: the total number of bytes sent, which can be less than
* the number requested to be sent in the len parameter
\star - On error: -1
* /
typedef rfInt (*send_udp_data_t)(
       void* socket, const void *data, rfSize len,
       rfUint32 dest_ip_addr, rfUint16 dest_port);
```

#### recv\_data\_from\_t

Прототип: typedef rflnt (\*recv\_data\_from\_t)(void\* socket, void \*buf, rfSize len, rfUint32\* srs\_ip\_addr, rfUint16\* srs\_port);

Описание: Указатель на функцию recv\_data\_from\_t получает данные из сокета и адрес отправителя.

## Параметры:

- socket Указатель дескриптора сокета
- buf Указатель на буфер для приема входящих данных
- len Длина в байтах буфера, на который указывает параметр buf
- srs ip addr Указатель на IP-адрес из которого были получены данные
- srs\_port Указатель на порт из которого были получены данные

Возвращаемое значение: Если ошибок не происходит, recv\_data\_from\_t возвращает общее количество принятых байтов. В противном случае возвращается значение -1.

## Пример в коде:

```
/** @file network platform.h */
* @brief Pointer to the function that receive message from socket and capture
* address of sender.
* @param socket Specifies a socket descriptor from which data should
* be received.
 * @param buf Specifies the buffer in which to place the message.
* @param len Specifies the length of the buffer area.
* @param srs_ip_addr Pointer to the IP address from which the data
* @param srs_port Pointer to the port from which the data was received.
 * @return
 * - On success: the number of bytes received
 * - On error: -1
*/
typedef rfInt (*recv_data_from_t)(
       void* socket, void *buf, rfSize len,
       rfUint32* srs_ip_addr, rfUint16* srs_port);
```

# recv\_data\_t

Прототип: typedef rfInt (\*recv\_data\_t)(void\* socket, void \*buf, rfSize len);

**Описание:** Указатель на функцию recv\_data\_t получает данные от подключенного сокета или привязанного сокета без установления соединения.

#### Параметры:

- socket Указатель дескриптора сокета
- buf Указатель на буфер для приема входящих данных
- len Длина в байтах буфера, на который указывает параметр buf

**Возвращаемое значение:** *Если ошибок не происходит,* recv\_data\_t возвращает общее количество принятых байтов. В противном случае возвращается значение -1.

#### Пример в коде:

```
/** @file network_platform.h */
/**
    * @brief Pointer to the function that receive message from socket and capture
    * address of sender.
    *
    * @param sockfd Specifies a socket descriptor from which data
    * should be received.
    * @param buf Specifies the buffer in which to place the message.
    * @param len Specifies the length of the buffer area.
    *
    * @return
    * - On success: the number of bytes received
    * - On error: -1
    */
typedef rfInt (*recv_data_t) (void* socket, void *buf, rfSize len);
```

## trace\_info\_t, trace\_warning\_t, trace\_error\_t

# Прототип:

- typedef rfInt(\*trace info t)(const rfChar\* msg, ...);
- typedef rfInt(\*trace\_warning\_t)(const rfChar\* msg, ...);
- typedef rfInt(\*trace\_error\_t)(const rfChar\* msg, ...);

Описание: Указатели на функции trace\_info\_t, trace\_warning\_t u trace\_error\_t , необходимы для вывода как информационных сообщений, так и сообщений о предупреждениях и ошибках.

## Параметры:

- msg Указатель на строку, содержащую текст для вывода
- . . . (дополнительные аргументы) В зависимости от формата строки, функция может ожидать последовательность дополнительных аргументов.

**Возвращаемое значение:** В случае успеха возвращается общее количество написанных символов

#### Пример в коде:

```
/** @file iostream_platform.h */
/**

* @brief Method for outputting debugging information

*

* @param msg Pointer to a string containing the text to be output

* @param ...(additional arguments) Depending on the format string,

* the function may expect a sequence of additional arguments

*

* @return On success, the total number of characters written is returned.

*/

typedef rfInt(*trace_info_t)(const rfChar* msg, ...);

/**
```

```
* @brief Method for outputting alert information
*
* @param msg Pointer to a string containing the text to be output
* @param ... (additional arguments) Depending on the format string,
* the function may expect a sequence of additional arguments

*
* @return On success, the total number of characters written is returned.
*/
typedef rfInt(*trace_warning_t)(const rfChar* msg, ...);

/**

* @brief Method for outputting error information

*

* @param msg Pointer to a string containing the text to be output
* @param ... (additional arguments) Depending on the format string,
* the function may expect a sequence of additional arguments

*
* @return On success, the total number of characters written is returned.
*/
typedef rfInt(*trace_error_t)(const rfChar* msg, ...);
```

# Запуск «ядра»

После реализации всех платформозависимых функций разработчику необходимо проинициализировать следующие структуры iostream\_platform\_dependent\_methods\_t, memory\_platform\_dependent\_methods\_t и network\_platform\_dependent\_methods\_t

## Пример в коде:

```
/** @file iostream_platform.h */
/**
* @brief Structure with user-provided iostream platform-specific methods
* /
typedef struct
  trace info t trace info;
  trace_warning_t trace_warning;
  trace_error_t trace_error;
}iostream_platform_dependent_methods_t;
extern iostream_platform_dependent_methods_t iostream_platform;
/** @file memory_platform.h */
* @brief Structure with user-provided memory platform-specific methods
* /
typedef struct
  calloc_t rf_calloc;
  malloc_t rf_malloc;
  realloc_t rf_realloc;
  free_t rf_free;
```

```
memset_t rf_memset;
  memcpy_t rf_memcpy;
  memcmp_t rf_memcmp;
}memory_platform_dependent_methods_t;
extern memory_platform_dependent_methods_t memory_platform;
  /** @file memory_platform.h */
 * @brief Structure with user-provided network platform-specific methods
typedef struct
  hton long t hton long;
  ntoh_long_t ntoh_long;
  hton_short_t hton_short;
  ntoh_short_t ntoh_short;
  create_udp_socket_t create_udp_socket;
  set_broadcast_socket_option_t set_broadcast_socket_option;
  set_reuseaddr_socket_option_t set_reuseaddr_socket_option;
  set_socket_option_t set_socket_option;
  set_socket_recv_timeout_t set_socket_recv_timeout;
  socket_connect_t socket_connect;
  socket_bind_t socket_bind;
  socket_listen_t socket_listen;
  socket_accept_t socket_accept;
  close_socket_t close_socket;
  send_tcp_data_t send_tcp_data;
  send_udp_data_t send_udp_data;
  recv data from t recv data from;
  recv_data_t recv_data;
}network_platform_dependent_methods_t;
typedef struct
  rfUint32 host_ip_addr;
  rfUint32 host_mask;
}network_platform_dependent_settings_t;
typedef struct
  network platform dependent methods t network methods;
  network_platform_dependent_settings_t network_settings;
}network_platform_t;
extern network_platform_t network_platform;
```

Инициализация данных структур производится путем присваивания указателей на реализованные платформозависимые функции, а адреса проинициализированных экземпляров структур передаются в метод init\_platform\_dependent\_methods для инициализации кросс-платформенной части «ядра».

## Пример в коде:

# 3.2 Компиляция «обёртки» на С

Данная библиотека позволяет упростить разработку приложений на языке СИ.

Для её использования в проектах СИ разработчик должен включить необходимые h-файлы библиотеки в свой проект и собрать статическую или динамическую программную библиотеку.

# 3.2.1 Как скомпилировать

Библиотека-«обёртка» может быть скомпилирован при помощи консоли или среды разработки (Visual Studio, Qt Creator).

Для начала необходимо скачать проект SDK.

**Примечание:** Для получения дополнительной информации о шагах загрузки проекта см. *Скачивание проекта* 

## **CMake**

Находясь в папке проекта **RF62X-SDK**, для построения библиотеки-«обёртки» на СИ введите следующую команду в консоль (терминал):

```
mkdir build && cd build cmake .. -D_WRAPPER_LANGUAGE:STRING=C -D_SUBMODULE_CACHE_OVERWRITE=OFF cmake --build .
```

#### **Qt Creator**

Для построения библиотеки-«обёртки» с использованием IDE Qt Creator:

- Загрузите файл CMakeLists.txt из папки **RF62X-SDK** через **File > Open File or Project** (выберите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Измените параметр WRAPPER\_LANGUAGE (язык компилируемой обертки) в файле CMakeLists.txt проекта на C (SET(\${PARENT}\_WRAPPER\_LANGUAGE "C" CACHE STRING "" \${REWRITE\_FORCE}))
- Скомпилируйте проект

#### **Visual Studio**

Находясь в папке проекта **RF62X-SDK**, для построения библиотеки-«обёртки» на СИ введите следующую команду в консоль (терминал):

```
mkdir build && cd build cmake .. -D_WRAPPER_LANGUAGE:STRING=C -D_SUBMODULE_CACHE_OVERWRITE=OFF
```

- Откройте полученное решение RF62X-SDK.sln в Visual Studio
- Скомпилируйте проект

#### 3.2.2 Как использовать

Вы можете **создать свой проект**, включив в него статическую или динамическую библиотеку и необходимые заголовочные файлы (см. *Создание проекта С/С++*), или **открыть и скомпилировать** один из имеющихся в СДК примеров (см. *Запуск примеров на С/С++*).

**Примечание:** Для получения дополнительной информации по каждой функции «обёртки» СИ см. *Интерфейс «обёртки» на С* 

# 3.3 Компиляция «обёртки» на C++

Данная библиотека позволяет упростить разработку приложений на языке С++.

Для её использования в проектах C++ разработчик должен включить необходимые h-файлы библиотеки в свой проект и собрать статическую или динамическую программную библиотеку.

#### 3.3.1 Как скомпилировать

Библиотека-«обёртка» RF62X-SDK может быть скомпилирован при помощи консоли или среды разработки (Visual Studio, Qt Creator).

Для начала необходимо скачать проект SDK.

**Примечание:** Для получения дополнительной информации о шагах загрузки проекта см. *Скачивание проекта* 

#### **CMake**

Находясь в папке проекта **RF62X-SDK**, для построения библиотеки-«обёртки» на C++ введите следующую команду в консоль (терминал):

```
mkdir build && cd build cmake .. -D_WRAPPER_LANGUAGE:STRING=C++ -D_SUBMODULE_CACHE_OVERWRITE=OFF cmake --build .
```

#### **Qt Creator**

Для построения библиотеки-«обёртки» с использованием IDE Qt Creator:

- Загрузите файл CMakeLists.txt из папки **RF62X-SDK** через **File > Open File or Project** (выберите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Измените параметр WRAPPER\_LANGUAGE (язык компилируемой обертки) в файле CMakeLists.txt проекта на C++ (SET(\${PARENT}\_WRAPPER\_LANGUAGE "C++" CACHE STRING "" \${REWRITE\_FORCE}))
- Скомпилируйте проект

## **Visual Studio**

Находясь в папке проекта **RF62X-SDK**, для построения библиотеки-«обёртки» на C++ введите следующую команду в консоль (терминал):

```
mkdir build && cd build cmake .. -D_WRAPPER_LANGUAGE:STRING=C++ -D_SUBMODULE_CACHE_OVERWRITE=OFF
```

- Откройте полученное решение RF62X-SDK.sln в Visual Studio
- Скомпилируйте проект

#### 3.3.2 Как использовать

Вы можете **создать свой проект**, включив в него статическую или динамическую библиотеку и необходимые заголовочные файлы (см. *Создание проекта С/С++*), или **открыть и скомпилировать** один из имеющихся в СДК примеров (см. *Запуск примеров на С/С++*).

**Примечание:** Для получения дополнительной информации по каждому методу «обёртки» С++ см. *Интерфейс «обёртки» на С*++

# 3.4 Компиляция «обёртки» на С#

Данная «обёртка» представляет собой библиотеку .NET, написанную на языке С#, которая может быть использована в приложении на любом языке программирования, поддерживающем платформу .NET Framework (C#, Visual Basic, C++/CLI и др.)

Для её использования в проектах .NET разработчик должен собрать или скачать динамическую программную библиотеку RF62X-SDK для .NET и добавить её в проект, а также скачать дополнительные зависимости в каталог к исполняемому файлу проекта.

**Примечание:** Архив библиотек для C# можно скачать по ссылке: последние выпуски RF62X-SDK библиотек

# 3.4.1 Как скомпилировать

Библиотека-«обёртка» может быть скомпилирована при помощи среды разработки Visual Studio.

Для начала необходимо скачать проект SDK.

**Примечание:** Для получения дополнительной информации о шагах загрузки проекта см. *Скачивание проекта* 

#### **Visual Studio**

- Откройте в Visual Studio решение RF62X-SDK.sln (папка RF62X-SDK/RF62X-Wrappers/CSharp)
- Скомпилируйте проект

## 3.4.2 Как использовать

Вы можете **создать свой проект**, включив в него динамическую библиотеку-«обёртку» (см. *Создание проекта С#*), или **открыть и скомпилировать** один из имеющихся в СДК примеров (см. *Запуск примеров на С#*).

**Примечание:** Для получения дополнительной информации по каждому методу «обёртки» .NET см. *Интерфейс «обёртки» на С#* 

Описания АРІ

# 4.1 Интерфейс «обёртки» на С

Данная библиотека позволяет упростить разработку приложений на языке СИ.

Для её использования в проектах СИ разработчику необходимо включить h-файлы библиотеки в свой проект, а также добавить к проекту «обёртку» в качестве статической или динамической программной библиотеки.

Для скачивания библиотеки см. Последние выпуски RF62X-SDK библиотек. Для компиляции библиотеки из исходников см. *Компиляция «обёртки» на СИ*. Для использования в проектах см. *Создание проекта C/C++*.

#### 4.1.1 Инициализация SDK

Файл rf62Xcore.h необходим для вызова функции инициализации SDK: core\_init()

Файл rf62X\_sdk.h является основным файлом программного интерфейса (API) для разработки программ на языке СИ и определяет функциональность библиотеки-«обёртки».

Файл rf62x\_types.h содержит основные структуры и типы, используемые в SDK.

# core\_init

Прототип: int8\_t core\_init();

Описание: Функция инициализации SDK. Должна быть вызвана один раз перед дальнейшими вызовами любых библиотечных функций

**Возвращаемое значение:** После успешного завершения возвращается 1 (TRUE). В противном случае должен быть возвращен код ошибки.

Пример в коде:

```
/** @file rf62Xcore.h */
* @brief core_init - Initialize sdk library
* @details Must be called once before further calls to any
* library functions
^{\star} @return 1 if success or error code.
int8_t core_init();
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Initialize sdk library
uint8_t is_init = core_init();
  if (is_init == 1)
     printf("SDK version: %s\n", sdk_version());
  else
     printf("SDK initialization error: %s\n", is_init);
     return -1;
  }
  // some code...
```

# core\_cleanup

**Прототип:** void core\_cleanup();

**Описание:** Функция высвобождает ресурсы, выделенные с помощью функции  $core\_init$ 

# Пример в коде:

```
/** @file rf62Xcore.h */
/**
    * @brief core_cleanup - Cleanup resources allocated
    * with core_init() function
    */
void core_cleanup();
```

```
/** @file main.c */
#include <stdio.h>
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"

int main()
{
    // Initialize sdk library
    core_init();
    // some code...
    // Cleanup resources
    core_cleanup();
}
```

# sdk\_version

Прототип: char\* sdk\_version();

Описание: Функция получения информации о версии SDK

## Пример в коде:

```
/** @file rf62Xcore.h */
/**
* @brief sdk_version - Return info about SDK version
* @return SDK version
char* sdk_version();
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Initialize sdk library
  core_init();
   // Print return rf627 sdk version
  printf("SDK version: %s\n", sdk_version());
```

```
// Cleanup resources
core_cleanup();
}
```

# 4.1.2 Интерфейс работы со сканерами серии RF627 v20.x.x.x

Файлы rf62X\_sdk.h, rf62X\_types.h и rf62Xcore.h предоставляют весь необходимый интерфейс для работы со сканерами серии RF627 v20.x.x.x

# search\_scanners

Прототип: rfUint8 search\_scanners(vector\_t \*list, scanner\_types\_t type, rfUint32 timeout, protocol\_types\_t protocol);

Описание: Функция поиска устройств RF62X v20.x.x.x в сети

## Параметры:

- list Указатель на список, который будет заполнен найденными сканерами в сети.
- type Тип сканера для поиска (kRF627\_OLD, kRF627\_SMART).
- timeout Время поиска на каждом Ethernet интерфейсе (мс).
- protocol Тип протокола, по которому будет осуществляться поиск (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file rf62X_sdk.h */
/**
    * @brief search_scanners - Search for RF62X devices over network
    *
    * @param[out] list Ptr to list of rf627 objects. If not null list will be
    * filled with found devices
    * @param[in] type Scanner's type (RF627-old, RF627-smart)
    * @param[in] timeout Time to search
    * @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
    *
    * @return TRUE on success
    */
    rfUint8 search_scanners(
        vector_t *list, scanner_types_t type,
        rfUint32 timeout, protocol_types_t protocol);

/** @file main.c */

#include <stdio.h>
#include <stdib.h>
```

```
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Initialize sdk library
  core_init();
  // Create value for scanners vector's type
  vector_t* scanners = (vector_t*)calloc(1, sizeof (vector_t));
  // Initialization vector
  vector init(&scanners);
  // Iterate over all available network adapters in the current operating
  // system to send "Hello" requests.
  uint32_t count = 0;
  for (int i=0; i<GetAdaptersCount(); i++)</pre>
     uint32_t host_ip_addr = ntohl(inet_addr(GetAdapterAddress(i)));
     uint32_t host_mask = ntohl(inet_addr(GetAdapterMasks(i)));
      // call the function to change adapter settings inside the library.
     set_platform_adapter_settings(host_mask, host_ip_addr);
      // Search for rf627old devices over network by Service Protocol.
     if (host_ip_addr != 0)
         // Get another IP Addr and set this changes in adapter settings.
        printf("Search scanners from:\n "
               "* IP Address\t: %s\n "
              "* Netmask\t: %s\n",
              GetAdapterAddress(i), GetAdapterMasks(i));
         search_scanners(scanners, kRF627_OLD, 300, kSERVICE);
        // Print count of discovered rf627old in network
        printf("Discovered\t: %d RF627\n", (int) vector_count (scanners) -count);
        printf("----\n");
        count = (int)vector_count(scanners);
      }
   }
  // Print count of discovered rf627old in network
  printf("Was found\t: %d RF627 v20.x.x.x", (int)vector count(scanners));
   // some code...
```

#### get\_info\_about\_scanner

**Прототип:** hello\_information get\_info\_about\_scanner(scanner\_base\_t \*device, protocol\_types\_t protocol):

**Описание:** Функция получения информации о сканере из пакета приветствия (Helloпакет)

# Параметры:

- device Указатель на сканер
- protocol Тип протокола, по которому был получен пакет приветствия (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: hello\_information в случае успеха, иначе ошибка

#### Пример в коде:

```
/** @file rf62X sdk.h */
/**
* @brief get_info_about_scanner - Get information about scanner from
 * hello packet
* @param[in] device Ptr to scanner
* @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return hello_information on success
hello_information get_info_about_scanner(
      scanner_base_t *device, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search scanners(scanners, kRF627 OLD, timeout, kSERVICE);
   // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
   for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      hello_information result =
              get_info_about_scanner(vector_get(scanners,i), kSERVICE);
      rf627_smart_hello_info_by_service_protocol* info =
              result.rf627smart.hello_info_service_protocol;
      printf("\n\nID scanner's list: %d\n", i);
      printf("-----
```

```
printf("Device information: \n");
  printf("* Name\t: %s\n", info->user_general_deviceName);
  printf("* Serial\t: %d\n", info->fact_general_serial);
  printf("* IP Addr\t: %s\n", info->user_network_ip);
  printf("* MAC Addr\t: %s\n", info->fact_network_macAddr);
  printf("\nWorking ranges: \n");
  printf("* Zsmr, mm\t: %d\n", info->fact_general_smr);
  printf("* Zmr , mm\t: %d\n", info->fact_general_mr);
  printf("* Xsmr, mm\t: %d\n", info->fact_general_xsmr);
  printf("* Xemr, mm\t: %d\n", info->fact_general_xemr);
  printf("\nVersions: \n");
  printf("* Firmware\t: %d.%d.%d\n",
         info->fact_general_firmwareVer[0],
         info->fact general firmwareVer[1],
         info->fact general firmwareVer[2]);
  printf("* Hardware\t: %d\n", info->fact_general_hardwareVer);
  printf("-----
// some code...
```

## free\_scanner

**Прототип:** void free scanner(scanner base t \*device);

Описание: Функция очистки памяти, используемой объектом типа scanner base t

## Параметры:

• device - Указатель на сканер

#### Пример в коде:

```
int main()
{
    // Actions before search (see example of search_scanners() method)...

    // Search for RF627-old devices over network by Service Protocol.
    search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);

    // Print count of discovered rf627old in network by Service Protocol
    printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));

    while (vector_count(scanners) > 0)
    {
        uint32_t index = vector_count(scanners)-1;
        // Get last scanner in vector for delete
        scanner_base_t* device = vector_get(scanners, index);

        // Cleanup resources allocated by device
        free_scanner(device);

        // Delete from vector
        vector_delete(scanners, index);
    }
}
```

## connect\_to\_scanner

Прототип: rfUint8 connect\_to\_scanner(scanner\_base\_t \*device, protocol\_types\_t protocol);

Описание: Функция установки соединения со сканером

#### Параметры:

- device Указатель на сканер
- protocol Тип протокола, по которому будет выполнено подключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search scanners(scanners, kRF627 OLD, timeout, kSERVICE);
  // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection to the RF627 device by Service Protocol.
      uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
      if (!isConnected) {
         printf("Failed to connect to scanner!");
         continue;
      }
      // some actions with scanner...
   }
```

# disconnect\_from\_scanner

Прототип: rfUint8 disconnect\_from\_scanner(scanner\_base\_t \*device, protocol\_types\_t protocol);

Описание: Функция закрытия ранее установленного соединения со сканером

#### Параметры:

- device Указатель на сканер
- protocol Тип протокола, по которому будет выполнено отключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file rf62X_sdk.h */

/**

* @brief disconnect_from_scanner - Close connection to the device
```

```
* @param[in] device Prt to scanner
 * @param[in] protocol Protocol's type (Service, ENIP, Modbus-TCP)
 * @return TRUE on success
*/
rfUint8 disconnect_from_scanner(
      scanner_base_t *device, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
   // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
  // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection to the RF627 device by Service Protocol.
      uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
      if (!isConnected) {
         printf("Failed to connect to scanner!");
         continue;
      }
      // some actions with scanner...
      // Disconnect from scanner.
     disconnect_from_scanner(scanner, kSERVICE)
  }
```

## check connection to scanner

Прототип: check\_connection\_to\_scanner(scanner\_base\_t \*device, rfUint32 timeout, protocol\_types\_t protocol);

**Описание:** Функция проверки доступности сканера в сети (после подключения к нему) **Параметры:** 

- device Указатель на сканер
- timeout Время проверки соединения со сканером (мс).
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file rf62X sdk.h */
/**
* @brief check_connection_to_scanner - Check connection to the RF62X device
* @param[in] device Ptr to scanner
* @param[in] timeout Time to check connection
* @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return TRUE on success
* /
rfUint8 check connection to scanner(
      scanner_base_t *device, rfUint32 timeout, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search scanners (scanners, kRF627 OLD, timeout, kSERVICE);
  // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection to the RF627 device by Service Protocol.
      uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
      if (!isConnected) {
         printf("Failed to connect to scanner!");
         continue;
      }
      // Check connection to the RF627 device.
      uint8_t is_available =
```

```
check_connection_to_scanner(scanner, 300, kSERVICE);
if (!is_available) {
    printf("Scanner is not available now!");
    continue;
}

// some actions with scanner...
}
```

# get\_profile2D\_from\_scanner

Прототип: rf627\_profile2D\_t\* get\_profile2D\_from\_scanner(scanner\_base\_t \*device, rfBool zero\_points, rfBool realtime, protocol\_types\_t protocol);

Описание: Функция получения результатов измерений

## Параметры:

- device Указатель на сканер
- zero\_points Включать нулевые точки в возвращаемом профиле.
- realtime Получение профиля в реальном времени (буферизация отключена).
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Bозвращаемое значение: Указатель на rf627\_profile2D\_t при успехе, иначе - NULL

#### Пример в коде:

```
/** @file rf62X_sdk.h */
 * @brief get_profile2D_from_scanner - Get measurement from scanner's
 * data stream
 * @param[in] device - ptr to scanner
 * @param[in] zero_points Enable zero points in return profile2D
 * @param[in] realtime Enable getting profile in realtime (buffering disabled)
* @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return ptr to rf627_profile_t structure
*/
rf627_profile2D_t* get_profile2D_from_scanner(
      scanner_base_t *device, rfBool zero_points,
      rfBool realtime, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
```

```
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
  // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
     scanner_base_t* scanner = vector_get(scanners,i);
     connect_to_scanner(scanner, kSERVICE);
     uint8_t zero_points = TRUE;
     uint8_t realtime = TRUE;
     // Get profile from scanner's data stream by Service Protocol.
     rf627_profile2D_t* result = get_profile2D_from_scanner(
           scanner, zero_points, realtime, kSERVICE);
     rf627_smart_profile2D_t* profile2D = result->rf627old_profile2D;
      if (profile2D != NULL) {
        printf("Profile was successfully received!");
         // some actions with profile...
        free_profile2D(result);
      }else
        printf("Profile was not received!");
  }
```

#### free profile2D

Прототип: void free profile2D(rf627 profile2D t\* profile);

Описание: Функция очистки ресурсов, выделенных для rf627\_profile2D\_t

#### Параметры:

• profile - Указатель на профиль

#### Пример в коде:

```
/** @file rf62X_sdk.h */
/**
    * @brief free_profile2D - Cleanup resources allocated for profile2D
    *
    * @param[in] profile Ptr to rf627_profile2D_t
    */
void free_profile2D(rf627_profile2D_t* profile);
```

```
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
   // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
   for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      connect_to_scanner(scanner, kSERVICE);
      uint8_t zero_points = TRUE;
      uint8 t realtime = TRUE;
      // Get profile from scanner's data stream by Service Protocol.
      rf627_profile2D_t* result = get_profile2D_from_scanner(
            scanner, zero_points, realtime, kSERVICE);
      rf627_smart_profile2D_t* profile2D = result->rf627old_profile2D;
      if (profile2D != NULL) {
         printf("Profile was successfully received!");
         // some actions with profile...
         free_profile2D(result);
      }else
         printf("Profile was not received!");
   }
```

## read\_params\_from\_scanner

Прототип: rfUint8 read\_params\_from\_scanner(scanner\_base\_t \*device, uint32\_t timeout, protocol\_types\_t protocol);

**Описание:** Функция получения текущих параметров сканера. При вызове данной функции SDK вычитывает со сканера все актуальные параметры, сохраняя их ввиде «списка параметров» для дальнейшей работы во внутренней памяти SDK.

## Параметры:

- device Указатель на сканер
- timeout Время получения списка параметров со сканера.
- protocol Тип протокола, по которому будет выполнена проверка (Service

## Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

## Пример в коде:

```
/** @file rf62X sdk.h */
/**
* @brief read_params_from_scanner - Read parameters from device to
* Internal structure.
 * @param device Ptr to scanner
 * @param timeout Time to read parameters
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return TRUE on success
 * /
rfUint8 read_params_from_scanner(
      scanner_base_t *device, rfUint32 timeout, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
  // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      connect_to_scanner(scanner, kSERVICE);
     uint8 t is read = read params from scanner(scanner, 300, kSERVICE);
      if (is read) {
         printf("Scanner parameters were read successfully!");
         // some actions with params...
      }else
         printf("Scanner parameters were not read!");
  }
```

#### get parameter

**Прототип**: parameter\_t\* get\_parameter(scanner\_base\_t \*device, const rfChar\* param\_name);

Описание: Функция получения конкретного параметра по его имени (ключу). При вызове данной функции SDK осуществляет поиск нужного параметра из последних прочитанных при вызове функции read\_params\_from\_scanner . В случае, если запрашиваемый параметр отсутствует в конкретном сканере, функция вернёт NULL.

## Параметры:

- device Указатель на сканер
- param\_name Имя (ключ) параметра.

Возвращаемое значение: parameter\_t\* при успехе, иначе - NULL

#### Пример в коде:

```
/** @file rf62X sdk.h */
* @brief get_parameter - Search parameters by his name
 * @param device - ptr to scanner
* @param param_name - name of parameter
 * @return param on success, else - null
parameter_t* get_parameter(
      scanner_base_t *device, const rfChar* param_name);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X_types.h"
int main()
   // Actions before search (see example of search_scanners() method)...
   // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
  // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
```

```
// Establish connection.
  connect_to_scanner(scanner, kSERVICE);
   // Read params.
  read_params_from_scanner(scanner, 300, kSERVICE);
  // Get parameter of Device Name
  parameter_t* name = get_parameter(scanner, "user_general_deviceName");
  if (name != NULL) {
     char* value = name->val_str->value;
     printf("Current Device Name\t: %s\n", value);
  // Get parameter of Sensor Framerate
  parameter_t* framerate = get_parameter(scanner, "user_sensor_framerate");
  if (framerate != NULL) {
     uint32 t value = framerate->val uint32->value;
     printf("Current FPS\t\t: %d\n", value);
  // some actions with other parameters...
}
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

## set\_parameter

Прототип: rfUint8 set parameter(scanner base t \*device, parameter t\* param)

Описание: Функция установки конкретного параметра. При вызове данной функции происходит установка параметра в списке параметров во внутренней памяти SDK.\* Для отправки изменений в сканер необходимо вызвать метод write\_params\_to\_scanner.

# Параметры:

- device Указатель на сканер.
- рагат Указатель на параметр для установки.

Возвращаемое значение: TRUE при успехе, иначе - FALSE

# Пример в коде:

```
/** @file rf62X_sdk.h */
/**
   * @brief set_parameter - Set parameter
   *
   * @param device Ptr to scanner
   * @param param Parameter name
   *
```

```
* @return TRUE on success
*/
rfUint8 set_parameter(
      scanner_base_t *device, parameter_t* param);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X types.h"
int main()
   // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
   // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
   for (int i = 0; i < (int)vector count(scanners); i++)</pre>
     scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection.
     connect_to_scanner(scanner, kSERVICE);
      // Read params.
     read_params_from_scanner(scanner, 300, kSERVICE);
      // Example of working with the parameter type:
     // uint32_t
      //
      // Get parameter of Laser Enabled
     parameter_t* laser = get_parameter(scanner, "user_laser_enabled");
      if (laser != NULL)
        uint32 t is enabled = laser->val uint32->value;
        printf("Current Laser State\t: %s\n", (is enabled? "ON":"OFF"));
         // Change the current state to the opposite
         is_enabled = !is_enabled;
         laser_enabled->val_uint32->value = is_enabled;
         printf("New Laser State\t: %s\n", (is_enabled? "ON":"OFF"));
         printf("----\n");
        set_parameter(scanner, laser_enabled);
      }
```

```
// some actions with other parameters before applying changes...
}
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

# write\_params\_to\_scanner

Прототип: rfUint8 write\_params\_to\_scanner(scanner\_base\_t \*device, rfUint32 timeout, protocol\_types\_t protocol)

Описание: Функция передачи параметров из внутренней памяти SDK в сканер. При вызове данной функции происходит отправка изменённых параметров в сканер

## Параметры:

- device Указатель на сканер.
- timeout Время отправки изменённых параметров в сканер.
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file rf62X_sdk.h */
/**
* @brief write_params_to_scanner - Send current parameters to device
 * @param device Ptr to scanner
 * @param timeout Time to send parameters
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return TRUE on success
rfUint8 write_params_to_scanner(
      scanner base t *device, rfUint32 timeout, protocol types t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
```

```
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
  // Print count of discovered rf627old in network by Service Protocol
  printf("Discovered: %d rf627-old\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
     scanner_base_t* scanner = vector_get(scanners,i);
     // Establish connection.
     connect to scanner(scanner, kSERVICE);
     // Read params.
     read_params_from_scanner(scanner, 300, kSERVICE);
     // Example of working with the parameter type:
     // uint32_t
     //
     // Get parameter of Laser Enabled
     parameter_t* laser = get_parameter(scanner, "user_laser_enabled");
     if (laser != NULL)
        uint32_t is_enabled = laser->val_uint32->value;
        printf("Current Laser State\t: %s\n", (is_enabled? "ON":"OFF"));
        // Change the current state to the opposite
        is_enabled = !is_enabled;
        laser_enabled->val_uint32->value = is_enabled;
        printf("New Laser State\t: %s\n", (is_enabled? "ON":"OFF"));
        printf("----\n");
        set_parameter(scanner, laser_enabled);
     }
     // some actions with other parameters before applying changes...
     // Apply changed parameters to the device
     uint8_t is_applied = write_params_to_scanner(scanner, 300, kSERVICE);
     if (is_applied)
        printf("Scanner parameters were applied successfully!");
     else
        printf("Scanner parameters were not applied!");
  }
```

# save\_params\_to\_scanner

Прототип: rfUint8 save\_params\_to\_scanner(scanner\_base\_t \*device, rfUint32 timeout, protocol\_types\_t protocol);

**Описание:** Функция сохранения параметров сканера во внутреннюю память устройства. Сохраненные параметры также будут использоваться после перезапуске устройства или после смены(обновления) прошивки.

## Параметры:

- device Указатель на сканер.
- timeout Время ожидания результата сохранения параметров в сканере.
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

## Пример в коде:

```
/** @file rf62X sdk.h */
/**
* @brief save_params_to_scanner - Save changes to device's memory
* @param device Ptr to scanner
* @param timeout Time to save parameters
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return TRUE on success
rfUint8 save_params_to_scanner(
      scanner_base_t *device, rfUint32 timeout, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-old devices over network by Service Protocol.
  search_scanners(scanners, kRF627_OLD, timeout, kSERVICE);
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
   {
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection.
      connect_to_scanner(scanner, kSERVICE);
      // Read params.
      read_params_from_scanner(scanner, 300, kSERVICE);
```

```
// After changing some parameters...

// Apply changed parameters to the device
write_params_to_scanner(scanner, 300, kSERVICE);

// Save current parameters in the device memory
uint8_t is_saved = save_params_to_scanner(scanner, 300, kSERVICE);
if (is_saved)
    printf("Scanner parameters saved successfully!");
else
    printf("Scanner parameters were not saved!");
}
```

## 4.1.3 Интерфейс работы со сканерами серии RF62X v2.x.x

Файлы rf62X\_sdk.h, rf62X\_types.h и rf62Xcore.h предоставляют весь необходимый интерфейс для работы со сканерами серии RF62X v2.x.x

## search\_scanners

Прототип: rfUint8 search\_scanners(vector\_t \*list, scanner\_types\_t type, rfUint32 timeout, protocol\_types\_t protocol);

Описание: Функция поиска устройств RF62X v2.x.x в сети

# Параметры:

- list Указатель на список, который будет заполнен найденными сканерами в сети.
- type Тип сканера для поиска (kRF627 OLD, kRF627 SMART).
- timeout Время поиска на каждом Ethernet интерфейсе (мс).
- protocol Тип протокола, по которому будет осуществляться поиск (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

66

```
/** @file rf62X_sdk.h */
/**
    * @brief search_scanners - Search for RF62X devices over network
    *
    * @param[out] list Ptr to list of rf627 objects. If not null list will be
    * filled with found devices
    * @param[in] type Scanner's type (RF627-old, RF627-smart)
    * @param[in] timeout Time to search
    * @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
    *
    * @return TRUE on success
    */
rfUint8 search_scanners(
```

```
vector_t *list, scanner_types_t type,
    rfUint32 timeout, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X types.h"
int main()
  // Initialize sdk library
  core_init();
  // Create value for scanners vector's type
  vector_t* scanners = (vector_t*)calloc(1, sizeof (vector_t));
  // Initialization vector
  vector_init(&scanners);
  // Iterate over all available network adapters in the current operating
  // system to send "Hello" requests.
  uint32_t count = 0;
  for (int i=0; i<GetAdaptersCount(); i++)</pre>
     uint32_t host_ip_addr = ntohl(inet_addr(GetAdapterAddress(i)));
     uint32_t host_mask = ntohl(inet_addr(GetAdapterMasks(i)));
     // call the function to change adapter settings inside the library.
     set_platform_adapter_settings(host_mask, host_ip_addr);
     // Search for rf627smart devices over network by Service Protocol.
     if (host_ip_addr != 0)
         // Get another IP Addr and set this changes in adapter settings.
        printf("Search scanners from:\n "
               "* IP Address\t: %s\n "
               "* Netmask\t: %s\n",
              GetAdapterAddress(i), GetAdapterMasks(i));
         search_scanners(scanners, kRF627_SMART, 300, kSERVICE);
         // Print count of discovered rf627smart in network
        printf("Discovered\t: %d RF627\n", (int) vector_count(scanners)-count);
        printf("----\n");
        count = (int)vector_count(scanners);
      }
  }
  // Print count of discovered rf627smart in network
  printf("Was found\t: %d RF627 v2.x.x", (int)vector_count(scanners));
```

```
// some code...
}
```

## get\_info\_about\_scanner

**Прототип:** hello\_information get\_info\_about\_scanner(scanner\_base\_t \*device, protocol\_types\_t protocol);

**Описание:** Функция получения информации о сканере из пакета приветствия (Helloпакет)

# Параметры:

- device Указатель на сканер
- protocol Тип протокола, по которому был получен пакет приветствия (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: hello\_information в случае успеха, иначе ошибка

## Пример в коде:

```
/** @file rf62X sdk.h */
 * @brief get_info_about_scanner - Get information about scanner from
 * hello packet
 * @param[in] device Ptr to scanner
* @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return hello_information on success
*/
hello_information get_info_about_scanner(
      scanner_base_t *device, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
   // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search scanners(scanners, kRF627 SMART, timeout, kSERVICE);
   // Print count of discovered rf627smart in network by Service Protocol
   printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
```

```
for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
  hello_information result =
           get_info_about_scanner(vector_get(scanners,i), kSERVICE);
   rf627_smart_hello_info_by_service_protocol* info =
          result.rf627smart.hello_info_service_protocol;
  printf("\n\nID scanner's list: %d\n", i);
  printf("----\n");
  printf("Device information: \n");
  printf("* Name\t: %s\n", info->user_general_deviceName);
  printf("* Serial\t: %d\n", info->fact_general_serial);
  printf("* IP Addr\t: %s\n", info->user_network_ip);
  printf("* MAC Addr\t: %s\n", info->fact_network_macAddr);
  printf("\nWorking ranges: \n");
  printf("* Zsmr, mm\t: %d\n", info->fact_general_smr);
  printf("* Zmr , mm\t: %d\n", info->fact_general_mr);
  printf("* Xsmr, mm\t: %d\n", info->fact_general_xsmr);
  printf("* Xemr, mm\t: %d\n", info->fact_general_xemr);
  printf("\nVersions: \n");
  printf("* Firmware\t: %d.%d.%d\n",
         info->fact_general_firmwareVer[0],
         info->fact_general_firmwareVer[1],
         info->fact_general_firmwareVer[2]);
  printf("* Hardware\t: %d\n", info->fact_general_hardwareVer);
// some code...
```

## free\_scanner

**Прототип**: void free scanner(scanner base t \*device);

Описание: Функция очистки памяти, используемой объектом типа scanner\_base\_t

## Параметры:

• device - Указатель на сканер

## Пример в коде:

```
/** @file rf62X_sdk.h */
/**
    * @brief free_scanner - Cleanup resources allocated by device
    *
    * @param[in] device Prt to scanner
    */
void free_scanner(scanner_base_t *device);
```

```
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
{
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
  while (vector_count(scanners) > 0)
     uint32_t index = vector_count(scanners)-1;
      // Get last scanner in vector for delete
      scanner_base_t* device = vector_get(scanners, index);
      // Cleanup resources allocated by device
     free_scanner(device);
      // Delete from vector
     vector_delete(scanners, index);
   }
```

## connect to scanner

Прототип: rfUint8 connect\_to\_scanner(scanner\_base\_t \*device, protocol\_types\_t protocol);

Описание: Функция установки соединения со сканером

## Параметры:

- device Указатель на сканер
- protocol Тип протокола, по которому будет выполнено подключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

## Пример в коде:

```
/** @file rf62X_sdk.h */
/**
* @brief connect_to_scanner - Establish connection to the RF62X device
                                                                  (continues on next page)
```

```
* @param[in] device Ptr to scanner
 * @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return TRUE on success
*/
rfUint8 connect_to_scanner(
      scanner_base_t *device, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection to the RF627 device by Service Protocol.
     uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
      if (!isConnected) {
         printf("Failed to connect to scanner!");
         continue;
      // some actions with scanner...
   }
```

## disconnect\_from\_scanner

Прототип: rfUint8 disconnect\_from\_scanner(scanner\_base\_t \*device, protocol\_types\_t protocol);

Описание: Функция закрытия ранее установленного соединения со сканером

## Параметры:

• device - Указатель на сканер

• protocol - Тип протокола, по которому будет выполнено отключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

## Пример в коде:

```
/** @file rf62X_sdk.h */
/**
* @brief disconnect_from_scanner - Close connection to the device
 * @param[in] device Prt to scanner
* @param[in] protocol Protocol's type (Service, ENIP, Modbus-TCP)
* @return TRUE on success
* /
rfUint8 disconnect_from_scanner(
      scanner_base_t *device, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
   // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
   for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection to the RF627 device by Service Protocol.
      uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
      if (!isConnected) {
         printf("Failed to connect to scanner!");
         continue;
      }
      // some actions with scanner...
      // Disconnect from scanner.
      disconnect from scanner (scanner, kSERVICE)
  }
```

## check connection to scanner

Прототип: check\_connection\_to\_scanner(scanner\_base\_t \*device, rfUint32 timeout, protocol\_types\_t protocol);

Описание: Функция проверки доступности сканера в сети (после подключения к нему)

## Параметры:

- device Указатель на сканер
- timeout Время проверки соединения со сканером (мс).
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file rf62X sdk.h */
* @brief check_connection_to_scanner - Check connection to the RF62X device
 * @param[in] device Ptr to scanner
 * @param[in] timeout Time to check connection
 * @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return TRUE on success
*/
rfUint8 check_connection_to_scanner(
      scanner_base_t *device, rfUint32 timeout, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
```

```
// Establish connection to the RF627 device by Service Protocol.
uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
if (!isConnected) {
    printf("Failed to connect to scanner!");
    continue;
}

// Check connection to the RF627 device.

uint8_t is_available =
    check_connection_to_scanner(scanner, 300, kSERVICE);
if (!is_available) {
    printf("Scanner is not available now!");
    continue;
}

// some actions with scanner...
}
```

## get\_profile2D\_from\_scanner

Прототип: rf627\_profile2D\_t\* get\_profile2D\_from\_scanner(scanner\_base\_t \*device, rfBool zero\_points, rfBool realtime, protocol\_types\_t protocol);

Описание: Функция получения результатов измерений

## Параметры:

- device Указатель на сканер
- zero\_points Включать нулевые точки в возвращаемом профиле.
- realtime Получение профиля в реальном времени (буферизация отключена).
- protocol Тип протокола, по которому будет получен профиль (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: Указатель на rf627\_profile2D\_t при успехе, иначе - NULL

## Пример в коде:

```
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      connect_to_scanner(scanner, kSERVICE);
      uint8_t zero_points = TRUE;
      uint8_t realtime = TRUE;
      // Get profile from scanner's data stream by Service Protocol.
      rf627_profile2D_t* result = get_profile2D_from_scanner(
            scanner, zero_points, realtime, kSERVICE);
      rf627_smart_profile2D_t* profile2D = result->rf627smart_profile2D;
      if (profile2D != NULL) {
         printf("Profile was successfully received!");
         // some actions with profile...
         free_profile2D(result);
         printf("Profile was not received!");
   }
```

## free\_profile2D

**Прототип:** void free profile2D(rf627 profile2D t\* profile);

Описание: Функция очистки ресурсов, выделенных для rf627 profile2D t

## Параметры:

• profile - Указатель на профиль

## Пример в коде:

```
/** @file rf62X_sdk.h */
 * @brief free_profile2D - Cleanup resources allocated for profile2D
 * @param[in] profile Ptr to rf627_profile2D_t
*/
void free_profile2D(rf627_profile2D_t* profile);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
   for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      connect_to_scanner(scanner, kSERVICE);
      uint8 t zero points = TRUE;
      uint8_t realtime = TRUE;
      // Get profile from scanner's data stream by Service Protocol.
      rf627_profile2D_t* result = get_profile2D_from_scanner(
            scanner, zero_points, realtime, kSERVICE);
      rf627_smart_profile2D_t* profile2D = result->rf627smart_profile2D;
      if (profile2D != NULL) {
         printf("Profile was successfully received!");
         // some actions with profile...
         free_profile2D(result);
        printf("Profile was not received!");
  }
```

## get\_frame\_from\_scanner

Прототип: rf627\_frame\_t\* get\_frame\_from\_scanner(scanner\_base\_t \*device, protocol\_types\_t protocol);

Описание: Функция получения кадров с матрицы устройства

## Параметры:

- device Указатель на сканер
- protocol Тип протокола, по которому будет получен кадр (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: Указатель на rf627 frame t при успехе, иначе - NULL

#### Пример в коде:

```
/** @file rf62X sdk.h */
/**
* @brief get_frame_from_scanner - Get RAW frame from scanner
* @param[in] device Ptr to scanner
* @param[in] protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return ptr to rf627_frame_t structure
rf627_frame_t* get_frame_from_scanner(
      scanner base t *device, protocol types t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int) vector count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
   {
      scanner_base_t* scanner = vector_get(scanners,i);
      connect_to_scanner(scanner, kSERVICE);
      // Get frame from CMOS-sensor.
      rf627_frame_t* frame = get_frame_from_scanner(scanner, kSERVICE);
      if (frame != NULL) {
         printf("Frame was successfully received!");
         // some actions with Frame...
         free_frame(frame);
         printf("Frame was not received!");
```

}

## free\_frame

**Прототип:** void free\_frame(rf627\_frame\_t\* profile);

**Описание:** Функция очистки ресурсов, выделенных для rf627 frame t

## Параметры:

• frame - Указатель на кадр

## Пример в коде:

```
/** @file rf62X_sdk.h */
/**
* @brief free_frame - Cleanup resources allocated for frame
* @param[in] frame Ptr to rf627_frame_t
void free_frame(rf627_frame_t* frame);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
  for (int i = 0; i < (int) vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      connect_to_scanner(scanner, kSERVICE);
      // Get frame from CMOS-sensor.
      rf627_frame_t* frame = qet_frame_from_scanner(scanner, kSERVICE);
      if (frame != NULL) {
         printf("Frame was successfully received!");
         // some actions with Frame...
         free_frame(frame);
```

```
}else
    printf("Frame was not received!");
}
```

## read params from scanner

Прототип: rfUint8 read\_params\_from\_scanner(scanner\_base\_t \*device, uint32\_t timeout, protocol\_types\_t protocol);

**Описание:** Функция получения текущих параметров сканера. При вызове данной функции SDK вычитывает со сканера все актуальные параметры, сохраняя их ввиде «списка параметров» для дальнейшей работы во внутренней памяти SDK.

## Параметры:

- device Указатель на сканер
- timeout Время получения списка параметров со сканера.
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file rf62X sdk.h */
* @brief read_params_from_scanner - Read parameters from device to
* Internal structure.
* @param device Ptr to scanner
* @param timeout Time to read parameters
* @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
\star @return TRUE on success
rfUint8 read_params_from_scanner(
     scanner_base_t *device, rfUint32 timeout, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X_types.h"
int main()
   // Actions before search (see example of search_scanners() method)...
```

```
// Search for RF627-smart devices over network by Service Protocol.
search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);

// Print count of discovered rf627smart in network by Service Protocol
printf("Discovered: %d rf627-smart\n", (int) vector_count(scanners));

for (int i = 0; i < (int) vector_count(scanners); i++)
{
    scanner_base_t* scanner = vector_get(scanners,i);
    connect_to_scanner(scanner, kSERVICE);

    uint8_t is_read = read_params_from_scanner(scanner, 300, kSERVICE);
    if (is_read) {
        printf("Scanner parameters were read successfully!");
        // some actions with params...
    }else
        printf("Scanner parameters were not read!");
}</pre>
```

#### get parameter

**Прототип**: parameter\_t\* get\_parameter(scanner\_base\_t \*device, const rfChar\* param\_name);

Описание: Функция получения конкретного параметра по его имени (ключу). При вызове данной функции SDK осуществляет поиск нужного параметра из последних прочитанных при вызове функции read\_params\_from\_scanner . В случае, если запрашиваемый параметр отсутствует в конкретном сканере, функция вернёт NULL.

## Параметры:

- device Указатель на сканер
- param\_name Имя (ключ) параметра.

Возвращаемое значение: parameter\_t\* при успехе, иначе - NULL

## Пример в коде:

```
/** @file rf62X_sdk.h */
/**
    * @brief get_parameter - Search parameters by his name
    *
    * @param device - ptr to scanner
    * @param param_name - name of parameter
    *
    * @return param on success, else - null
    */
parameter_t* get_parameter(
        scanner_base_t *device, const rfChar* param_name);

/** @file main.c */
```

```
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
   {
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection.
      connect_to_scanner(scanner, kSERVICE);
      // Read params.
      read_params_from_scanner(scanner, 300, kSERVICE);
      // Get parameter of Device Name
      parameter_t* name = get_parameter(scanner, "user_general_deviceName");
      if (name != NULL) {
        char* value = name->val_str->value;
        printf("Current Device Name\t: %s\n", value);
      // Get parameter of Sensor Framerate
      parameter_t* framerate = get_parameter(scanner, "user_sensor_framerate");
      if (framerate != NULL) {
        uint32_t value = framerate->val_uint32->value;
        printf("Current FPS\t\t: %d\n", value);
      // some actions with other parameters...
  }
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

## set\_parameter

Прототип: rfUint8 set parameter(scanner base t \*device, parameter t\* param)

Описание: Функция установки конкретного параметра. При вызове данной функции происходит установка параметра в списке параметров во внутренней памяти SDK.\* Для отправки изменений в сканер необходимо вызвать метод write\_params\_to\_scanner.

## Параметры:

- device Указатель на сканер.
- рагат Указатель на параметр для установки.

Возвращаемое значение: TRUE при успехе, иначе - FALSE

## Пример в коде:

```
/** @file rf62X sdk.h */
* @brief set_parameter - Set parameter
 * @param device Ptr to scanner
* @param param Parameter name
 * @return TRUE on success
*/
rfUint8 set_parameter(
      scanner_base_t *device, parameter_t* param);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
   search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
   // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
   for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection.
      connect_to_scanner(scanner, kSERVICE);
      // Read params.
      read_params_from_scanner(scanner, 300, kSERVICE);
```

```
//
   // Example of working with the parameter type:
  // uint32_t
   //
   // Get parameter of Laser Enabled
  parameter_t* laser = get_parameter(scanner, "user_laser_enabled");
  if (laser != NULL)
     uint32 t is enabled = laser->val uint32->value;
     printf("Current Laser State\t: %s\n", (is_enabled? "ON":"OFF"));
      // Change the current state to the opposite
      is_enabled = !is_enabled;
     laser enabled->val uint32->value = is enabled;
     printf("New Laser State\t: %s\n", (is_enabled? "ON":"OFF"));
     set_parameter(scanner, laser_enabled);
   // some actions with other parameters before applying changes...
}
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

#### write params to scanner

Прототип: rfUint8 write\_params\_to\_scanner(scanner\_base\_t \*device, rfUint32 timeout, protocol types t protocol)

**Описание:** Функция передачи параметров из внутренней памяти SDK в сканер. При вызове данной функции происходит отправка изменённых параметров в сканер

#### Параметры:

- device Указатель на сканер.
- timeout Время отправки изменённых параметров в сканер.
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

#### Пример в коде:

```
/** @file rf62X_sdk.h */
/**
     * @brief write_params_to_scanner - Send current parameters to device
     *
     * @param device Ptr to scanner
```

```
* @param timeout Time to send parameters
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return TRUE on success
rfUint8 write_params_to_scanner(
     scanner_base_t *device, rfUint32 timeout, protocol_types_t protocol);
/** @file main.c */
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
   // Actions before search (see example of search_scanners() method)...
  // Search for RF627-smart devices over network by Service Protocol.
  search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  // Print count of discovered rf627smart in network by Service Protocol
  printf("Discovered: %d rf627-smart\n", (int)vector_count(scanners));
  for (int i = 0; i < (int) vector_count(scanners); i++)</pre>
     scanner_base_t* scanner = vector_get(scanners,i);
      // Establish connection.
      connect_to_scanner(scanner, kSERVICE);
     // Read params.
     read_params_from_scanner(scanner, 300, kSERVICE);
      // Example of working with the parameter type:
      // uint32_t
      //
      // Get parameter of Laser Enabled
     parameter_t* laser = get_parameter(scanner, "user_laser_enabled");
      if (laser != NULL)
        uint32_t is_enabled = laser->val_uint32->value;
        printf("Current Laser State\t: %s\n", (is_enabled? "ON":"OFF"));
         // Change the current state to the opposite
         is_enabled = !is_enabled;
         laser_enabled->val_uint32->value = is_enabled;
         printf("New Laser State\t: %s\n", (is_enabled? "ON":"OFF"));
        printf("----\n");
```

```
set_parameter(scanner, laser_enabled);
}

// some actions with other parameters before applying changes...

// Apply changed parameters to the device

uint8_t is_applied = write_params_to_scanner(scanner, 300, kSERVICE);

if (is_applied)
    printf("Scanner parameters were applied successfully!");

else
    printf("Scanner parameters were not applied!");

}
```

## save\_params\_to\_scanner

Прототип: rfUint8 save\_params\_to\_scanner(scanner\_base\_t \*device, rfUint32 timeout, protocol\_types\_t protocol);

**Описание:** Функция сохранения параметров сканера во внутреннюю память устройства. Сохраненные параметры также будут использоваться после перезапуске устройства или после смены(обновления) прошивки.

## Параметры:

- device Указатель на сканер.
- timeout Время ожидания результата сохранения параметров в сканере.
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: TRUE при успехе, иначе - FALSE

## Пример в коде:

```
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  // Actions before search (see example of search_scanners() method)...
   // Search for RF627-smart devices over network by Service Protocol.
   search_scanners(scanners, kRF627_SMART, timeout, kSERVICE);
  for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
      scanner base t* scanner = vector get(scanners,i);
      // Establish connection.
      connect_to_scanner(scanner, kSERVICE);
      // Read params.
      read_params_from_scanner(scanner, 300, kSERVICE);
      // After changing some parameters...
      // Apply changed parameters to the device
      write_params_to_scanner(scanner, 300, kSERVICE);
      // Save current parameters in the device memory
      uint8_t is_saved = save_params_to_scanner(scanner, 300, kSERVICE);
      if (is_saved)
         printf("Scanner parameters saved successfully!");
      else
         printf("Scanner parameters were not saved!");
   }
```

# 4.2 Интерфейс «обёртки» на С++

Данная библиотека позволяет упростить разработку приложений на языке С++

Для её использования в проектах С++ разработчику необходимо включить h-файлы библиотеки в свой проект, а также добавить к проекту «обёртку» в качестве статической или динамической программной библиотеки.

Для скачивания библиотеки см. Последние выпуски RF62X-SDK библиотек. Для компиляции библиотеки из исходников см. *Компиляция «обёртки» на С++*. Для использования в проектах см. *Создание проекта С/С++*.

## 4.2.1 Инициализация SDK

Файл rf62Xsdk.h является основным файлом программного интерфейса (API) и определяет функциональность библиотеки-«обёртки». Файл rf62Xtypes.h содержит дополнительный набор классов, структур, типов и перечислений используемых в SDK.

## sdk\_init

Прототип: bool sdk init();

Описание: Функция инициализации SDK. Должна быть вызвана один раз перед дальнейшими вызовами любых библиотечных функций

**Возвращаемое значение:** После успешного завершения возвращается 1 (true). В противном случае должен быть возвращен код ошибки.

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief sdk_init - Initialize sdk library
* @details Must be called once before further calls to any
* library functions
* @return true if success.
* /
int8_t sdk_init();
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
  bool isInit = sdk_init();
  if (isInit)
     std::cout << "SDK version: " << sdk_version() << std::endl;</pre>
  else
      std::cout << "SDK initialization error!" << std::endl;</pre>
      return -1;
   // some code...
```

## sdk\_cleanup

**Прототип:** void sdk\_cleanup();

Описание: Функция высвобождает ресурсы, выделенные при инициализации СДК

функцией sdk\_init

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief sdk_cleanup - Cleanup resources allocated with
* sdk_init() function
void sdk_cleanup();
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // some code...
  // Cleanup resources
  sdk_cleanup();
```

## sdk\_version

Прототип: std::string sdk\_version();

Описание: Функция получения информации о версии SDK

Возвращаемое значение: версия SDK в формате X.Y.Z (мажорная, минорная, патч)

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief sdk_version - Return info about SDK version
    *
    * @return SDK version
    */
std::string sdk_version();
```

```
/** @file main.cpp */
#include <string>
#include <iostream>

#include "rf62Xsdk.h"
#include "rf62Xtypes.h"

int main()
{
    // Initialize sdk library
    sdk_init();

    // Print return rf62X sdk version
    std::cout << "SDK version: " << sdk_version() << std::endl;

    // some code...
}</pre>
```

## 4.2.2 Kласс rf627old

Данный класс определён в файле rf62Xsdk.h и предоставляет интерфейс для работы со сканерами серии RF627 v20.x.x.x

#### search

Прототип: static std::vector<std::shared\_ptr<rf627old>> search(uint32\_t timeout = 300, bool only available result = true, PROTOCOLS protocol = PROTOCOLS::SERVICE);

Описание: Метод поиска устройств RF62X v2.x.x в сети

## Параметры:

- timeout Время поиска на каждом Ethernet интерфейсе (мс).
- only\_available\_result Без сохранения истории поиска (только доступные сканеры на текущий момент).
- protocol Тип протокола, по которому будет осуществляться поиск (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: Вектор rf627old устройств

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief search - Search for rf627old devices over network
    *
    * @param timeout Search timeout[ms] for each Ethernet interface
    * @param only_available_result Without saving search history
    * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
    *
```

```
* @return vector of rf627old devices
 */
static std::vector<std::shared_ptr<rf627old>> search(
        uint32_t timeout = 300, bool only_available_result = true,
        PROTOCOLS protocol = PROTOCOLS::SERVICE);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627old>> list;
   // Search for rf627old devices over network
  list = rf627old::search(500);
  // Print count of discovered rf627old in network
  std::cout << "Was found\t: " << list.size() << " RF627 v20.x.x.x";
   // some code...
```

## get\_info

Прототип: std::shared\_ptr<hello\_info> get\_info(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод получения информации о сканере из пакета приветствия (Helloпакет)

#### Параметры:

• protocol - Тип протокола, по которому был получен пакет приветствия (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: hello\_info в случае успеха, иначе - null

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief get_info - Get information about scanner from hello packet
    *
```

```
* @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return hello_info on success, else - nullptr
std::shared_ptr<hello_info> get_info(
       PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627old>> list;
  // Search for rf627old devices over network
  list = rf627old::search(500);
  // Print count of discovered rf627old in network by Service Protocol
  std::cout << "Was found\t: "<<li>!st.size()<<" RF627-Old"<< std::endl;</pre>
  std::cout << "======== " << std::endl;
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared_ptr<hello_info> info = list[i]->get_info();
     std::cout << "\n\nID scanner's list: " << i</pre>
                                                             << std::endl;
     std::cout << "-----" << std::endl;
     std::cout << "Device information: "</pre>
                                                             << std::endl;
     std::cout << "* Name \t: " << info->device_name() << std::endl;
     std::cout << "* Serial\t: " << info->serial_number()
                                                             << std::endl;
     std::cout << "* IP Addr\t: " << info->ip_address()
                                                             << std::endl;
     std::cout << "* MAC Addr\t: " << info->mac_address() << std::endl;</pre>
     std::cout << "\nWorking ranges: "</pre>
                                                             << std::endl;
     std::cout << "* Zsmr, mm\t: " << info->z smr()
                                                          << std::endl;
     std::cout << "* Zmr , mm\t: " << info->z_mr()
                                                             << std::endl;
     std::cout << "* Xsmr, mm\t: " << info->x_smr()
                                                             << std::endl;
     std::cout << "* Xemr, mm\t: " << info->x_emr()
                                                             << std::endl;
     std::cout << "\nVersions: "</pre>
                                                             << std::endl;
     std::cout << "* Firmware\t: " << info->firmware_version() << std::endl;</pre>
     std::cout << "* Hardware\t: " << info->hardware_version() << std::endl;</pre>
     std::cout << "-----" << std::endl;
   }
```

```
// some code...
}
```

#### connect

**Прототип:** bool connect(PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод установки соединения со сканером

## Параметры:

• protocol - Тип протокола, по которому будет выполнено подключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief connect - Establish connection to the rf627old device
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return true on success, else - false
bool connect(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
{
  // Initialize sdk library
  sdk_init();
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627old>> list;
  // Search for rf627old devices over network
  list = rf627old::search(500);
  // Print count of discovered rf627old in network by Service Protocol
  std::cout << "Was found\t: "<<li>size()<<" RF627-Old"<< std::endl;</pre>
  for (size_t i = 0; i < list.size(); i++)</pre>
```

```
std::shared_ptr<rf627old> scanner = list[i];

// Establish connection to the RF627 device by Service Protocol.

bool isConnected = scanner->connect();

if (!isConnected) {
    std::cout << "Failed to connect to scanner!" << std::endl;
    continue;
}

// some actions with scanner...
}</pre>
```

## is\_connected

**Прототип:** bool is\_connected();

Описание: Получение статуса подключения к сканеру методом connect

**Возвращаемое значение:** true \*, если соединение со сканером было успешно установлено, иначе - \* false

## Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief is_connected - Scanner connection status by the
* connect() method.
\star @return true, if a connection to the scanner was previously
* established using the connect() method, else - false.
bool is_connected();
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
  sdk_init();
  // Search for rf627old devices over network
  std::vector<std::shared_ptr<rf627old>> list = rf627old::search();
   for (size_t i = 0; i < list.size(); i++)</pre>
```

```
{
    std::shared_ptr<rf627old> scanner = list[i];

    // Establish connection to the RF627 device by Service Protocol.
    scanner->connect();

    bool result = scanner->is_connected()
    if (result) {
        std::cout << "Connection has been established";
    }
}</pre>
```

#### disconnect

**Прототип:** bool disconnect(PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод закрытия ранее установленного соединения со сканером

## Параметры:

• protocol - Тип протокола, по которому будет выполнено отключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief disconnect - Close connection to the device
    *
    * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
    *
    * @return true on success, else - false
    */
    bool disconnect(PROTOCOLS protocol = PROTOCOLS::CURRENT);

/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xsdk.h"
int main()
{
    // Initialize sdk library
    sdk_init();
    // Search for rf627old devices over network
    std::vector<std::shared_ptr<rf627old>> list = rf627old::search();
```

```
for (size_t i = 0; i < list.size(); i++)
{
    std::shared_ptr<rf627old> scanner = list[i];

    // Establish connection to the RF627 device by Service Protocol.
    bool isConnected = scanner->connect();
    if (!isConnected){
        std::cout << "Failed to connect to scanner!" << std::endl;
        continue;
    }

    // some actions with scanner...

    // Disconnect from scanner.
    scanner->disconnect();
}
```

## check connection

Прототип: bool check\_connection(uint32\_t timeout = 500, PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод проверки доступности сканера в сети (после подключения к нему)

## Параметры:

- timeout Время проверки соединения со сканером (мс).
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
   sdk_init();
   // Search for rf627old devices over network
   std::vector<std::shared_ptr<rf627old>> list = rf627old::search();
   for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627old> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      bool isConnected = scanner->connect();
      if (!isConnected) {
         std::cout << "Failed to connect to scanner!" << std::endl;</pre>
         continue;
      }
      // Check connection to the RF627 device.
      bool isAvailable = scanner->check_connection(300);
      if (!isAvailable) {
         std::cout << "Scanner is not available now, "</pre>
                   << "please call back later!" << std::endl;</pre>
         continue;
      // some actions with scanner...
   }
```

## is available

Прототип: bool is\_available();

**Описание:** Метод получения статуса доступности сканера в сети. Значение, возвращаемое методом, зависит от результатов выполнения методов search и check\_connection

Возвращаемое значение: true если сканер доступен, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
  * @brief is_available - Scanner availability status on the network.
  * @details The value returned by the method depends on the results
  * of the execution of the search() and check_connection() methods.
  *
  * @return true, if the scanner is available, otherwise - false.
```

```
*/
bool is_available();
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
   sdk_init();
   // Search for rf627old devices over network
   std::vector<std::shared_ptr<rf627old>> list = rf627old::search();
   for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627old> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      scanner->connect();
      // some time after using the scanner...
      // Check network connections to scanner
      scanner->check_connection(300);
      bool isAvailable = scanner->is_available();
      if (!isAvailable) {
         std::cout << "Scanner is not available!" << std::endl;</pre>
         std::cout << "Check the power supply to the scanner.";</pre>
      // some code...
   }
```

## get\_profile2D

**Прототип**: std::shared\_ptrprofile2D> get\_profile2D(bool zero\_points = true, bool realtime = true, PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод получения результатов измерений

## Параметры:

- zero\_points Включать нулевые точки в возвращаемом профиле.
- realtime Получение профиля в реальном времени (буферизация отключена).

• protocol - Тип протокола, по которому будет получен профиль (Service Protocol, ENIP, Modbus-TCP)

Boзвращаемое значение: std::shared\_ptrptrprofile2D> при успехе, иначе - nullptr
Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief get_profile2D - Get 2D measurement from scanner's data stream
 * @param zero_points Enable zero points in return profile2D
* @param realtime Enable getting profile in real time (buffering is disabled)
* @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return profile2D if success, else - nullptr
std::shared_ptrprofile2D> get_profile2D(
        bool zero_points = true, bool realtime = true,
        PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
  sdk_init();
  // Search for rf627old devices over network
  std::vector<std::shared_ptr<rf627old>> list = rf627old::search();
  for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627old> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      bool isConnected = scanner->connect();
      if (isConnected) {
         bool zero_points = true;
         bool realtime = true;
         std::shared_ptrprofile2D> profile = nullptr;
         // Get profile from scanner
         profile = scanner->get_profile2D(zero_points, realtime);
         if (profile != nullptr) {
            std::cout << "Profile was successfully received!" << std::endl;</pre>
            // some actions with profile...
         }else
            std::cout << "Profile was not received!" << std::endl;</pre>
```

```
}
// some code...
}
```

## read params

**Прототип:** bool read\_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод получения текущих параметров сканера. При вызове данного метода SDK вычитывает со сканера все актуальные параметры, сохраняя их в виде «списка параметров» для дальнейшей работы во внутренней памяти SDK.

## Параметры:

• protocol - Тип протокола, по которому будут прочитаны параметры (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief read_params - Read parameters from device to
* internal SDK memory
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return true on success, else - false
bool read_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Search for rf627old devices over network
  std::vector<std::shared_ptr<rf627old>> list = rf627old::search();
  for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627old> scanner = list[i];
```

```
// Establish connection to the RF627 device by Service Protocol.
bool isConnected = scanner->connect();
if (isConnected) {
    // read params from RF627 device by Service Protocol.
    bool isRead = scanner->read_params();
    if (isRead) {
        std::cout << "Scanner parameters were read successfully!";
        // some actions with params...
    }else
        std::cout << "Scanner parameters were not read!";
}
</pre>
```

#### get param

**Прототип:** std::shared\_ptr<param> get\_param(std::string param\_name);

Описание: Метод получения конкретного параметра по его имени (ключу). При вызове данного метода SDK осуществляет поиск нужного параметра из последних прочитанных при вызове функции read\_params. В случае, если запрашиваемый параметр отсутствует в конкретном сканере, метод вернёт nullptr.

## Параметры:

• param\_name - Имя (ключ) параметра.

**Возвращаемое значение:** std::shared\_ptr<param> при успехе, иначе - nullptr

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief get_param - Get parameter by his name
    * Before using read_params() method should be called
    *
    * @param param_name Name of parameter
    *
    * @return param on success, else - null
    */
std::shared_ptr<param> get_param(std::string param_name);

/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
{
```

```
// Initialize sdk library
sdk_init();
// Search for rf627old devices over network
std::vector<std::shared_ptr<rf627old>> scanners = rf627old::search();
for (size_t i = 0; i < scanners.size(); i++)</pre>
   // Establish connection.
   scanners[i]->connect();
   // Read params.
   scanners[i]->read_params();
   // Get parameter of Device Name
   auto name = scanners[i]->get_param("user_general_deviceName");
   if (name != nullptr) {
      std::string str_name = name->getValue<std::string>();
      std::cout << "Current Device Name \t: " << str_name << std::endl;</pre>
   }
   // Get parameter of Sensor Framerate
   auto framerate = scanner->get_param("user_sensor_framerate");
   if (framerate != nullptr) {
      uint32_t framerate_value = framerate->getValue<uint32_t>();
      std::cout<<"Current FPS\t\t: "<< framerate_value << std::endl;</pre>
   // some actions with other parameters...
// some code...
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

## set\_param

**Прототип:** bool set\_param(std::string name, T value);

**Описание:** Метод установки конкретного параметра. При вызове данного метода происходит установка параметра в списке параметров во внутренней памяти SDK.\* Для отправки изменений в сканер необходимо вызвать метод write\_params.

## Параметры:

- param\_name Имя (ключ) параметра.
- value \*- Новое значение параметра

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief set_param - Set parameter
* @param name Name of parameter
* @param value Value to set
 * @return true on success, else - false
template<typename T>
bool set_param(std::string name, T value);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <vector>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
   // Search for rf627old devices over network
  std::vector<std::shared_ptr<rf627old>> scanners = rf627old::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      scanners[i]->read_params();
      // Set parameter of Device Name
      scanner->set_param("user_general_deviceName", "RF627 New Name");
      // Sen parameter of Sensor Framerate
     scanner->set_param("user_sensor_framerate", 100);
      // Set parameter of Device IP Addr
      std::vector<uint32_t> ip {192, 168, 1, 31};
      scanner->set_param("user_network_ip", ip);
      // some actions with other parameters...
   // some code...
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

## set\_param\_by\_key

**Прототип:** bool set param by key(std::string name, std::string key);

Описание: Метод установки конкретного параметра по ключу. При вызове данного метода происходит установка параметра в списке параметров во внутренней памяти SDK. Для отправки изменений в сканер необходимо вызвать метод write params.

## Параметры:

- param\_name Имя (ключ) параметра.
- key \*- Ключ (enum) параметра

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief set_param_by_key - Set parameter from Enum
 \star @param name Name of parameter
* @param key Key to set
 * @return true on success, else - false
* /
bool set_param_by_key(std::string name, std::string key);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Search for rf627old devices over network
  std::vector<std::shared_ptr<rf627old>> scanners = rf627old::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      scanners[i]->read params();
      // Set parameter of Laser Enabled (TRUE or FALSE)
      scanner->set_param_by_key("user_laser_enabled", "FALSE");
      // Sen parameter of Sensor sync source (SYNC_INTERNAL,
      // SYNC_EXTERNAL, SYNC_SOFTWARE_EXT or SYNC_SOFTWARE)
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

## write\_params

**Прототип:** bool write\_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод передачи параметров из внутренней памяти SDK в сканер. При вызове данного метода происходит отправка изменённых параметров в сканер

## Параметры:

• protocol - Тип протокола, по которому будут отправлена команда на установку параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

### Пример в коде:

```
// Initialize sdk library
sdk_init();
// Search for rf627old devices over network
std::vector<std::shared_ptr<rf627old>> scanners = rf627old::search();
for (size_t i = 0; i < scanners.size(); i++)</pre>
   scanners[i]->connect();
   scanners[i]->read_params();
   // Set parameter of Device Name
   scanner->set_param("user_general_deviceName", "RF627 New Name");
   // Sen parameter of Sensor Framerate
   scanner->set param("user sensor framerate", 100);
   // some actions with other parameters...
   // Apply changed parameters to the device
   bool isApplied = scanner->write_params();
   if (isApplied)
      std::cout << "Scanner parameters were applied successfully!";</pre>
      std::cout << "Scanner parameters were not applied!";</pre>
// some code...
```

## save\_params

**Прототип**: bool save\_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод сохранения параметров сканера во внутреннюю память устройства. Сохраненные параметры также будут использоваться после перезапуске устройства или после смены(обновления) прошивки.

# Параметры:

• protocol - Тип протокола, по которому будет отправлена команда сохранения параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief save_params - Save changes to device's memory
    * @details The saved parameters will also be used if the device
    * is restarted or even if the firmware is updated.
    *
    * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
    *
```

```
* @return true on success, else - false
 */
bool save_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
   sdk_init();
   // Search for rf627old devices over network
   std::vector<std::shared_ptr<rf627old>> scanners = rf627old::search();
   for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      scanners[i]->read_params();
      // After changing some parameters...
      // Apply changed parameters to the device
      scanner->write_params();
      // Save current parameters in the device memory
      bool isSaved = scanner->save params();
      if (isSaved)
         std::cout << "Scanner parameters saved successfully!";</pre>
      else
         std::cout << "Scanner parameters were not saved!";</pre>
   // some code...
```

#### reboot\_device

**Прототип:** bool reboot device(PROTOCOLS protocol = PROTOCOLS::CURRENT)

Описание: Метод перезагрузки устройства

#### Параметры:

• protocol - Тип протокола, по которому будет отправлена команда на перезагрузку устройства (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief reboot_device - The scanner will restart
* @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
* @return true on success, else - false
bool reboot_device(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <chrono>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Search for rf627old devices over network
  std::vector<std::shared_ptr<rf627old>> scanners = rf627old::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      // Start device reboot
     scanners[i]->reboot_device();
      // Waiting 10 sec
      std::this_thread::sleep_for(std::chrono::seconds(10));
      bool isAvailable = scanners[i]->check_connection();
      if (isAvailable) {
         std::cout << "Scanner has been successfully restarted" << std::endl;</pre>
      // some other actions with scanner...
  }
```

#### send cmd

Прототип: bool send\_cmd(std::string command\_name, std::vector<uint8\_t> in, std::vector<uint8\_t>& out);

Описание: Метод отправки команды в сканер

#### Параметры:

- command\_name Название команды. (CID\_PERIPHERY\_SEND, CID\_PROFILE\_SET\_COUNTERS, и др.)
- in Данные для отправки.
- out Данные, которые были получены.

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief send_cmd - Send command to scanner
 * @param command_name Name of command:
 * CID_PERIPHERY_SEND - send/receive data to/from a peripheral device
 * CID_PROFILE_SET_COUNTERS - set counters in devices
 * @param input Data to send in command payload
 * @param output Data to receive from command payload
* @return true on success, else - false
*/
bool send_cmd(std::string command_name,
              std::vector<uint8_t> in, std::vector<uint8_t>& out);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <chrono>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
   sdk_init();
  // Search for rf627old devices over network
  std::vector<std::shared_ptr<rf627old>> scanners = rf627old::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      // Send data to periphery
      std::vector<uint8_t> in { 1, 2, 3, 4, 5};
      std::vector<uint8_t> out;
      bool isSent = scanners[i]->send_cmd("CID_PERIPHERY_SEND", in, out);
      if (isSent) {
```

```
std::cout << "The data was sent successfully." << std::endl;
std::cout << "Size of received data: " << out.size() << std::endl;
}

// Reset counters
std::vector<uint8_t> in(0);
std::vector<uint8_t> out;
isSent = scanners[i]->send_cmd("CID_PROFILE_SET_COUNTERS", in, out);
if (isSent){
    std::cout << "The counters was reset successfully." << std::endl;
}

// some other actions with scanner...
}</pre>
```

## 4.2.3 Класс rf627smart

Данный класс определён в файле rf62Xsdk.h и предоставляет интерфейс для работы со сканерами серии RF62X v2.x.x

#### search

Прототип: static std::vector<std::shared\_ptr<rf627smart>> search(uint32\_t timeout = 300, bool only available result = true, PROTOCOLS protocol = PROTOCOLS::SERVICE);

Описание: Метод поиска устройств RF62X v2.x.x в сети

#### Параметры:

- timeout Время поиска на каждом Ethernet интерфейсе (мс).
- only\_available\_result Без сохранения истории поиска (только доступные сканера на текущий момент).
- protocol Тип протокола, по которому будет осуществляться поиск (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: Вектор rf627smart устройств

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
  * @brief search - Search for rf627smart devices over network
  *
  * @param timeout Search timeout[ms] for each Ethernet interface
  * @param only_available_result Without saving search history
  * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
  *
  * @return vector of rf627smart devices
  */
static std::vector<std::shared_ptr<rf627smart>> search(
      uint32_t timeout = 300, bool only_available_result = true,
```

```
PROTOCOLS protocol = PROTOCOLS::SERVICE);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search(500);
  // Print count of discovered rf627smart in network
  std::cout << "Was found\t: " << list.size() << " RF62X v2.x.x";
   // some code...
```

## get info

Прототип: std::shared\_ptr<hello\_info> get\_info(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод получения информации о сканере из пакета приветствия (Helloпакет)

# Параметры:

• protocol - Тип протокола, по которому был получен пакет приветствия (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: hello\_info в случае успеха, иначе - null

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
  * @brief get_info - Get information about scanner from hello packet
  *
  * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
  *
  * @return hello_info on success, else - nullptr
  */
```

```
std::shared_ptr<hello_info> get_info(
       PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search(500);
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: "<<li>size()<<" RF627-Smart"<< std::endl;</pre>
  std::cout << "----" << std::endl;
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared_ptr<hello_info> info = list[i]->get_info();
     std::cout << "\n\nID scanner's list: " << i</pre>
                                                         << std::endl;
     std::cout << "-----" << std::endl;
     std::cout << "Device information: "</pre>
                                                          << std::endl;
     std::cout << "* MAC Addr\t: " << info->mac_address()
                                                         << std::endl;
     std::cout << "\nWorking ranges: "</pre>
                                                          << std::endl;
     std::cout << "* Zsmr, mm\t: " << info->z_smr()
                                                          << std::endl;
     std::cout << "* Zmr , mm\t: " << info->z_mr()
                                                          << std::endl;
     std::cout << "* Xsmr, mm\t: " << info->x_smr()
                                                          << std::endl;
     std::cout << "* Xemr, mm\t: " << info->x_emr()
                                                         << std::endl;
     std::cout << "\nVersions: "</pre>
                                                          << std::endl;
     std::cout << "* Firmware\t: " << info->firmware_version() << std::endl;</pre>
     std::cout << "* Hardware\t: " << info->hardware_version() << std::endl;</pre>
     std::cout << "-----" << std::endl;
  }
  // some code...
```

#### connect

**Прототип:** bool connect(PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод установки соединения со сканером

#### Параметры:

• protocol - Тип протокола, по которому будет выполнено подключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief connect - Establish connection to the rf627smart device
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return true on success, else - false
bool connect(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search(500);
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: "<<list.size()<<" RF627-Smart"<< std::endl;</pre>
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared_ptr<rf627smart> scanner = list[i];
     // Establish connection to the RF627 device by Service Protocol.
     bool isConnected = scanner->connect();
     if (!isConnected) {
```

#### is\_connected

**Прототип:** bool is connected();

**Описание:** Получение статуса подключения к сканеру методом connect

**Возвращаемое значение:** true \*, если соединение со сканером было успешно установлено, иначе - \* false

## Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief is_connected - Scanner connection status by the
* connect() method.
 * @return true, if a connection to the scanner was previously
 * established using the connect() method, else - false.
* /
bool is_connected();
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> list = rf627smart::search();
   for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627smart> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      scanner->connect();
```

```
bool result = scanner->is_connected()
  if (result) {
    std::cout << "Connection has been established";
  }
}</pre>
```

#### disconnect

**Прототип:** bool disconnect(PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод закрытия ранее установленного соединения со сканером

#### Параметры:

• protocol - Тип протокола, по которому будет выполнено отключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
 * @brief disconnect - Close connection to the device
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return true on success, else - false
*/
bool disconnect(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> list = rf627smart::search();
  for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627smart> scanner = list[i];
```

```
// Establish connection to the RF627 device by Service Protocol.
bool isConnected = scanner->connect();
if (!isConnected) {
    std::cout << "Failed to connect to scanner!" << std::endl;
    continue;
}

// some actions with scanner...

// Disconnect from scanner.
scanner->disconnect();
}
```

## check\_connection

Прототип: bool check\_connection(uint32\_t timeout = 500, PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод проверки доступности сканера в сети (после подключения к нему)

# Параметры:

- timeout Время проверки соединения со сканером (мс).
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

# Пример в коде:

```
{
  // Initialize sdk library
   sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> list = rf627smart::search();
   for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627smart> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      bool isConnected = scanner->connect();
      if (!isConnected) {
         std::cout << "Failed to connect to scanner!" << std::endl;</pre>
         continue;
      // Check connection with device
      bool isAvailable = scanner->check_connection(300);
      if (!isAvailable) {
         std::cout << "Scanner is not available now, "</pre>
                   << "please call back later!" << std::endl;
         continue;
      }
      // some actions with scanner...
  }
```

#### is available

Прототип: bool is available();

**Описание:** Метод получения статуса доступности сканера в сети. Значение, возвращаемое методом, зависит от результатов выполнения методов search и check\_connection

Возвращаемое значение: true если сканер доступен, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief is_available - Scanner availability status on the network.
    * @details The value returned by the method depends on the results
    * of the execution of the search() and check_connection() methods.
    *
    * @return true, if the scanner is available, otherwise - false.
    */
bool is_available();
```

```
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
   sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared ptr<rf627smart>> list = rf627smart::search();
   for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627smart> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      scanner->connect();
      // some time after using the scanner...
      // Check network connections to scanner
      scanner->check connection(300);
      bool isAvailable = scanner->is_available();
      if (!isAvailable) {
         std::cout << "Scanner is not available!" << std::endl;</pre>
         std::cout << "Check the power supply to the scanner.";</pre>
      // some code...
   }
```

#### get profile2D

**Прототип**: std::shared\_ptrprofile2D> get\_profile2D(bool zero\_points = true, bool realtime = true, PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод получения результатов измерений

#### Параметры:

- zero\_points Включать нулевые точки в возвращаемом профиле.
- realtime Получение профиля в реальном времени (буферизация отключена).
- protocol Тип протокола, по которому будет получен профиль (Service Protocol, ENIP, Modbus-TCP)

Boзвращаемое значение: std::shared\_ptr<profile2D> при успехе, иначе - nullptr Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief get_profile2D - Get 2D measurement from scanner's data stream
* @param zero points Enable zero points in return profile2D
 * @param realtime Enable getting profile in real time (buffering is disabled)
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return profile2D if success, else - nullptr
std::shared_ptrprofile2D> get_profile2D(
        bool zero_points = true, bool realtime = true,
        PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
{
  // Initialize sdk library
  sdk_init();
   // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> list = rf627smart::search();
  for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627smart> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      bool isConnected = scanner->connect();
      if (isConnected) {
         bool zero_points = true;
         bool realtime = true;
         std::shared_ptrprofile2D> profile = nullptr;
         // Get profile from scanner
         profile = scanner->get_profile2D(zero_points, realtime);
         if (profile != nullptr) {
            std::cout << "Profile was successfully received!" << std::endl;</pre>
            // some actions with profile...
            std::cout << "Profile was not received!" << std::endl;</pre>
      // some code...
  }
```

## get\_frame

Прототип: std::shared\_ptr<frame> get\_frame(PROTOCOLS protocol = PROTOCOLS::CURRENT):

Описание: Метод получения кадров видео с матрицы сканера

# Параметры:

• protocol - Тип протокола, по которому будет получен кадр (Service Protocol, ENIP, Modbus-TCP)

**Возвращаемое значение:** std::shared\_ptr<frame> при успехе, иначе - nullptr

#### Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief get frame - Get RAW frame from scanner
* @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return frame if success, else - null
* /
std::shared_ptr<frame> get_frame(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> list = rf627smart::search();
  for (size_t i = 0; i < list.size(); i++)</pre>
      std::shared_ptr<rf627smart> scanner = list[i];
      // Establish connection to the RF627 device by Service Protocol.
      bool isConnected = scanner->connect();
      if (isConnected) {
         // Get Frame from scanner.
         std::shared_ptr<frame> frame = scanner->get_frame();
         if (frame != nullptr) {
            std::cout << "Frame was successfully received!" << std::endl;</pre>
            // some actions with profile...
         }else
```

```
std::cout << "Frame was not received!" << std::endl;
}
// some code...
}
</pre>
```

#### read params

**Прототип:** bool read\_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод получения текущих параметров сканера. При вызове данного метода SDK вычитывает со сканера все актуальные параметры, сохраняя их ввиде «списка параметров» для дальнейшей работы во внутренней памяти SDK.

# Параметры:

• protocol - Тип протокола, по которому будут прочитаны параметры (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief read_params - Read parameters from device to
* internal SDK memory
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return true on success, else - false
bool read_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
  // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> list = rf627smart::search();
   for (size_t i = 0; i < list.size(); i++)</pre>
```

```
std::shared_ptr<rf627smart> scanner = list[i];

// Establish connection to the RF627 device.
bool isConnected = scanner->connect();
if (isConnected) {
    // read params from RF627 device.
    bool isRead = scanner->read_params();
    if (isRead) {
        std::cout << "Scanner parameters were read successfully!";
        // some actions with params...
    }else
        std::cout << "Scanner parameters were not read!";
    }
}
// some code...
}</pre>
```

#### get param

**Прототип:** std::shared\_ptr<param> get\_param(std::string param\_name);

**Описание:** Метод получения конкретного параметра по его имени (ключу). При вызове данного метода SDK осуществляет поиск нужного параметра из последних прочитанных при вызове метода read\_params . В случае, если запрашиваемый параметр отсутствует в конкретном сканере, функция вернёт nullptr.

## Параметры:

• param\_name - Имя (ключ) параметра.

**Возвращаемое значение:** std::shared\_ptr<param> при успехе, иначе - nullptr

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
  * @brief get_param - Get parameter by his name
  * Before using read_params() method should be called
  *
  * @param param_name Name of parameter
  *
  * @return param on success, else - null
  */
std::shared_ptr<param> get_param(std::string param_name);

/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
```

```
int main()
   // Initialize sdk library
  sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      // Establish connection.
      scanners[i]->connect();
      // Read params.
      scanners[i]->read_params();
      // Get parameter of Device Name
      auto name = scanners[i]->get_param("user_general_deviceName");
      if (name != nullptr) {
         std::string str_name = name->getValue<std::string>();
         std::cout << "Current Device Name \t: " << str_name << std::endl;</pre>
      }
      // Get parameter of Sensor Framerate
      auto framerate = scanner->get_param("user_sensor_framerate");
      if (framerate != nullptr) {
         uint32_t framerate_value = framerate->getValue<uint32_t>();
         std::cout<<"Current FPS\t\t: "<< framerate_value << std::endl;</pre>
      }
      // some actions with other parameters...
   // some code...
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

#### set\_param

**Прототип:** bool set param(std::string name, T value);

**Описание:** Метод установки конкретного параметра. При вызове данного метода происходит установка параметра в списке параметров во внутренней памяти SDK.\* Для отправки изменений в сканер необходимо вызвать метод write\_params.

#### Параметры:

- param\_name Имя (ключ) параметра.
- value Новое значение параметра

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief set_param - Set parameter
 * @param name Name of parameter
* @param value Value to set
* @return true on success, else - false
template<typename T>
bool set_param(std::string name, T value);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <vector>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
  sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      scanners[i]->read_params();
      // Set parameter of Device Name
      scanner->set_param("user_general_deviceName", "RF627 New Name");
      // Set parameter of Sensor Framerate
      scanner->set_param("user_sensor_framerate", 100);
      // Set parameter of Device IP Addr
      std::vector<uint32_t> ip {192, 168, 1, 31};
      scanner->set_param("user_network_ip", ip);
      // some actions with other parameters...
   // some code...
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X

#### Firmware Cloud

## set\_param\_by\_key

**Прототип:** bool set\_param\_by\_key(std::string name, std::string key);

**Описание:** Метод установки конкретного параметра по ключу. При вызове данного метода происходит установка параметра в списке параметров во внутренней памяти SDK. Для отправки изменений в сканер необходимо вызвать метод write\_params.

## Параметры:

- param\_name Имя (ключ) параметра.
- кеу Ключ (епит) параметра

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief set_param_by_key - Set parameter from Enum
* @param name Name of parameter
* @param key Key to set
 * @return true on success, else - false
* /
bool set_param_by_key(std::string name, std::string key);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
  sdk_init();
  // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      scanners[i]->read_params();
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

## write\_params

**Прототип:** bool write\_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод передачи параметров из внутренней памяти SDK в сканер. При вызове данного метода происходит отправка изменённых параметров в сканер

### Параметры:

• protocol - Тип протокола, по которому будут отправлена команда на установку параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
   sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
   for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      scanners[i]->read_params();
      // Set parameter of Device Name
      scanner->set_param("user_general_deviceName", "RF627 New Name");
      // Sen parameter of Sensor Framerate
      scanner->set_param("user_sensor_framerate", 100);
      // some actions with other parameters...
      // Apply changed parameters to the device
      bool isApplied = scanner->write_params();
      if (isApplied)
         std::cout << "Scanner parameters were applied successfully!";</pre>
      else
         std::cout << "Scanner parameters were not applied!";</pre>
   // some code...
```

#### save\_params

**Прототип:** bool save params(PROTOCOLS protocol = PROTOCOLS::CURRENT);

**Описание:** Метод сохранения параметров сканер во внутреннюю память устройства. Сохраненные параметры также будут использоваться после перезапуске устройства или после смены(обновления) прошивки.

#### Параметры:

• protocol - Тип протокола, по которому будет отправлена команда сохранения параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
    * @brief save_params - Save changes to device's memory
```

```
* @details The saved parameters will also be used if the device
 * is restarted or even if the firmware is updated.
* @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return true on success, else - false
* /
bool save_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
   sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
   for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      scanners[i]->read_params();
      // After changing some parameters...
      // Apply changed parameters to the device
      scanner->write_params();
      // Save current parameters in the device memory
      bool isSaved = scanner->save_params();
      if (isSaved)
         std::cout << "Scanner parameters saved successfully!";</pre>
         std::cout << "Scanner parameters were not saved!";</pre>
   // some code...
```

## load recovery params

**Прототип**: bool load\_recovery\_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);

Описание: Метод загрузки значений параметров устройства из области восстановления. Загруженные значения будут записаны в пользовательскую область

## Параметры:

• protocol - Тип протокола, по которому будет отправлена команда на восстановление параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief load_recovery_params - Loading parameters from recovery area
* @details The device will automatically reboot.
 * @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return true on success, else - false
bool load_recovery_params(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
   sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared ptr<rf627smart>> scanners = rf627smart::search();
   for (size_t i = 0; i < scanners.size(); i++)</pre>
   {
      scanners[i]->connect();
      // Load parameters from recovery area
      bool isLoaded = scanner->load_recovery_params();
      if (isLoaded)
         std::cout << "Recovery parameters loaded successfully!";</pre>
      else
         std::cout << "Recovery parameters were not loaded!";</pre>
   // some code...
```

# start\_dump\_recording

**Прототип**: bool start\_dump\_recording(uint32\_t count\_of\_profiles = 0);

Описание: Метод включения записи профилей во внутреннюю память устройства запуск записи дампа. Запись остановится, когда количество записанных профилей превысит максимально допустимый размер дампа, или когда будет превышено количество переданного в метод параметра count\_of\_profiles, или когда будет вызван метод остановки записи stop dump recording.

## Параметры:

• count of profiles - Количество профилей для записи дампа

Возвращаемое значение: true если запись началась успешно, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief start_dump_recording - enabling profile recording to the internal
* memory of the device - generating a dump.
* @details Recording will stop when the number of recorded profiles exceeds
* the maximum allowed dump size, or when the count_of_profiles number is
* exceeded, or when the stop_dump_recording method is called.
* @param count_of_profiles The number of profiles to record the dump:
* if count_of_profiles == 0 - Recording will continue until the maximum
* dump size is reached, or until recording is stopped by calling
* the stop dump recording method;
* if count of profiles > 0 - Recording will continue until the number
* of recorded profiles exceeds the specified number.
 * @return true if recording started successfully, else - false
bool start_dump_recording(uint32_t count_of_profiles = 0);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk init();
  // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
  {
     scanners[i]->connect();
      // Start dump recording
     uint32_t count_of_profiles = 1000;
```

```
bool isStarted = scanners[i]->start_dump_recording(count_of_profiles);
if (isStarted)
    std::cout << "Dump recording started...";
else
    std::cout << "Dump recording failed!";

// Next steps in stop_dump_recording example...
}
</pre>
```

## stop\_dump\_recording

**Прототип:** bool stop\_dump\_recording(uint32\_t& count\_of\_profiles);

**Описание:** Метод остановки записи профилей во внутреннюю память устройства - остановка записи дампа.

#### Параметры:

• count\_of\_profiles - Количество записанных профилей в дампе

Возвращаемое значение: true если запись остановлена успешно, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief stop_dump_recording - disabling profile recording to the internal
* memory of the device.
* @param count_of_profiles The number of recorded profiles
 * @return true if recording was stopped successfully, else - false
bool stop_dump_recording(uint32_t& count_of_profiles);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <chrono>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
```

```
for (size_t i = 0; i < scanners.size(); i++)
{
    scanners[i]->connect();

    // Start dump recording
    scanners[i]->start_dump_recording();

    // Waiting 1 sec
    std::this_thread::sleep_for(std::chrono::seconds(1));

    // Stop dump recording
    uint32_t count_of_profiles = 0;
    bool isStopped = scanners[i]->stop_dump_recording(count_of_profiles);
    if (isStopped)
        std::cout << "Current profiles in dump: " << count_of_profiles;
    else
        std::cout << "Failed to stop dump recording!";

    // Next steps in get_dumps_profiles example...
}
</pre>
```

## get\_dumps\_profiles

Прототип: std::vector<std::shared\_ptr<pre>profile2D>> get\_dumps\_profiles(uint32\_t index, uint32\_t count, uint32\_t timeout = 10000);

Описание: Метод скачивания дампа из внутренней памяти устройства

# Параметры:

- index Начальный номер запрашиваемого профиля из дампа
- count Количество скачиваемых профилей относительно начального номера index
- timeout Время ожидания скачивания дампа.

Возвращаемое значение: Вектор профилей

## Пример в коде:

```
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
   sdk init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
   for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      // Start dump recording
      uint32_t count_of_profiles = 1000;
      scanners[i]->start_dump_recording(count_of_profiles);
      // Print information about the current dump size
      uint32_t size = 0;
      do {
         scanners[i]->read_params();
         size =scanners[i]->get_param("user_dump_size")->getValue<uint32_t>();
         std::cout << "Current profiles in the dump: " << size << std::endl;</pre>
      }while(size < count of profiles);</pre>
      std::vector<std::shared_ptr<pre>cprofile2D>> dump =
               list[i]->get_dumps_profiles(0, count_of_profiles);
      std::cout << dump.size() << " Profiles were received! " << std::endl;</pre>
      // Next steps with dumps...
   }
```

### start\_profile\_capturing

Прототип: std::vector<std::shared\_ptr<pre>profile2D>> get\_dumps\_profiles(uint32\_t index, uint32\_t count, uint32\_t timeout = 10000);

Описание: Метод начала выполнения измерений. Используется только в режиме запуска программного измерения (параметр user\_sensor\_syncSource = "SYNC\_SOFTWARE" или user\_sensor\_syncSource = "SYNC\_SOFTWARE\_EXT"). При получении команды устройство запускает цикл измерения, после чего выполняется расчет и отправляется стандартный пакет с профилем

В режиме «программного измерения» метод  $get\_profile2D$  должен использоваться с параметром realtime = false , чтобы избежать потери запрашиваемых профилей.

#### Параметры:

• count\_of\_profiles - Количество запрашиваемых измерений.

Возвращаемое значение: true если измерения запущены успешно, иначе - false

# Пример в коде:

```
/** @file rf62Xsdk.h */
/**
* @brief start_profile_capturing - Command to start profiles measuring.
* @details This command is used only in the "software measurement" mode:
* when parameter "user_sensor_syncSource" == "SYNC_SOFTWARE"
 * or "SYNC_SOFTWARE_EXT". Device starts a measurement cycle immediately
 * after receiving this command.
 * ! In "software measurement" mode the get_profile2D method must be used
 * with the realtime == false argument to avoid loss of requested profiles.
 * @param count_of_profiles The count of measurements
* @return true if measuring was started successfully, else - false
bool start_profile_capturing(uint32_t count_of_profiles = 0);
/** @file main.cpp */
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk init();
  // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      // Select SYNC_SOFTWARE measurement mode
      scanners[i]->set_param_by_key("user_sensor_syncSource", "SYNC_SOFTWARE
\hookrightarrow ");
      // Start profile capturing
      uint32_t count_of_profiles = 1000;
      scanners[i]->start_profile_capturing(count_of_profiles);
```

## reboot device

**Прототип:** bool reboot\_device(PROTOCOLS protocol = PROTOCOLS::CURRENT)

Описание: Метод перезагрузки устройства

### Параметры:

• protocol - Тип протокола, по которому будет отправлена команда на перезагрузку устройства (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

# Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief reboot device - The scanner will restart
* @param protocol Protocol's type (Service Protocol, ENIP, Modbus-TCP)
 * @return true on success, else - false
bool reboot_device(PROTOCOLS protocol = PROTOCOLS::CURRENT);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <chrono>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
  sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
```

```
for (size_t i = 0; i < scanners.size(); i++)
{
    scanners[i]->connect();

    // Start device reboot
    scanners[i]->reboot_device();

    // Waiting 10 sec
    std::this_thread::sleep_for(std::chrono::seconds(10));

    bool isAvailable = scanners[i]->check_connection();
    if (isAvailable) {
        std::cout << "Scanner has been successfully restarted" << std::endl;
    }

    // some other actions with scanner...
}
</pre>
```

# reboot\_sensor

**Прототип:** bool reboot sensor(PROTOCOLS protocol = PROTOCOLS::CURRENT)

**Описание:** Метод переинициализация СМОS-сенсора устройства, необходимо использовать, если сенсор «завис» при воздействии внешней помехи.

## Параметры:

• protocol - Тип протокола, по которому будет отправлена команда на переинициализацию CMOS-сенсора устройства (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
{
    // Initialize sdk library
    sdk_init();
    // Search for rf627smart devices over network
    std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
    for (size_t i = 0; i < scanners.size(); i++)
    {
        scanners[i]->connect();
        // Reboot CMOS-sensor
        scanners[i]->reboot_sensor();
        // Waiting 100 milliseconds
        std::this_thread::sleep_for(std::chrono::milliseconds(100));
        // some other actions with scanner...
    }
}
```

#### send to periphery

Прототип: bool send\_to\_periphery(std::string iface\_name, std::vector<char> in, std::vector<char>& out, uint32\_t timeout)

Описание: Метод отправки данных к периферийному устройству. Под периферией понимаются «внешние» по отношению к сканеру устройства, например: драйверы шаговых двигателей, пневматические клапаны, устройства термостатирования и т.д. Периферия подключается по стандартным интерфейсам, например USART, I2C и т.д. Команды работы с периферией обеспечивают «прозрачный» обмен, не добавляя и не убирая никаких данных.

## Параметры:

- iface\_name Имя интерфейса, на который будут отправляться данные. Если интерфейс не существует, будет возвращена ошибка «RF\_WRONG\_ARGUMENT». Поддерживаемые значения: «Usart0» - отправка на периферию, подключенную через USART0.
- in Данные для отправки. Если данных для отправки нет, будет возвращена ошибка «RF\_NO\_DATA». Ограничение длины: 1024 байта. Если длина данных превышает лимит, будет возвращена ошибка «RF\_OUT\_OF\_BOUNDS».
- out Данные, которые были получены.
- timeout Таймаут ответа в мс. Если таймаут равен 0, будут возвращены данные, уже находящиеся в буфере устройства.

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/** @file rf62Xsdk.h */
* @brief send_to_periphery - sending data to a peripheral device.
* @details Peripherals are devices "external" to the scanner,
* for example: stepper motors, pneumatic valves, thermostats, etc.
 * Peripherals are connected via standard interfaces such as USART,
 * I2C, etc. Peripheral commands provide transparent exchange without
 * adding or removing any data.
* @param iface_name The name of the interface where the
* data will be sent. If the interface does not exist,
* the error "RF_WRONG_ARGUMENT" will be returned.
* Supported values:
 * "Usart0" - sending to the peripherals connected via the USART0.
 * @param in The data to be sent. If there is no data to send,
 * then the error "RF_NO_DATA" will be returned.
 * Length limit: 1024 bytes. If the data length is greater than
 * the limit, the error "RF_OUT_OF_BOUNDS" will be returned.
 * @param out The data that was received.
 * @param timeout Response timeout in ms. If the timeout is 0,
* the data already in the device buffer will be returned.
* @return true on success, else - false
bool send_to_periphery(
        std::string iface_name, std::vector<char> in,
        std::vector<char>& out, uint32_t timeout);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <chrono>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
  // Initialize sdk library
  sdk init();
  // Search for rf627smart devices over network
  std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
  for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      // Send data to periphery
      std::vector<char> in {'H', 'E', 'L', 'L', 'O'};
      std::vector<char> out;
```

```
bool isSent = scanners[i]->send_to_periphery("Usart0", in, out, 1000);
if (isSent) {
    std::cout << "The data was sent successfully." << std::endl;
    std::cout << "Size of received data: " << out.size() << std::endl;
}
// some other actions with scanner...
}
</pre>
```

#### receive\_from\_periphery

Прототип: bool receive\_from\_periphery(std::string iface\_name, uint16\_t count, std::vector<char>& out, uint32\_t timeout)

Описание: Метод приема данных от периферийного устройства.

#### Параметры:

- iface\_name Имя интерфейса с которого будут прочитаны данные. Если интерфейс не существует, будет возвращена ошибка «RF\_WRONG\_ARGUMENT». Поддерживаемые значения: «Usart0» получение с периферии, подключенную через USART0.
- count Количество байт, которые ожидается принять. Если count равен
  0, то будет возвращена ошибка «RF\_NO\_DATA». Ограничение длины: 1024
  байта. Если длина данных для разового получения превышает лимит, будет
  возвращена ошибка «RF\_OUT\_OF\_BOUNDS».
- out Данные, которые были получены.
- timeout Таймаут ответа в мс. Если требуемое количество байт не было принято по истечении данного времени, то будет возвращено принятое количество байт. Если таймаут равен 0, будут возвращены данные, уже находящиеся в буфере устройства.

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/** @file rf62Xsdk.h */

/**

* @brief receive_from_periphery - receiving data from a

* peripheral device

*

* @param iface_name The name of the interface from which the data

* will be received. If the interface does not exist, the error

* "RF_WRONG_ARGUMENT" will be returned.

* Supported values:

* "Usart0" - sending to the peripherals connected via the USART0.

* @param count The number of bytes expected to be received

* @param out The data that was received.

* @param timeout Response timeout in ms. If the requested number of

* bytes is not received after this time, will be returned current
```

```
* number of bytes.
 * @return true on success, else - false
bool receive_from_periphery(
        std::string iface_name, uint16_t count,
        std::vector<char>& out, uint32_t timeout);
/** @file main.cpp */
#include <string>
#include <iostream>
#include <chrono>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
int main()
   // Initialize sdk library
  sdk_init();
   // Search for rf627smart devices over network
   std::vector<std::shared_ptr<rf627smart>> scanners = rf627smart::search();
   for (size_t i = 0; i < scanners.size(); i++)</pre>
      scanners[i]->connect();
      // Receive data from periphery
      std::vector<char> out;
      scanners[i]->receive from periphery("Usart0", 512, out, 1000);
      std::cout << "Size of received data: " << out.size() << std::endl;</pre>
      // some other actions with scanner...
   }
```

# 4.3 Интерфейс «обёртки» на С#

Эта «обёртка» представляет собой библиотеку .NET, написанную на языке C#, которая позволяет упростить разработку приложений на языках C#, Visual Basic .NET, C++/CLI и JScript .NET

Для её использования в проектах .NET разработчику необходимо собрать или скачать динамическую программную библиотеку RF62X-SDK.dll, после чего подключить библиотеку в проект (Project > Add References), а также добавить дополнительные зависимости в каталог к исполняемому файлу проекта.

Для скачивания библиотеки см. Последние выпуски RF62X-SDK библиотек. Для компиляции библиотеки из исходников см. *Компиляция «обёртки» на С#*. Для использования в проектах см. *Создание проекта С#*.

#### 4.3.1 Инициализация SDK

Файл RF62X-SDK.cs является основным файлом программного интерфейса (API) и определяет функциональность библиотеки-«обёртки». RF62X-TYPES.cs содержит дополнительный набор классов, структур, типов и перечислений используемых в SDK.

#### **SdkInit**

Прототип: bool SdkInit();

**Описание:** Функция инициализации SDK. Должна быть вызвана один раз перед дальнейшими вызовами любых библиотечных функций

**Возвращаемое значение:** После успешного завершения возвращается true. В противном случае должен быть возвращен false.

# Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// SdkInit - Initialize sdk library
/// </summary>
/// <remarks>
/// Must be called once before further calls to any library functions
/// </remarks>
/// <returns>true if success.</returns>
public static bool SdkInit();
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         bool isInit = RF62X.SdkInit();
         if (isInit)
            Console.WriteLine("SDK version: {0}", RF62X.SdkVersion());
         else
```

```
Console.WriteLine("SDK initialization error!");
}

// some code...
}
}
```

# **SdkCleanup**

Прототип: void SdkCleanup();

Описание: Функция высвобождает ресурсы, выделенные при инициализации СДК функцией SdkInit

# Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// SdkCleanup - Cleanup resources allocated with sdk_init() function
/// </summary>
public static void SdkCleanup();
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         bool isInit = RF62X.SdkInit();
         if (isInit)
            Console.WriteLine("SDK version: {0}", RF62X.SdkVersion());
         else
         {
            Console.WriteLine("SDK initialization error!");
         // some code...
         // Cleanup resources
         SdkCleanup();
      }
   }
```

#### **SdkVersion**

Прототип: string SdkVersion();

Описание: Функция получения информации о версии SDK

Возвращаемое значение: версия SDK в формате X.Y.Z (мажорная, минорная, патч)

### Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// SdkCleanup - Cleanup resources allocated with sdk_init() function
/// </summary>
public static void SdkCleanup();
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         bool isInit = RF62X.SdkInit();
         if (isInit)
            Console.WriteLine("SDK version: {0}", RF62X.SdkVersion());
         else
         {
            Console.WriteLine("SDK initialization error!");
         }
         // some code...
         // Cleanup resources
         RF62X.SdkCleanup();
      }
   }
```

# 4.3.2 Класс rf627smart

Данный класс определён в файле RF62X-SDK.cs и предоставляет интерфейс для работы со сканерами серии RF627 v2.x.x

### Search

**Прототип:** static List<RF627smart> Search(uint timeout = 300, PROTOCOL\_TYPES protocol = PROTOCOL\_TYPES.SERVICE);

Описание: Метод поиска устройств RF62X v2.x.x в сети

# Параметры:

- timeout Время поиска на каждом Ethernet интерфейсе (мс).
- protocol Тип протокола, по которому будет осуществляться поиск (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: \*Список обнаруженных в сети сканеров серии RF627 v2.x.x.

### Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// Search for RF627smart devices over network
/// </summary>
/// <param name="timeout">Search timeout for each Ethernet interface</param>
/// <param name="protocol">Protocol's type</param>
/// <returns>List of RF627smart devices</returns>
static List<RF627smart> Search(
     uint timeout = 300, PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE);
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
     static void Main(string[] args)
        // Initialize sdk library
        RF62X.SdkInit();
         // Search for RF627smart devices over network
        List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         // Print count of discovered rf627smart in network
        Console.WriteLine("Was found\t: {0} RF627-Smart", list.Count);
        Console.WriteLine("=========");
         // some code...
         // Cleanup resources allocated with SdkInit()
        RF62X.SdkCleanup();
```

```
}
```

#### GetInfo

Прототип: HelloInfo GetInfo(PROTOCOL\_TYPES protocol = PROTOCOL\_TYPES.SERVICE);

**Описание:** Метод получения информации о сканере из пакета приветствия (Helloпакет)

# Параметры:

 protocol - Тип протокола, по которому будет осуществляться поиск (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: HelloInfo в случае успеха

### Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// Get information about scanner from hello packet
/// </summary>
/// <param name="protocol">protocol's type</param>
/// <returns>Hello_info on success</returns>
HelloInfo GetInfo(PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE);
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)</pre>
            RF62X.HelloInfo info = list[i].GetInfo();
            Console.WriteLine("\n\nID scanner's list: {0}", i);
            Console.WriteLine("-----
            Console.WriteLine("Device information: ");
```

```
Console.WriteLine("* Name\t: {0}", info.device_name);
        Console.WriteLine("* Serial\t: {0}", info.serial_number);
        Console.WriteLine("* IP Addr\t: {0}", info.ip_address);
        Console.WriteLine("* MAC Addr\t: {0}", info.mac_address);
        Console.WriteLine("\nWorking ranges: ");
        Console.WriteLine("* Zsmr, mm\t: {0}", info.z_smr);
        Console.WriteLine("* Zmr , mm\t: {0}", info.z_mr);
        Console.WriteLine("* Xsmr, mm\t: {0}", info.x_smr);
        Console.WriteLine("* Xemr, mm\t: {0}", info.x_emr);
        Console.WriteLine("\nVersions: ");
        Console.WriteLine("* Firmware\t: {0}", info.firmware_version);
        Console.WriteLine("* Hardware\t: {0}", info.hardware_version);
        Console.WriteLine("-----
     }
  }
}
```

#### Connect

Прототип: bool Connect(PROTOCOL TYPES protocol = PROTOCOL TYPES.SERVICE);

Описание: Метод установки соединения со сканером

# Параметры:

• protocol - Тип протокола, по которому будет выполнено подключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

### Пример в коде:

```
static void Main(string[] args)
{
    // Initialize sdk library
    RF62X.SdkInit();

    // Search for RF627smart devices over network
    List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);

    for (int i = 0; i < list.Count; i++)
    {
        // Establish connection to the RF627 device.
        bool isConnected = list[i].Connect();
        if (!isConnected) {
            Console.WriteLine("Failed to connect to scanner!");
            continue;
        }
        // some actions with scanner...
    }
}</pre>
```

#### **Disconnect**

Прототип: bool Disconnect(PROTOCOL\_TYPES protocol = PROTOCOL\_TYPES.SERVICE);

Описание: Метод закрытия ранее установленного соединения со сканером

### Параметры:

• protocol - Тип протокола, по которому будет выполнено отключение (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

## Пример в коде:

```
/// <file> RF62X-SDK.cs

/// <summary>
/// Close connection to the device
/// </summary>
/// <param name="protocol">protocol's type</param>
/// <returns>true on success</returns>
bool Disconnect(PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE)

/// <file> Program.cs

using System;
using System.Collections.Generic;
using System.Threading;
using SDK.SCANNERS;

namespace EXAMPLE
```

```
class Program
   static void Main(string[] args)
      // Initialize sdk library
      RF62X.SdkInit();
      // Search for RF627smart devices over network
      List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
      for (int i = 0; i < list.Count; i++)</pre>
         // Establish connection to the RF627 device.
         bool isConnected = list[i].Connect();
         if (!isConnected) {
            Console.WriteLine("Failed to connect to scanner!");
            continue;
         // some actions with scanner...
         // Disconnect from scanner.
         list[i].Disconnect();
      }
   }
}
```

### CheckConnection

Прототип: bool CheckConnection(uint timeout = 300, PROTOCOL\_TYPES protocol = PROTOCOL TYPES.SERVICE);

Описание: Метод проверки доступности сканера в сети (после подключения к нему)

## Параметры:

- timeout Время проверки соединения со сканером (мс).
- protocol Тип протокола, по которому будет выполнена проверка (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

### Пример в коде:

```
/// <file> RF62X-SDK.cs

/// <summary>
/// Check connection with RF627smart device
/// </summary>
/// <param name="timeout">Connection check timeout</param>
/// <param name="protocol">Protocol's type</param>
/// <returns>true on success</returns>
bool CheckConnection(
    uint timeout = 300, PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE);
```

```
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
   class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)</pre>
            // Establish connection to the RF627 device.
            bool isConnected = list[i].Connect();
            if (!isConnected) {
               Console.WriteLine("Failed to connect to scanner!");
               continue;
            }
            // Check connection with device
            bool isAvailable = list[i].CheckConnection(500);
            if (!isAvailable) {
               Console.WriteLine("Scanner is not available now.");
               Console.WriteLine("Please call back later!");
               continue;
            }
            // some actions with scanner...
         }
      }
   }
```

### **GetProfile**

Прототип: Profile2D GetProfile(bool zero\_points = true, bool realtime = true, PROTOCOL\_TYPES protocol = PROTOCOL\_TYPES.SERVICE);

Описание: Метод получения результатов измерений

#### Параметры:

- zero\_points Включать нулевые точки в возвращаемом профиле.
- realtime Получение профиля в реальном времени (буферизация отключена).

• protocol - Тип протокола, по которому будет получен профиль (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: Profile2D при успехе, иначе - null

### Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// Get 2D measurement from scanner's data stream
/// </summary>
/// <param name="zero_points">include zero points in return Profile</param>
/// <param name="realtime">Enable getting profile in real time</param>
/// <param name="protocol">protocol's type</param>
/// <returns>Profile</returns>
Profile2D GetProfile(
      bool zero_points = true, bool realtime = true,
      PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE);
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)</pre>
            // Establish connection to the RF627 device.
            list[i].Connect();
            // Get profile from scanner's data stream by Service Protocol.
            RF62X.Profile2D profile = null;
            bool zero_points = true;
            bool realtime = true;
            // Get profile from scanner
            profile = list[i].GetProfile(zero_points, realtime);
            if (profile != null) {
               Console.WriteLine("Profile was successfully received!");
            }else
               Console.WriteLine("Profile was not received!");
         }
```

```
}
```

#### **GetFrame**

Прототип: Frame GetFrame(PROTOCOL\_TYPES protocol = PROTOCOL\_TYPES.SERVICE);

Описание: Метод получения кадров видео с матрицы сканера

### Параметры:

• protocol - Тип протокола, по которому будет получен кадр (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: Frame при успехе, иначе - null

# Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// Get RAW frame from scanner
/// </summary>
/// <param name="protocol">protocol's type</param>
/// <returns>Frame</returns>
Frame GetFrame(PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE);
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)
            // Establish connection to the RF627 device.
            list[i].Connect();
            // Get Frame from scanner.
            RF62X.Frame frame = list[i].GetFrame();
            if (frame != null) {
               Console.WriteLine("Frame was successfully received!");
```

#### **ReadParams**

Прототип: bool ReadParams(PROTOCOL\_TYPES protocol = PROTOCOL\_TYPES.SERVICE);

**Описание:** Метод получения текущих параметров сканера. При вызове данного метода SDK вычитывает со сканера все актуальные параметры, сохраняя их в виде «списка параметров» для дальнейшей работы во внутренней памяти SDK.

# Параметры:

• protocol - Тип протокола, по которому будут прочитаны параметры (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

# Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summarv>
/// Read parameters from device to internal structure.
/// </summary>
/// <param name="protocol">protocol's type</param>
/// <returns>true on success</returns>
bool ReadParams (PROTOCOL TYPES protocol = PROTOCOL TYPES.SERVICE)
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
   class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)</pre>
```

```
// Establish connection to the RF627 device.
list[i].Connect();

// Read params from RF627 device.
bool isRead = list[i].ReadParams();
if (isRead) {
    Console.WriteLine("Scanner parameters were read!");
}else
    Console.WriteLine("Scanner parameters were not read!");
}
}
}
```

#### **GetParam**

**Прототип:** dynamic GetParam(string nameKey);

**Описание:** Метод получения конкретного параметра по его имени (ключу). При вызове данного метода SDK осуществляет поиск нужного параметра из последних прочитанных при вызове метода ReadParams . В случае, если запрашиваемый параметр отсутствует в конкретном сканере, функция вернёт null.

## Параметры:

• param\_name - Имя (ключ) параметра.

Возвращаемое значение: Parameter при успехе, иначе - null

#### Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// Search parameters by his name
/// </summary>
/// <param name="nameKey">name of parameter</param>
/// <returns>param on success, else - null</returns>
dynamic GetParam(string nameKey);
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System.Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
```

```
RF62X.SdkInit();
      // Search for RF627smart devices over network
      List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
      for (int i = 0; i < list.Count; i++)</pre>
         // Establish connection to the RF627 device.
         list[i].Connect();
         // Read params from RF627 device.
         list[i].ReadParams();
         RF62X.Parameter<string> name =
               list[i].GetParam("user_general_deviceName");
         if (name != null) {
            string str_name = name.GetValue();
            Console.WriteLine("Current Device Name \t: {0}", str_name);
         RF62X.Parameter<uint> framerate =
               list[i].GetParam("user_sensor_framerate");
         if (framerate != null) {
            uint framerate_value = framerate.GetValue();
            Console.WriteLine("Current FPS\t: {0}", framerate_value);
   }
}
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

#### **SetParam**

**Прототип:** bool SetParam(string name, dynamic value);

**Описание:** Метод установки конкретного параметра. При вызове данного метода происходит установка параметра в списке параметров во внутренней памяти SDK.\* Для отправки изменений в сканер необходимо вызвать метод WriteParams.

# Параметры:

- param\_name Имя (ключ) параметра.
- value \*- Новое значение параметра

Возвращаемое значение: true при успехе, иначе - false

# Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
```

```
/// Set parameter by name
/// </summary>
/// <param name="param">Name of parameter</param>
/// <param name="value">Value to set</param>
/// <returns>true on success, else - false</returns>
bool SetParam(string name, dynamic value)
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)</pre>
            // Establish connection to the RF627 device.
            list[i].Connect();
            // Read params from RF627 device.
            list[i].ReadParams();
            // Set parameter of Device Name
            list[i].SetParam("user_general_deviceName", "RF627 New Name");
            // Set parameter of Sensor Framerate
            list[i].SetParam("user_sensor_framerate", 100);
            // some actions with other parameters...
         }
      }
  }
```

**Примечание:** Для более детального описания каждого параметра и его свойств см. RF62X Firmware Cloud

#### **WriteParams**

Прототип: bool WriteParams(PROTOCOL TYPES protocol = PROTOCOL TYPES.SERVICE);

**Описание:** Метод передачи параметров из внутренней памяти SDK в сканер. При вызове данного метода происходит отправка изменённых параметров в сканер

## Параметры:

• protocol - Тип протокола, по которому будут отправлена команда на установку параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

#### Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// Send current parameters to device
/// </summary>
/// <param name="protocol">protocol's type</param>
/// <returns>true on success</returns>
bool WriteParams (PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE)
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System. Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)</pre>
            list[i].Connect();
            list[i].ReadParams();
            // Set parameter of Device Name
            list[i].SetParam("user_general_deviceName", "RF627 New Name");
            // Set parameter of Sensor Framerate
            list[i].SetParam("user_sensor_framerate", 100);
            // some actions with other parameters...
            // Apply changed parameters to the device
```

```
bool isApplied = list[i].WriteParams();
    if (isApplied)
        Console.WriteLine("Scanner parameters were applied!");
    else
        Console.WriteLine("Scanner parameters were not applied!");
}
}
}
```

#### **SaveParams**

Прототип: bool SaveParams(PROTOCOL TYPES protocol = PROTOCOL TYPES.SERVICE);

**Описание:** Метод сохранения параметров сканер во внутреннюю память устройства. Сохраненные параметры также будут использоваться после перезапуске устройства или после смены(обновления) прошивки.

# Параметры:

• protocol - Тип протокола, по которому будут отправлена команда на установку параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

# Пример в коде:

```
/// <file> RF62X-SDK.cs
/// <summary>
/// Save changes to device's memory.
/// The saved parameters will also be used if the device
/// is restarted or even if the firmware is updated.
/// </summary>
/// <param name="protocol">protocol's type</param>
/// <returns>true on success</returns>
bool SaveParams(PROTOCOL_TYPES protocol = PROTOCOL_TYPES.SERVICE);
/// <file> Program.cs
using System;
using System.Collections.Generic;
using System.Threading;
using SDK.SCANNERS;
namespace EXAMPLE
  class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
```

```
// Search for RF627smart devices over network
      List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
      for (int i = 0; i < list.Count; i++)</pre>
         list[i].Connect();
         list[i].ReadParams();
         // After changing some parameters...
         // Apply changed parameters to the device
         list[i].WriteParams();
         // Save current parameters in the device memory
         bool isSaved = list[i].SaveParams();
         if (isSaved)
            Console.WriteLine("Scanner parameters were applied!");
         else
            Console.WriteLine("Scanner parameters were not applied!");
   }
}
```

# LoadRecoveryParams

Прототип: bool SaveParams(PROTOCOL\_TYPES protocol = PROTOCOL\_TYPES.SERVICE);

**Описание:** Метод загрузки значений параметров устройства из области восстановления. Загруженные значения будут записаны в пользовательскую область

### Параметры:

• protocol - Тип протокола, по которому будут отправлена команда на установку параметров (Service Protocol, ENIP, Modbus-TCP)

Возвращаемое значение: true при успехе, иначе - false

### Пример в коде:

```
using System.Collections.Generic;
using System.Threading;
using SDK.SCANNERS;
namespace EXAMPLE
{
   class Program
      static void Main(string[] args)
         // Initialize sdk library
         RF62X.SdkInit();
         // Search for RF627smart devices over network
         List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
         for (int i = 0; i < list.Count; i++)</pre>
            list[i].Connect();
            // Load parameters from recovery area
            bool isLoaded = list[i].LoadRecoveryParams();
            if (isLoaded)
               Console.WriteLine("Recovery parameters loaded successfully!");
            else
               Console.WriteLine("Recovery parameters were not loaded!");
      }
  }
```

Примеры использования

# 5.1 Примеры для С

# 5.1.1 Поиск устройств RF62X

Ниже приведен пример поиска сканеров серии RF627 v2.x.x:

```
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X_types.h"
int main()
  printf("##############################");
  printf("#
  printf("#
                  Search Example v2.x.x
                                               #\n");
  printf("#
  printf("###############################;\n");
  // Initialize sdk library
  core_init();
  // Print return rf627 sdk version
  printf("SDK version: %s\n", sdk_version());
  printf("========n");
  // Create value for scanners vector's type
  vector_t* scanners = (vector_t*)calloc(1, sizeof (vector_t));
  // Initialization vector
  vector_init(&scanners);
```

```
// Iterate over all available network adapters in the current operating
// system to send "Hello" requests.
uint32_t count = 0;
for (int i=0; i<GetAdaptersCount(); i++)</pre>
  uint32_t host_ip_addr = ntohl(inet_addr(GetAdapterAddress(i)));
  uint32_t host_mask = ntohl(inet_addr(GetAdapterMasks(i)));
   // call the function to change adapter settings inside the library.
   set_platform_adapter_settings(host_mask, host_ip_addr);
   // Search for rf627old devices over network by Service Protocol.
   if (host_ip_addr != 0)
      // Get another IP Addr and set this changes in adapter settings.
      printf("Search scanners from:\n "
           "* IP Address\t: %s\n "
           "* Netmask\t: %s\n",
           GetAdapterAddress(i), GetAdapterMasks(i));
      search_scanners(scanners, kRF627_SMART, 300, kSERVICE);
      // Print count of discovered rf627old in network
      printf("Discovered\t: %d RF627\n",(int)vector_count(scanners)-count);
      printf("----\n");
     count = (int) vector_count (scanners);
  }
}
// Print count of discovered rf627smart in network
printf("Was found\t: %d RF627 v2.x.x", (int)vector_count(scanners));
for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
   hello_information result =
           get info about scanner(vector get(scanners,i), kSERVICE);
   rf627_smart_hello_info_by_service_protocol* info =
           result.rf627smart.hello_info_service_protocol;
  printf("\n\nID scanner in list: %d\n", i);
  printf("----\n");
   printf("Device information: \n");
  printf("* Name \t: %s\n", info->user_general_deviceName);
  printf("* Serial\t: %d\n", info->fact_general_serial);
   printf("* IP Addr\t: %s\n", info->user_network_ip);
   printf("* MAC Addr\t: %s\n", info->fact_network_macAddr);
  printf("\nWorking ranges: \n");
   printf("* Zsmr, mm\t: %d\n", info->fact_general_smr);
   printf("* Zmr , mm\t: %d\n", info->fact_general_mr);
   printf("* Xsmr, mm\t: %d\n", info->fact_general_xsmr);
  printf("* Xemr, mm\t: %d\n", info->fact_general_xemr);
   printf("\nVersions: \n");
   printf("* Firmware\t: %d.%d.%d\n",
         info->fact_general_firmwareVer[0],
         info->fact_general_firmwareVer[1],
```

```
info->fact_general_firmwareVer[2]);
    printf("* Hardware\t: %d\n", info->fact_general_hardwareVer);
    printf("----\n");
}

core_cleanup();
}
```

Ниже приведён результат вывода приложения при успешном обнаружении сканера в сети:

```
#
#
        Search Example v2.x.x
SDK version: 2.17.2
_____
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered : 1 RF627
Search scanners from:
* IP Address : 192.168.2.104
* Netmask : 255.255.255.0
Discovered : 0 RF627
Was found : 1 RF627 v2.x.x
ID scanner in list: 0
_____
Device information:
* Name : RF627 scanner
* Serial : 190068
* IP Addr : 192.168.1.30
* MAC Addr
           : 00:0A:35:6E:07:F5
Working ranges:
* Zsmr, mm : 70
            : 50
* Zmr , mm
* Xsmr, mm
* Xemr, mm
            : 42
Versions:
           : 2.7.1
* Firmware
* Hardware : 302388224
Press <RETURN> to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью **Qt Creator**:

- Загрузите файл *CMakeLists.txt* из папки **Examples/C/RF627\_SMART/SEARCH\_EXAMPLE** через **File > Open File or Project** (укажите файл *CMakeLists.txt*)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

# 5.1.2 Получение профиля сканера

Ниже приведен пример получение профиля со сканера серии RF627 v2.x.x:

```
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X types.h"
int main()
  printf("########################;");
  printf("#
                                                 #\n");
  printf("#
                 Profile Example v2.x.x
                                                 \# \n");
  printf("#
                                                 #\n");
  printf("###############################");
  // Initialize sdk library
  core_init();
  // Print return rf627 sdk version
  printf("SDK version: %s\n", sdk_version());
  printf("=======\n");
  // Create value for scanners vector's type
  vector_t* scanners = (vector_t*)calloc(1, sizeof (vector_t));
  // Initialization vector
  vector_init(&scanners);
  // Iterate over all available network adapters in the current operating
  // system to send "Hello" requests.
  uint32_t count = 0;
  for (int i=0; i<GetAdaptersCount(); i++)</pre>
     uint32_t host_ip_addr = ntohl(inet_addr(GetAdapterAddress(i)));
     uint32_t host_mask = ntohl(inet_addr(GetAdapterMasks(i)));
     // call the function to change adapter settings inside the library.
     set_platform_adapter_settings(host_mask, host_ip_addr);
     // Search for rf627old devices over network by Service Protocol.
     if (host_ip_addr != 0)
     {
        // Get another IP Addr and set this changes in adapter settings.
        printf("Search scanners from:\n "
               "* IP Address\t: %s\n "
               "* Netmask\t: %s\n",
               GetAdapterAddress(i), GetAdapterMasks(i));
        search_scanners(scanners, kRF627_SMART, 300, kSERVICE);
        // Print count of discovered rf627old in network
        printf("Discovered\t: %d RF627\n",(int)vector_count(scanners)-count);
        printf("----\n");
        count = (int) vector_count (scanners);
```

```
}
// Print count of discovered rf627smart in network
printf("Was found\t: %d RF627 v2.x.x", (int)vector_count(scanners));
for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
   scanner_base_t* scanner = vector_get(scanners,i);
   hello_information _info = get_info_about_scanner(scanner, kSERVICE);
   rf627_smart_hello_info_by_service_protocol* info =
            _info.rf627smart.hello_info_service_protocol;
   printf("\n\nID scanner in list: %d\n", i);
   printf("-----
   printf("Device information: \n");
   printf("* Name\t\t: %s\n", info->user_general_deviceName);
   printf("* Serial\t: %d\n", info->fact_general_serial);
   printf("* IP Addr\t: %s\n", info->user_network_ip);
   // Establish connection to the RF627 device
   uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
   if (!is_connected)
     continue;
   // Read params from RF627 device
   uint8_t is_read = read_params_from_scanner(scanner, 3000, kSERVICE);
   if (!is_read)
     continue;
   uint8_t zero_points = TRUE;
   uint8_t realtime = TRUE;
   // Get profile from scanner's data stream by Service Protocol.
   rf627_profile2D_t* result = get_profile2D_from_scanner(
               scanner, zero_points, realtime, kSERVICE);
   rf627_smart_profile2D_t* profile2D = result->rf627smart_profile2D;
   if (profile2D != NULL)
     printf("Profile information: \n");
      switch (profile2D->header.data_type)
     case (int)DTY_PixelsNormal:
          printf("* DataType\t: PIXELS\n");
         uint32 t count = profile2D->pixels format.pixels count;
          printf("* Count\t\t: %d\n", count);
         break;
      case (int)DTY_PixelsInterpolated:
          printf("* DataType\t: PIXELS_INTRP\n");
          uint32_t count = profile2D->pixels_format.pixels_count;
          printf("* Count\t\t: %d\n", count);
          break;
```

```
case (int)DTY_ProfileNormal:
         printf("* DataType\t: PROFILE\n");
         uint32_t count = profile2D->profile_format.points_count;
         printf("* Count\t\t: %d\n", count);
        break;
     }
     case (int)DTY_ProfileInterpolated:
         printf("* DataType\t: PROFILE_INTRP\n");
         uint32_t count = profile2D->profile_format.points_count;
         printf("* Count\t\t: %d\n", count);
        break;
     }
     }
     printf("Profile was successfully received!\n");
     printf("----\n");
     free_profile2D(result);
  }else
     printf("Profile was not received!\n");
     printf("----\n");
  disconnect_from_scanner(scanner, kSERVICE);
// Cleanup resources allocated with core_init()
core_cleanup();
```

Ниже приведён результат вывода приложения при успешном получении профиля:

```
#
      Profile Example v2.x.x
SDK version: 2.17.2
_____
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered
          : 1 RF627
Search scanners from:
* IP Address : 192.168.2.104
* Netmask
Discovered
           : 255.255.255.0
          : 0 RF627
Was found
          : 1 RF627 v2.x.x
ID scanner in list: 0
Device information:
* Name : RF627 scanner 
* Serial : 190068
```

Вы можете открыть и скомпилировать этот пример с помощью **Qt Creator**:

- Загрузите файл CMakeLists.txt из папки Examples/C/RF627\_SMART/PROFILE\_EXAMPLE через File > Open File or Project (укажите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

# 5.1.3 Получение кадра матрицы

Ниже приведен пример получение кадра матрицы со сканера серии RF627 v2.x.x:

```
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X_types.h"
int main()
  printf("################################");
  printf("#
                                                #\n");
  printf("#
                  Frame Example v2.x.x
  printf("#
                                                #\n");
  printf("##############################");
  // Initialize sdk library
  core init();
  // Print return rf627 sdk version
  printf("SDK version: %s\n", sdk_version());
  printf("=======\n");
  // Create value for scanners vector's type
  vector_t* scanners = (vector_t*)calloc(1, sizeof (vector_t));
  // Initialization vector
  vector_init(&scanners);
  // Iterate over all available network adapters in the current operating
  // system to send "Hello" requests.
  uint32_t count = 0;
  for (int i=0; i<GetAdaptersCount(); i++)</pre>
   {
     uint32_t host_ip_addr = ntohl(inet_addr(GetAdapterAddress(i)));
```

```
uint32_t host_mask = ntohl(inet_addr(GetAdapterMasks(i)));
   // call the function to change adapter settings inside the library.
   set_platform_adapter_settings(host_mask, host_ip_addr);
   // Search for rf627old devices over network by Service Protocol.
   if (host_ip_addr != 0)
      // Get another IP Addr and set this changes in adapter settings.
     printf("Search scanners from:\n "
            "* IP Address\t: %s\n '
            "* Netmask\t: %s\n",
            GetAdapterAddress(i), GetAdapterMasks(i));
      search_scanners(scanners, kRF627_SMART, 300, kSERVICE);
      // Print count of discovered rf627old in network
      printf("Discovered\t: %d RF627\n",(int)vector_count(scanners)-count);
     printf("----\n");
     count = (int)vector_count(scanners);
// Print count of discovered rf627smart in network
printf("Was found\t: %d RF627 v2.x.x", (int)vector_count(scanners));
for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
   scanner_base_t* scanner = vector_get(scanners,i);
  hello_information _info = get_info_about_scanner(scanner, kSERVICE);
   rf627_smart_hello_info_by_service_protocol* info =
           _info.rf627smart.hello_info_service_protocol;
   printf("\n\nID scanner in list: %d\n", i);
  printf("----\n");
  printf("Device information: \n");
   printf("* Name\t\t: %s\n", info->user_general_deviceName);
  printf("* Serial\t: %d\n", info->fact_general_serial);
  printf("* IP Addr\t: %s\n", info->user_network_ip);
   // Establish connection to the RF627 device
   uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
  if (!is_connected)
     continue;
  // Read params from RF627 device
   uint8_t is_read = read_params_from_scanner(scanner, 3000, kSERVICE);
   if (!is_read)
      continue;
   rf627_frame_t* _frame = get_frame_from_scanner(scanner, kSERVICE);
   if (_frame != NULL && _frame->rf627smart_frame != NULL)
     uint32_t data_size = _frame->rf627smart_frame->data_size;
      uint32_t frame_width = _frame->rf627smart_frame->fact_sensor_width;
      uint32_t frame_height = _frame->rf627smart_frame->fact_sensor_height;
```

(continues on next page)

166

```
printf("Frame information: \n");
    printf("* Data Size\t: %d\n", data_size);
    printf("* Frame Width\t: %d\n", frame_width);
    printf("* Frame Height\t: %d\n", frame_height);
    printf("Frame was successfully received!\n");
    printf("----\n");

    free_frame(_frame);
}

disconnect_from_scanner(scanner, kSERVICE);
}

// Cleanup resources allocated with core_init()
    core_cleanup();
}
```

Ниже приведён результат вывода приложения при успешном получении кадра:

```
#
#
       Frame Example v2.x.x
SDK version: 2.17.2
_____
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered : 1 RF627
Discovered
Search scanners from:
* IP Address : 192.168.2.104
* Netmask : 255.255.255.0
Discovered
           : 0 RF627
Was found
           : 1 RF627 v2.x.x
ID scanner in list: 0
Device information:
* Name : RF627 scanner
* Serial
           : 190068
* IP Addr : 192.168.1.30
Frame information:
* Data Size : 316224
* Frame Width
            : 648
* Frame Height : 488
Frame was successfully received!
Press <RETURN> to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью **Qt Creator**:

Загрузите файл CMakeLists.txt из папки Examples/C/RF627\_SMART/FRAME\_EXAMPLE через File > Open File or Project (укажите файл CMakeLists.txt)

- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

# 5.1.4 Получение и установка параметров

Ниже приведен пример получения и изменения имени сканера и смены состояния лазера (включение/выключение):

```
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X_sdk.h"
#include "rf62X types.h"
int main()
  printf("###############################"\n");
  printf("#
                                                  #\n");
  printf("#
                                                  #\n");
                  Parameter Example v2.x.x
  printf("#
                                                  #\n");
  printf("##############################"n");
  // Initialize sdk library
  core init();
  // Print return rf627 sdk version
  printf("SDK version: %s\n", sdk_version());
  printf("=======\n");
  // Create value for scanners vector's type
  vector_t* scanners = (vector_t*)calloc(1, sizeof (vector_t));
  // Initialization vector
  vector_init(&scanners);
  // Iterate over all available network adapters in the current operating
  // system to send "Hello" requests.
  uint32_t count = 0;
  for (int i=0; i<GetAdaptersCount(); i++)</pre>
     uint32_t host_ip_addr = ntohl(inet_addr(GetAdapterAddress(i)));
     uint32_t host_mask = ntohl(inet_addr(GetAdapterMasks(i)));
     // call the function to change adapter settings inside the library.
     set_platform_adapter_settings(host_mask, host_ip_addr);
     // Search for rf627old devices over network by Service Protocol.
     if (host ip addr != 0)
      {
        // Get another IP Addr and set this changes in adapter settings.
        printf("Search scanners from:\n "
               "* IP Address\t: %s\n "
               "* Netmask\t: %s\n",
               GetAdapterAddress(i), GetAdapterMasks(i));
        search_scanners(scanners, kRF627_SMART, 300, kSERVICE);
```

```
// Print count of discovered rf627old in network
     printf("Discovered\t: %d RF627\n",(int)vector_count(scanners)-count);
     printf("----\n");
     count = (int)vector_count(scanners);
   }
}
// Print count of discovered rf627smart in network
printf("Was found\t: %d RF627 v2.x.x", (int)vector_count(scanners));
for (int i = 0; i < (int)vector_count(scanners); i++)</pre>
  scanner_base_t* scanner = vector_get(scanners,i);
  printf("\n\nID scanner in list: %d\n", i);
  printf("-----
  // Establish connection to the RF627 device
  uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
  if (!is_connected)
     continue;
  // Read params from RF627 device
  uint8_t is_read = read_params_from_scanner(scanner, 3000, kSERVICE);
  if (!is_read)
     continue;
   //
  // Example of working with the parameter type:
  // string
  //
  // Get/Set parameter of Device Name
  parameter_t* name = get_parameter(scanner, "user_general_deviceName");
  if (name != NULL)
     char* value = name->val_str->value;
     printf("Current Device Name\t: %s\n", value);
     char* new_value = "TEST NAME";
     printf("New Device Name\t\t: %s\n", new_value);
     parameter_t* temp = create_parameter_from_type(name->base.type);
     uint32_t name_size = strlen(name->base.name) + 1;
     temp->base.name = platform_calloc(name_size, sizeof (char));
     platform_memcpy(temp->base.name, name->base.name, name_size);
     uint32_t value_size = strlen(new_value) + 1;
     temp->val_str->value = platform_calloc(value_size, sizeof (char));
     platform_memcpy(temp->val_str->value, new_value, value_size);
     temp->base.size = value_size;
     printf("----\n");
     set_parameter(scanner, temp);
     free_parameter(temp, scanner->type);
   }
```

```
11
   // Example of working with the parameter type:
   // uint32_t
   // Get/Set parameter of Laser Enabled
  parameter_t* laser = get_parameter(scanner, "user_laser_enabled");
   if (laser != NULL && strcmp(
              laser->base.type, "uint32_t") == 0)
     uint32_t isEnabled = laser->val_uint32->value;
      printf("Current Laser State\t: %s\n", (isEnabled?"ON":"OFF"));
      // Change the current state to the opposite
      isEnabled = !isEnabled;
      laser->val uint32->value = isEnabled;
      printf("New Laser State\t\t: %s\n", (isEnabled?"ON":"OFF"));
     printf("----\n");
      set_parameter(scanner, laser);
   }
   // Apply changed parameters to the device
   char answer = 'n';
  printf("Apply changed params to the device? (y/n): ");
   scanf("%c", &answer);
   if (answer == 'y' || answer == 'Y')
     write_params_to_scanner(scanner, 3000, kSERVICE);
      // Save changes to the device's memory
     printf("\nSave changes to device's memory? (y/n): ");
      scanf("%c", &answer);
      if (answer == 'y' || answer == 'Y')
           save_params_to_scanner(scanner, 3000, kSERVICE);
  }
}
// Cleanup resources allocated with core_init()
core_cleanup();
```

Ниже приведён результат вывода приложения при успешной установке новых параметров:

Вы можете открыть и скомпилировать этот пример с помощью Qt Creator:

- Загрузите файл CMakeLists.txt из папки Examples/C/RF627\_SMART/PARAMETER\_EXAMPLE через File > Open File or Project (укажите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

# 5.1.5 Запись и скачивание дампа

Ниже приведен пример записи дампа профилей и его скачивание:

```
#include <stdio.h>
#include <stdlib.h>
#include "network.h"
#include "rf62Xcore.h"
#include "rf62X sdk.h"
#include "rf62X types.h"
int main()
  printf("#################",");
  printf("#
                                             #\n");
                                             #\n");
  printf("#
                  Dump Example v2.x.x
  printf("#
  printf("##################################");
  // Initialize sdk library
  core_init();
  // Print return rf627 sdk version
  printf("SDK version: %s\n", sdk_version());
  printf("=======\n");
  // Create value for scanners vector's type
```

```
vector_t* scanners = (vector_t*)calloc(1, sizeof (vector_t));
// Initialization vector
vector_init(&scanners);
// Iterate over all available network adapters in the current operating
// system to send "Hello" requests.
uint32_t count = 0;
for (int i=0; i<GetAdaptersCount(); i++)</pre>
   uint32_t host_ip_addr = ntohl(inet_addr(GetAdapterAddress(i)));
   uint32_t host_mask = ntohl(inet_addr(GetAdapterMasks(i)));
   // call the function to change adapter settings inside the library.
   set_platform_adapter_settings(host_mask, host_ip_addr);
   // Search for rf627old devices over network by Service Protocol.
   if (host ip addr != 0)
      // Get another IP Addr and set this changes in adapter settings.
      printf("Search scanners from:\n "
             "* IP Address\t: %s\n "
             "* Netmask\t: %s\n",
            GetAdapterAddress(i), GetAdapterMasks(i));
      search_scanners(scanners, kRF627_SMART, 300, kSERVICE);
      // Print count of discovered rf627old in network
      printf("Discovered\t: %d RF627\n", (int) vector_count(scanners)-count);
      printf("----\n");
      count = (int) vector count(scanners);
  }
}
// Print count of discovered rf627smart in network
printf("Was found\t: %d RF627 v2.x.x", (int)vector_count(scanners));
for (int i = 0; i < (int) vector count(scanners); i++)</pre>
   scanner_base_t* scanner = vector_get(scanners,i);
  printf("\n\nID scanner in list: %d\n", i);
  printf("-----
   // Establish connection to the RF627 device
   uint8_t is_connected = connect_to_scanner(scanner, kSERVICE);
  if (!is_connected)
     continue;
  // Read params from RF627 device
   uint8_t is_read = read_params_from_scanner(scanner, 3000, kSERVICE);
   if (!is_read)
      continue;
  uint8_t status = FALSE;
   rf627_profile2D_t** dumps = NULL;
   uint32_t profiles_in_dump = 0;
   uint32_t count_of_profiles = 1000;
   // Get parameter of user_dump_capacity
```

```
parameter_t* capacity = get_parameter(scanner, "user_dump_capacity");
  if (capacity != NULL)
     capacity->val_uint32->value = count_of_profiles;
     set_parameter(scanner, capacity);
     write_params_to_scanner(scanner, 300, kSERVICE);
  // Get parameter of user_dump_enabled
  parameter_t* enabled = get_parameter(scanner, "user_dump_enabled");
  if (enabled != NULL && strcmp(enabled->base.type,"uint32_t") == 0)
     enabled->val_uint32->value = TRUE;
     set_parameter(scanner, enabled);
     write_params_to_scanner(scanner, 300, kSERVICE);
  printf("Start dump recording...\n");
  printf("----\n");
  uint32_t size = 0;
  // wait dump recording
  do {
     read_params_from_scanner(scanner, 300, kSERVICE);
     size = get_parameter(scanner, "user_dump_size") ->val_uint32->value;
     printf("Current profiles in the dump: %d\n", size);
   }while(size < count_of_profiles);</pre>
  printf("-----
  printf("Start dump downloading...\n");
  // Get parameter of user_dump_enabled
  parameter_t* unit_size =get_parameter(scanner, "fact_dump_unitSize");
  if (unit_size != NULL && strcmp(unit_size->base.type, "uint32_t") == 0)
     dumps = calloc(count_of_profiles, sizeof (rf627_profile2D_t*));
     uint32 t start index = 0;
     status = get_dumps_profiles_from_scanner(
                 scanner, start_index, count_of_profiles,
                 10000, kSERVICE,
                 dumps, &profiles_in_dump,
                 unit_size->val_uint32->value);
  }
  if (status) {
     printf("%d Profiles in dump were downloaded!\n", profiles_in_dump);
     printf("----\n");
     printf("Dump was not received!\n");
     printf("----\n");
  for(uint32_t i = 0; i < profiles_in_dump; i++)</pre>
     free_profile2D(dumps[i]);
  free (dumps);
// Cleanup resources allocated with core_init()
core_cleanup();
```

}

Ниже приведён результат вывода приложения при успешной записи и скачивании дампа профилей:

```
#
      Parameter Example v2.x.x
SDK version: 2.17.2
_____
Search scanners from:
* IP Address : 192.168.1.2
* Netmask
           : 255.255.255.0
           : 1 RF627
Discovered
Search scanners from:
* IP Address : 192.168.2.104
         : 255.255.255.0
* Netmask
Discovered
           : 0 RF627
Was found : 1 RF627 v2.x.x
ID scanner's list: 0
Start dump recording...
Current profiles in the dump: 0
Current profiles in the dump: 67
Current profiles in the dump: 205
Current profiles in the dump: 415
Current profiles in the dump: 702
Current profiles in the dump: 921
Current profiles in the dump: 1000
Start dump downloading...
1000 Profiles were received!
Press <RETURN> to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью Qt Creator:

- Загрузите файл CMakeLists.txt из папки Examples/C/RF627\_SMART/DUMP\_EXAMPLE через File > Open File or Project (укажите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

# 5.2 Примеры для С++

# 5.2.1 Поиск устройств RF62X

Ниже приведен пример поиска сканеров серии RF627 v2.x.x:

```
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
using namespace SDK::SCANNERS::RF62X;
int main()
  #" << std::endl;
  std::cout << "#
  std::cout << "#
                                               #" << std::endl;</pre>
                     Search Example v2.x.x
                                               #" << std::endl;</pre>
  std::cout << "#
  std::cout << "#################################hn"<< std::endl;
  // Initialize sdk library
  sdk_init();
  // Print return rf62X sdk version
  std::cout << "SDK version: " << sdk_version()</pre>
                                                    << std::endl;
  std::cout << "========================
                                                    << std::endl;
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search(500);
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: " << list.size() << " RF627 v2.x.x" << std::endl;
  for (size_t i = 0; i < list.size(); i++)</pre>
    std::shared_ptr<hello_info> info = list[i]->get_info();
    std::cout << "\n\nID scanner's list: " << i</pre>
                                                    << std::endl;
    std::cout << "----" << std::endl;
    std::cout << "Device information: "</pre>
                                                    << std::endl;
    std::cout << "\nWorking ranges: "</pre>
                                                    << std::endl;
    std::cout << "* Zsmr, mm\t: " << info->z_smr()
                                                    << std::endl;
    std::cout << "* Zmr , mm\t: " << info->z_mr()
                                                    << std::endl;
    std::cout << "* Xsmr, mm\t: " << info->x_smr()
                                                   << std::endl;
    std::cout << "* Xemr, mm\t: " << info->x_emr()
                                                    << std::endl;
    std::cout << "\nVersions: "</pre>
                                                    << std::endl;
    std::cout << "* Firmware\t: " << info->firmware_version() << std::endl;</pre>
    std::cout << "* Hardware\t: " << info->hardware_version() << std::endl;</pre>
    std::cout << "-----" << std::endl;
```

```
// Cleanup resources allocated with sdk_init()
   sdk_cleanup();
}
```

Ниже приведён результат вывода приложения при успешном обнаружении сканера в сети:

```
#
       Search Example v2.x.x
                             #
SDK version: 2.19.0
______
Search scanners from:
* IP Address : 192.168.2.100
         : 255.255.255.0
* Netmask
          : 0 RF627-Smart
Discovered
_____
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered : 1 RF627-Smart
Was found : 1 RF627 v2.x.x
______
ID scanner's list: 0
______
Device information:
* Name : RF627 scanner
          : 190068
* Serial
* IP Addr
          : 192.168.1.30
* MAC Addr
          : 00:0A:35:6E:07:F5
Working ranges:
        : 70
* Zsmr, mm
           : 50
* Zmr , mm
          : 30
* Xsmr, mm
* Xemr, mm
           : 42
Versions:
          : 2.7.1
* Firmware
* Hardware : 18.6.20
Press <RETURN> to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью **Qt Creator**:

- Загрузите файл *CMakeLists.txt* из папки **Examples/Cpp/RF627\_SMART/SEARCH\_EXAMPLE** через **File > Open File or Project** (укажите файл *CMakeLists.txt*)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

## 5.2.2 Получение профиля сканера

Ниже приведен пример получение профиля со сканера серии RF627 v2.x.x:

```
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
using namespace SDK::SCANNERS::RF62X;
int main()
  #" << std::endl;
  std::cout << "#
                                                #" << std::endl;
  std::cout << "#
                     Profile Example v2.x.x
  std::cout << "#
                                                #" << std::endl;
  // Initialize sdk library
  sdk_init();
  // Print return rf62X sdk version
  std::cout << "SDK version: " << sdk_version()</pre>
                                                     << std::endl;
  std::cout << "=========""
                                                     << std::endl:
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search();
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: " << list.size() << " RF627 v2.x.x" << std::endl;
  // Iterate over all discovered scanners in network, connect to each of_
⇔them,
  // get a profile and print the main profile-info.
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared_ptr<rf627smart> scanner = list[i];
     std::shared_ptr<hello_info> info = scanner->get_info();
     // Print information about the scanner to which the profile belongs.
     std::cout << "\n\nID scanner's list: " << i</pre>
                                                    << std::endl;
     std::cout << "-----" << std::endl;
     std::cout << "Device information: "</pre>
                                                    << std::endl;
     std::cout << "* Name \t: " << info->device_name() << std::endl;
     std::cout << "* Serial\t: " << info->serial_number() << std::endl;</pre>
     std::cout << "* IP Addr\t: " << info->ip_address() << std::endl;</pre>
     // Establish connection to the RF627 device by Service Protocol.
     bool is_connected = scanner->connect();
     if (!is_connected)
```

```
continue;
   // Get profile from scanner's data stream by Service Protocol.
   std::shared_ptrprofile2D> profile = nullptr;
   bool zero_points = true;
   bool realtime = true;
   if ((profile=scanner->get_profile2D(zero_points,realtime)))
      std::cout << "Profile information: "</pre>
                                                              <<std::endl;
      switch ((PROFILE_DATA_TYPES)profile->getHeader().data_type)
      case PROFILE_DATA_TYPES::PIXELS:
         std::cout<<"* DataType\t: "<<"PIXELS"</pre>
                                                             <<std::endl;
         std::cout<<"* Count\t: "<<pre>rofile->qetPixels().size()<<std::endl;</pre>
      case PROFILE_DATA_TYPES::PIXELS_INTRP:
         std::cout<<"* DataType\t: "<<"PIXELS_INTRP"</pre>
                                                            <<std::endl;
         std::cout<<"* Count\t: "<<pre>profile->getPixels().size()<<std::endl;</pre>
         break;
      case PROFILE_DATA_TYPES::PROFILE:
         std::cout<<"* DataType\t: "<<"PROFILE"</pre>
                                                              <<std::endl;
         std::cout<<"* Size\t: "<<pre>file->getPoints().size() <<std::endl;</pre>
        break;
      case PROFILE_DATA_TYPES::PROFILE_INTRP:
         std::cout<<"* DataType\t: "<<"PROFILE_INTRP"</pre>
                                                             <<std::endl;
         std::cout<<"* Size\t: "<<pre>rofile->qetPoints().size() <<std::endl;</pre>
        break;
      }
      std::cout << "Profile was successfully received!"</pre>
                                                             <<std::endl;
      std::cout << "-----"<<std::endl;
   }else
      std::cout << "Profile was not received!"</pre>
                                                             <<std::endl;
      std::cout << "-----"<<std::endl;
   // Disconnect from scanner.
  scanner->disconnect();
}
// Cleanup resources allocated with sdk_init()
sdk_cleanup();
```

Ниже приведён результат вывода приложения при успешном получении профиля:

```
Profile Example v2.x.x
SDK version: 2.19.0
_____
Search scanners from:
* IP Address : 192.168.2.100
```

```
: 255.255.255.0
* Netmask
Discovered : 0 RF627-Smart
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
           : 1 RF627-Smart
Discovered
Was found
           : 1 RF627 v2.x.x
______
ID scanner's list: 0
Device information:
* Name : RF627 scanner
. Rr 027 : 190068 * IP Addr . ^ ^
            : 192.168.1.30
* MAC Addr : 00:0A:35:6E:07:F5
Profile information:
* DataType : PROFILE
* Size
            : 648
Profile was successfully received!
_____
Press <RETURN> to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью **Qt Creator**:

- Загрузите файл CMakeLists.txt из папки Examples/Cpp/RF627\_SMART/PROFILE\_EXAMPLE через File > Open File or Project (укажите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

#### 5.2.3 Получение кадра матрицы

Ниже приведен пример получение кадра матрицы со сканера серии RF627 v2.x.x:

```
// Initialize sdk library
sdk_init();
// Print return rf62X sdk version
std::cout << "SDK version: " << sdk_version()</pre>
                                                         << std::endl;
std::cout << "========""
                                                        << std::endl;
// Create value for scanners vector's type
std::vector<std::shared_ptr<rf627smart>> list;
// Search for rf627smart devices over network
list = rf627smart::search();
// Print count of discovered rf627smart in network by Service Protocol
std::cout << "Was found\t: " << list.size()<< " RF627 v2.x.x"<< std::endl;
// Iterate over all discovered scanners in network, connect to each of_
// get a profile and print the main profile-info.
for (size_t i = 0; i < list.size(); i++)</pre>
   std::shared_ptr<rf627smart> scanner = list[i];
   std::shared_ptr<hello_info> info = scanner->get_info();
   // Print information about the scanner to which the profile belongs.
   std::cout << "\n\nID scanner's list: " << i</pre>
                                                        << std::endl;
   std::cout << "-----
                                                   ----" << std::endl;
   std::cout << "Device information: "</pre>
                                                        << std::endl;
  std::cout << "* Name \t: " << info->device_name() << std::endl;
std::cout << "* Serial\t: " << info->serial_number() << std::endl;</pre>
   std::cout << "* IP Addr\t: " << info->ip_address() << std::endl;</pre>
   // Establish connection to the RF627 device by Service Protocol.
  bool is connected = scanner->connect();
  if (!is_connected)
     continue;
   // Get profile from scanner's data stream by Service Protocol.
   std::shared_ptrprofile2D> profile = nullptr;
   bool zero_points = true;
   bool realtime = true;
   std::shared_ptr<frame> frame = nullptr;
   if ((frame = scanner->get_frame()))
     std::cout << "Frame information: "</pre>
                                                               << "\n";
     std::cout << "* Data Size\t: " << frame->getDataSize() << "\n";</pre>
     std::cout << "* Frame Height\t: " << frame->getFrameHeight() << "\n";</pre>
     std::cout << "* Frame Width\t: " << frame->getFrameWidth() << "\n";</pre>
                                                              << "\n";
     std::cout << "Frame was successfully received!"</pre>
     std::cout << "----" << "\n";
   }else
   {
     std::cout << "Frame was not received!"</pre>
                                                               << "\n";
     std::cout << "-----"
                                                               << "\n";
```

```
}

// Disconnect from scanner.
scanner->disconnect();
}

// Cleanup resources allocated with sdk_init()
sdk_cleanup();
}
```

Ниже приведён результат вывода приложения при успешном получении кадра:

```
#
        Frame Example v2.x.x
                              #
SDK version: 2.19.0
_____
Search scanners from:
* IP Address : 192.168.2.100
* Netmask : 255.255.255.0
Discovered : 0 RF627-Smart
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered : 1 RF627-Smart
Was found : 1 RF627 v2.x.x
_____
ID scanner's list: 0
______
Device information:
* Name
     : RF627 scanner
           : 190068
: 192.168.1.30
* Serial
* IP Addr
* MAC Addr
           : 00:0A:35:6E:07:F5
Frame information:
* Data Size : 316224
* Frame Height : 488
* Frame Width : 648
Frame was successfully received!
Press <RETURN> to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью **Qt Creator**:

- Загрузите файл *CMakeLists.txt* из папки **Examples/Cpp/RF627\_SMART/FRAME\_EXAMPLE** через **File > Open File or Project** (укажите файл *CMakeLists.txt*)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

## 5.2.4 Получение и установка параметров

Ниже приведен пример получения и изменения имени сканера и смены состояния лазера (включение/выключение):

```
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"
using namespace SDK::SCANNERS::RF62X;
int main()
  #" << std::endl;</pre>
  std::cout << "#
                                                  #" << std::endl;
  std::cout << "#
                      Frame Example v2.x.x
                                                  #" << std::endl;
  std::cout << "#
  // Initialize sdk library
  sdk_init();
  // Print return rf62X sdk version
  std::cout << "SDK version: " << sdk version()</pre>
                                                       << std::endl;
  std::cout << "========"""
                                                       << std::endl;
  // Create value for scanners vector's type
  std::vector<std::shared ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search();
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: " << list.size()<< " RF627 v2.x.x"<< std::endl;
  // Iterate over all discovered scanners in network, connect to each of_
→them.
  // get a profile and print the main profile-info.
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared ptr<rf627smart> scanner = list[i];
     std::shared ptr<hello info> info = scanner->get info();
     // Print information about the scanner to which the profile belongs.
     -----" << std::endl;
     std::cout << "-----
                                                      << std::endl;
     std::cout << "Device information: "</pre>
     std::codt << beviete information.

std::cout << "* Name \t: " << info->device_name() << std::endl;

std::cout << "* Serial\t: " << info->serial_number() << std::endl;</pre>
     std::cout << "* IP Addr\t: " << info->ip_address()
                                                     << std::endl;
     // Establish connection to the RF627 device by Service Protocol.
     bool is_connected = scanner->connect();
```

```
if (!is_connected) {
  std::cout << "Failed to connect to scanner!" << std::endl;</pre>
  continue;
// read params from RF627 device by Service Protocol.
bool is_read = scanner->read_params();
if (!is_read) {
  std::cout << "Failed to read scanner parameters!" << std::endl;</pre>
  continue;
}
// Example of working with the parameter type:
// std::string
//
// Get parameter of Device Name
auto name = scanner->get_param("user_general_deviceName");
if (name != nullptr)
  std::string str_name = name->getValue<std::string>();
  std::cout << "Current Device Name \t: " << str_name << std::endl;</pre>
   // Add "_TEST" to the ending of the current name
  str_name += "_TEST";
  scanner->set_param("user_general_deviceName", str_name);
  std::cout << "-----
                                     -----"<< std::endl;
}
//
// Example of working with the parameter type:
// uint32_t
//
// Get parameter of Sensor Framerate
auto fps = scanner->get_param("user_sensor_framerate");
if (fps != nullptr)
{
  uint32_t value = fps->getValue<uint32_t>();
  std::cout<<"Current FPS\t\t: "<< value << std::endl;</pre>
  // Change the framerate to 100
  scanner->set_param("user_sensor_framerate", 100);
  std::cout<<"New FPS \t\t: " << 100 << std::endl;
  std::cout << "----"<< std::endl;
}
//
// Example of working with the parameter type:
// std::vector<uint32_t>
//
// Get parameter of Device IP Addr
auto ip_addr = scanner->get_param("user_network_ip");
if (ip_addr != nullptr)
  std::vector<uint32_t> ip =ip_addr->getValue<std::vector<uint32_t>>();
  std::cout << "Current Device IP\t: ";</pre>
```

```
for(auto i: ip) std::cout<<std::to_string(i)<<".";std::cout<< "\n";</pre>
   // Change last digit of IP address (e.g. 192.168.1.30->192.168.1.31)
   //ip[3]++;
   scanner->set_param("user_network_ip", ip);
   std::cout << "New Device IP \t: ";</pre>
   for(auto i: ip) std::cout<<std::to_string(i)<<".";std::cout<< "\n";</pre>
   std::cout << "-----"
}
// Example of working with using an Enum:
// uint32_t
11
// Get parameter of Sync Source
auto syncSource = scanner->get_param("user_sensor_syncSource");
if (syncSource != nullptr)
   uint32_t value = syncSource->getValue<uint32_t>();
   auto syncEnum = syncSource->getEnum<uint32_t>();
   std::cout << "Current Sync Source\t: "</pre>
             << syncEnum.findLabel(value)</pre>
             << std::endl;
   // Change the current state to SYNC_EXTERNAL (or SYNC_INTERNAL)
   if (value == syncEnum.getValue("SYNC_INTERNAL"))
      scanner->set_param_by_key(
                   "user_sensor_syncSource", "SYNC_EXTERNAL");
      std::cout << "New Sync Source \t: "</pre>
                << syncEnum.getLabel("SYNC_EXTERNAL")</pre>
                << std::endl;
   }else
   {
      scanner->set_param_by_key(
                   "user_sensor_syncSource", "SYNC_INTERNAL");
      std::cout << "New Sync Source \t: "</pre>
                << syncEnum.getLabel("SYNC_INTERNAL")</pre>
                << std::endl;
   }
   std::cout << "-----"<< std::endl;
}
//
// Example of working with using an Enum:
// uint32 t
//
// Get parameter of Laser Enabled
std::shared_ptr<param> laser = scanner->get_param("user_laser_enabled");
if (laser != nullptr)
{
   uint32_t isEnabled = laser->getValue<uint32_t>();
   auto laserEnum = laser->getEnum<uint32_t>();
   std::cout << "Current Laser State\t: "</pre>
             << laserEnum.findLabel(isEnabled)</pre>
             << std::endl;
```

```
// Change the current state to the opposite
      if(isEnabled == laser->getEnum<uint32_t>().getValue("FALSE"))
         scanner->set_param_by_key("user_laser_enabled", "TRUE");
         std::cout << "New Laser State \t: "</pre>
                   << laserEnum.getLabel("TRUE")</pre>
                   << std::endl;
      }else
      {
         scanner->set_param_by_key("user_laser_enabled", "FALSE");
         std::cout << "New Laser State \t: "</pre>
                   << laserEnum.getLabel("FALSE")</pre>
                   << std::endl;
      std::cout << "-----"<< std::endl;
   // Apply changed parameters to the device
   std::string answer = "n";
   std::cout << "Apply changed params to the device? (y/n): ";</pre>
   std::cin >> answer;
   if (answer == "y" || answer == "Y")
      scanner->write_params();
      // Save changes to the device's memory
      std::cout << std::endl << "Save changes to device's memory? (y/n): ";
      std::cin >> answer;
      if (answer == "y" || answer == "Y")
         scanner->save_params();
   }
   // Disconnect from scanner.
   scanner->disconnect();
}
// Cleanup resources allocated with sdk_init()
sdk_cleanup();
```

Ниже приведён результат вывода приложения при успешной установке новых параметров:

```
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered : 1 RF627-Smart
          : 1 RF627 v2.x.x
Was found
ID scanner's list: 0
Device information:
       : RF627 scanner
* Serial : 190068

* IP Addr : 192.168.1.30

* MAC Addr : 00:0A:35:6E:07:F5
Current Device Name : RF627 scanner
New Device Name : RF627 scanner_TEST
Current FPS
                        : 490
                        : 100
New FPS
Current Device IP : 192.168.1.30.
New Device IP : 192.168.1.30.
Current Sync Source : Internal : External
______
Current Laser State : true
New Laser State : false
______
Apply changed params to the device? (y/n): y
Save changes to device's memory? (y/n): n
Press <RETURN> to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью Qt Creator:

- Загрузите файл CMakeLists.txt из папки Examples/Cpp/RF627\_SMART/PARAMETER\_EXAMPLE через File > Open File or Project (укажите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

## 5.2.5 Запись и скачивание дампа

Ниже приведен пример записи дампа профилей и его скачивание:

```
#include <string>
#include <iostream>
#include "rf62Xsdk.h"
#include "rf62Xtypes.h"

using namespace SDK::SCANNERS::RF62X;
```

```
int main()
  #" << std::endl;
  std::cout << "#
  std::cout << "#
                                                  #" << std::endl;</pre>
                       Frame Example v2.x.x
                                                  #" << std::endl;
  std::cout << "#
  // Initialize sdk library
  sdk_init();
  // Print return rf62X sdk version
  std::cout << "SDK version: " << sdk_version()</pre>
                                                       << std::endl;
  // Create value for scanners vector's type
  std::vector<std::shared_ptr<rf627smart>> list;
  // Search for rf627smart devices over network
  list = rf627smart::search();
  // Print count of discovered rf627smart in network by Service Protocol
  std::cout << "Was found\t: " << list.size()<< " RF627 v2.x.x"<< std::endl;</pre>
  std::cout << "========================
                                                      << std::endl;
  // Iterate over all discovered scanners in network, connect to each of_
\rightarrowthem.
  // get a profile and print the main profile-info.
  for (size_t i = 0; i < list.size(); i++)</pre>
     std::shared_ptr<rf627smart> scanner = list[i];
     std::shared_ptr<hello_info> info = scanner->get_info();
     // Print information about the scanner to which the profile belongs.
     std::cout << "\n\nID scanner's list: " << i</pre>
                                                     << std::endl;
     std::cout << "----" << std::endl;
     std::cout << "Device information: "</pre>
                                                      << std::endl;
     std::cout << "* Name \t: " << info->device_name() << std::endl;
std::cout << "* Serial\t: " << info->serial_number() << std::endl;</pre>
                                                      << std::endl;
     std::cout << "* IP Addr\t: " << info->ip_address()
     std::cout << "----" << std::endl;
     // Establish connection to the RF627 device by Service Protocol.
     bool is connected = scanner->connect();
     if (!is_connected) {
       std::cout << "Failed to connect to scanner!" << std::endl;</pre>
       continue;
     uint32_t count_of_profiles = 1000;
     scanner->start_dump_recording(count_of_profiles);
     std::cout << "Start dump recording..."</pre>
                                                       << std::endl;
     std::cout << "----" << std::endl;
     uint32_t size = 0;
```

```
do {
     scanner->read_params();
     size = scanner->qet_param("user_dump_size")->qetValue<uint32_t>();
     std::cout << "Current profiles in the dump: "<< size << std::endl;</pre>
   }while(size < count_of_profiles);</pre>
   std::cout << "----
                                    ----- << std::endl;
   std::cout << "Start dump downloading..."</pre>
                                                         << std::endl;
   std::vector<std::shared_ptr<pre>profile2D>> dump =
           scanner->get_dumps_profiles(0, count_of_profiles);
   std::cout << dump.size() << " Profiles in dump were downloaded!\n";</pre>
   std::cout << "-----" << std::endl;
  // Disconnect from scanner.
  scanner->disconnect();
}
// Cleanup resources allocated with sdk_init()
sdk_cleanup();
```

Ниже приведён результат вывода приложения при успешной записи и скачивании дампа профилей:

```
Parameter Example v2.x.x
SDK version: 2.19.0
_____
Search scanners from:
* IP Address : 192.168.2.100
* Netmask : 255.255.255.0
Discovered : 0 RF627-Smart
          : 0 RF627-Smart
_____
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered
         : 1 RF627-Smart
         : 1 RF627 v2.x.x
Was found
_____
ID scanner's list: 0
Device information:
      : RF627 scanner
* Serial
          : 190068
* IP Addr : 192.168.1.30
Start dump recording...
Current profiles in the dump: 0
```

Вы можете открыть и скомпилировать этот пример с помощью Qt Creator:

- Загрузите файл CMakeLists.txt из папки Examples/Cpp/RF627\_SMART/DUMP\_EXAMPLE через File > Open File or Project (укажите файл CMakeLists.txt)
- Выберите компилятор (MinGW, MSVC, Clang) и нажмите Configure Project
- Запустите проект

# 5.3 Примеры для С#

# 5.3.1 Поиск устройств RF62X

Ниже приведен пример поиска сканеров серии RF627 v2.x.x:

```
using System;
using System.Collections.Generic;
using SDK.SCANNERS;
namespace SEARCH EXAMPLE
  class Program
     static void Main(string[] args)
        Console.WriteLine("###############################;);
        Console.WriteLine("#
                                                                 #");
        Console.WriteLine("#
                                   Search Example v2.x.x
                                                                 #");
        Console.WriteLine("#
                                                                 #");
        Console.WriteLine("################################");
        // Initialize sdk library
        RF62X.SdkInit();
        // Print return rf62X sdk version
        Console.WriteLine("SDK version: {0}", RF62X.SdkVersion());
        Console.WriteLine("=========");
        // Search for RF627smart devices over network
        List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
        // Print count of discovered rf627smart in network
        Console.WriteLine("Was found\t: {0} RF627 v2.x.x", list.Count);
```

```
Console.WriteLine("========");
     for (int i = 0; i < list.Count; i++)</pre>
        RF62X.HelloInfo info = list[i].GetInfo();
        Console.WriteLine("\n\nID scanner's list: {0}", i);
        Console.WriteLine("-----
        Console.WriteLine("Device information: ");
        Console.WriteLine("* Name\t: {0}", info.device_name);
        Console.WriteLine("* Serial\t: {0}", info.serial_number);
        Console.WriteLine("* IP Addr\t: {0}", info.ip_address);
        Console.WriteLine("* MAC Addr\t: {0}", info.mac_address);
        Console.WriteLine("\nWorking ranges: ");
        Console.WriteLine("* Zsmr, mm\t: {0}", info.z_smr);
        Console.WriteLine("* Zmr , mm\t: {0}", info.z_mr);
        Console.WriteLine("* Xsmr, mm\t: {0}", info.x_smr);
        Console.WriteLine("* Xemr, mm\t: {0}", info.x_emr);
        Console.WriteLine("\nVersions: ");
        Console.WriteLine("* Firmware\t: {0}", info.firmware_version);
        Console.WriteLine("* Hardware\t: {0}", info.hardware_version);
        Console.WriteLine("----");
     }
     // Cleanup resources allocated with SdkInit()
     RF62X.SdkCleanup();
     Console.WriteLine("Press any key to close this window...");
     Console.ReadKey();
  }
}
```

Ниже приведён результат вывода приложения при успешном обнаружении сканера в сети:

```
#
       Search Example v2.x.x
                             #
SDK version: 2.17.2
_____
Search scanners from:
* IP Address : 192.168.1.2
* Ir III.
* Netmask
          : 255.255.255.0
          : 1 RF627
Discovered
Search scanners from:
netmask : 255.255.255.0
Discovered : 0 PECCT
* IP Address : 192.168.2.104
Was found
          : 1 RF627 v2.x.x
```

```
ID scanner in list: 0
Device information:
* Name : RF627 scanner 
* Serial : 190068
               : 190068
* IP Addr : 192.168.1.30

* MAC Addr : 00:0A:35:6E:
               : 00:0A:35:6E:07:F5
Working ranges:
* Zsmr, mm : 70
* Zmr , mm
                : 50
               : 30
* Xsmr, mm
* Xemr, mm
               : 42
Versions:
* Firmware
               : 2.7.1
* Hardware : 18.6.20
Press any key to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью Visual Studio:

- Используя Visual Studio откройте из папки **RF62X-SDK/Examples/CSharp/RF627\_smart** проект *RF627\_TESTS*.
- Укажите целевую платформу **x64 Debug** или **x64 Release**
- Скомпилируйте SEARCH\_EXAMPLE
- Перед запуском скачайте архив библиотек для C# (смотреть последние выпуски RF62X-SDK библиотек) и скопируйте из архива в папке Dependencies все файлы с именем libRF62X-SDK в папку к исполняемому файлу проекта (../bin/x64/Debug/или ../bin/x64/Release/)
- Запустите пример

#### 5.3.2 Получение профиля сканера

Ниже приведен пример получение профиля со сканера серии RF627 v2.x.x:

```
using System;
using System.Collections.Generic;
using SDK.SCANNERS;

namespace SEARCH_EXAMPLE
{
    class Program
    {
        public static uint profileCount = 0;
        public static uint profileLost = 0;
        public static bool isReceiveRun = true;
        public static void receive_profiles(RF62X.RF627smart scanner)
        {
            // Get profile from scanner's data stream by Service Protocol.
            RF62X.Profile2D profile = null;
```

```
bool zero_points = true;
  bool realtime = false;
  uint last_index = 0;
  bool first_profile = true;
  while (true)
     if ((profile = scanner.GetProfile(zero_points, realtime)) != null)
        if (first_profile)
           last_index = profile.header.measure_count;
           first_profile = false;
        }
        else
           profileCount++;
           if (profile.header.measure_count - last_index > 1)
              profileLost+=(profile.header.measure_count - last_index);
           last_index = profile.header.measure_count;
        }
     }
     else
        Console.WriteLine("Profile was not received!");
        Console.WriteLine("-----
     }
}
static void Main(string[] args)
  Console.WriteLine("#################################;");
  Console.WriteLine("#
                                                           #");
                                                           #");
  Console.WriteLine("#
                             Profile Example v2.x.x
                                                           #");
  Console.WriteLine("#
  Console.WriteLine("#################################;");
  // Initialize sdk library
  RF62X.SdkInit();
  // Print return rf62X sdk version
  Console.WriteLine("SDK version: {0}", RF62X.SdkVersion());
  Console.WriteLine("==========");
  // Search for RF627smart devices over network
  List<RF62X.RF627smart> list = RF62X.RF627smart.Search(500);
  // Print count of discovered rf627smart in network
  Console.WriteLine("Was found\t: {0} RF627-Smart", list.Count);
  Console.WriteLine("========");
  int index = -1;
  if (list.Count > 1)
     Console.WriteLine("Select scanner for test: ");
     for (int i = 0; i < list.Count; i++)</pre>
        Console.WriteLine("{0}. Serial: {1}", i,
                         list[i].GetInfo().serial_number);
```

```
index = Convert.ToInt32(Console.ReadLine());
}
else if (list.Count == 1)
   index = 0;
           if (index == -1)
   return;
RF62X.HelloInfo info = list[index].GetInfo();
Console.WriteLine("----");
Console.WriteLine("Device information: ");
Console.WriteLine("* Name \t: {0}", info.device_name);
Console.WriteLine("* Serial\t: {0}", info.serial_number);
Console.WriteLine("* IP Addr\t: {0}", info.ip_address);
Console.WriteLine("-----
// Establish connection to the RF627 device by Service Protocol.
bool is_connected = list[index].Connect();
if (is_connected)
  Thread receiver = new Thread(() => receive_profiles(list[index]));
  isReceiveRun = true;
  receiver.Start();
   Console.WriteLine("Thread of receiving profiles started");
  Console.WriteLine("For interrupt receiving press \"Ctrl+C\"");
  bool isRun = true;
   Console.CancelKeyPress += delegate
     (object sender, ConsoleCancelEventArgs consoleArgs) {
     consoleArgs.Cancel = true;
     isRun = false;
     isReceiveRun = false;
   };
  while (isRun)
     Thread.Sleep(1000);
     Console.WriteLine("FPS: {0}, Lost: {1}",
                      Program.profileCount, profileLost);
     profileLost = 0;
     profileCount = 0;
   }
  receiver.Join();
  Console.WriteLine("Thread of receiving profiles interrupted");
  Console.WriteLine("----");
// Cleanup resources allocated with sdk_init()
RF62X.SdkCleanup();
Console.WriteLine("Press any key to close this window...");
Console.ReadKey();
```

```
}
```

Ниже приведён результат вывода приложения при успешном получении профиля:

```
#
#
       Profile Example v2.x.x
                               #
SDK version: 2.17.2
_____
Search scanners from:
* IP Address : 192.168.1.2
* Netmask : 255.255.255.0
Discovered : 1 RF627
Discovered
Search scanners from:
* IP Address : 192.168.2.104
* Netmask : 255.255.25.0
Discovered
          : 0 RF627
Was found : 1 RF627 v2.x.x
_____
Device information:
* Name : RF627 scanner
* Serial
           : 190068
         : 192.168.1.30
* IP Addr
Thread of receiving profiles started
For interrupt receiving press "Ctrl+C"
FPS: 494, Lost: 0
FPS: 490, Lost: 0
FPS: 491, Lost: 0
Thread of receiving profiles interrupted
Press any key to close this window...
```

Вы можете открыть и скомпилировать этот пример с помощью Visual Studio:

- Используя Visual Studio откройте из папки **RF62X-SDK/Examples/CSharp/RF627\_smart** проект *RF627\_TESTS*.
- Укажите целевую платформу **x64 Debug** или **x64 Release**
- Скомпилируйте PROFILE\_EXAMPLE
- Перед запуском скачайте архив библиотек для C# (смотреть последние выпуски RF62X-SDK библиотек) и скопируйте из архива в папке Dependencies все файлы с именем libRF62X-SDK в папку к исполняемому файлу проекта (../bin/x64/Debug/или ../bin/x64/Release/)
- Запустите пример