

- Request SFO/PFO with desired altitude [maximum 14.000'] with NATCF or Tower
- 4. Holding: Hold VFR at Dry Lake, left turns, at altitude directed by NATCF/Tower
- 5. Breakout Instructions: a. Overhead: Descend to 4K' feet MSL, proceed direct FLEX and comply w/ FLEX reentry

OVERHEAD SFO/PFO: Report "High Key", "Low Key" and "Base, gear down, low approach"

- STRAIGHT-IN SFO/PFO (RWY 21L/R ONLY): 1. If cleared by NATCF, proceed to 10 DME final

b. SI-SFO/PFO: As instructed by NATCF/Tower

- 2. Report position and altitude to Tower on initial contact
- 3. Report "Aircraft ID, 10 mile Straight In SFO/PFO" 4. Report "Aircraft ID, 5 mile final, gear down, low approach"