

TAKE-OFF RWY 21 L/R:

- Follow Noise Abatement procedures (Figure 4.1/paragraph 4.6).
 Request VFR cruising altitude on departure, maintain VFR during climb.
- 3. Fly DREAM THREE ground track to DREAM, proceed VFR to scheduled NTTR airspace.

3. Fly DREAM THREE ground track to DREAM, proceed VFR to scheduled NTTR airspace.