


USB to serial UART interface



The MTP memory on this FT-230XS-R device can be programmed directly over USB, using the FT_Prog utility to set the required options and program it. See:
www.ftdichip.com/Support/Utilities.htm#FT_Prog

LaPi - Mini LPMCU Eval Board Document Number FTDI Portion of Circuit