
KASEI

OPERATOR'S MANUAL

KZ-5000EA-PRO-2S

EARTH AUGER



Original Instructions

CAUTION: Thank you for purchasing a product. Before using our pole saw, please read this manual carefully to understand the proper use of your unit.

Serial No.


WARNING – The muffler and other parts of the engine (e.g. fins of the cylinder, spark plug) become hot during operation and remain hot for a while after stopping the engine.To reduce risk of burns do not touch the muffler and other parts while they are hot.

TECHNICAL SPECIFICATIONS


Model	KZ 5000EA-PRO
Reduction Rate	37:1
Engine Type	Single Cylinder Air cooling,2stroke gasoline
Displacement	50.8cc
Fuel Tank Capacity	0.9L
Carburetor	Diaphragm
Starting Method	Recoil starter
Power KW/HP	1.5/2
Net weight KG	9.5

DIAGRAM & SPARE PART LIST OF KZ 5000EA

GEAR BOX



SL NO.	PART NO.	DECSRIPTION
1	KZ-5000EA-01	GEAR BOX
2	KZ-5000EA-02	CLUTCH DRUM COMP.
3	KZ-5000EA-03	VENT-PLUG
4	KZ-5000EA-04	WHEEL BOX
5	KZ-5000EA-05	FUEL CUP
6	KZ-5000EA-06	BEARING
7	KZ-5000EA-07	BUSHING
8	KZ-5000EA-08	STOP RING
9	KZ-5000EA-09	STOP RING
10	KZ-5000EA-10	GEAR
11	KZ-5000EA-11	KEY(cancel)
12	KZ-5000EA-12	GEAR SHAFT
13	KZ-5000EA-13	GASKET
14	KZ-5000EA-14	WHEEL BOX
15	KZ-5000EA-15	SCREW
16	KZ-5000EA-16	BEARING
17	KZ-5000EA-17	GEAR
18	KZ-5000EA-18	KEY(cancel)
19	KZ-5000EA-19	SHAFT
20	KZ-5000EA-20	GASKET
21	KZ-5000EA-21	BEARING
22	KZ-5000EA-22	CASE COVER
23	KZ-5000EA-23	SCREW



37
38
39
47
46
45
40
41
42
43
44
25
24
26
27
27
29
34
29
28
33
32
29
29
33
32
35
29
29
36
30
31

Handle Assy & Lever Assy

24	KZ-5000EA-24	HANDLE ASSY
25	KZ-5000EA-25	RUBBER RINGER
26	KZ-5000EA-26	RUBBER WASHER
27	KZ-5000EA-27	SPACER
28	KZ-5000EA-28	BRACE
29	KZ-5000EA-29	NUT
30	KZ-5000EA-30	SHAFT
31	KZ-5000EA-31	PIN
32	KZ-5000EA-32	RUBBER POLE
33	KZ-5000EA-33	CUSHION
34	KZ-5000EA-34	BRACE
35	KZ-5000EA-35	SCREW
36	KZ-5000EA-36	HANDLE

37	KZ-5000EA-37	LEVER ASS'Y
38	KZ-5000EA-38	BOX,LEFT
39	KZ-5000EA-39	STOP BUTTON COMP.
40	KZ-5000EA-40	CABLE COMP.
41	KZ-5000EA-41	SCREW
42	KZ-5000EA-42	WASHER
43	KZ-5000EA-43	SCREW
44	KZ-5000EA-44	BOX,RIGHT
45	KZ-5000EA-45	HANDGRIP
46	KZ-5000EA-46	SPRING
46	KZ-5000EA-47	HANDGRIP
46	KZ-5000EA-48	DRILL

ENGINE DIAGRAM OF KZ 5000EA



SPARE PART LIST OF KZ 5000EA

1	KZ-5000EA-E01	BEARING
2	KZ-5000EA-E02	BACK OIL SEAL
3	KZ-5000EA-E03	FRONT HALF CRANK CASE
4	KZ-5000EA-E04	BACK HALF CRANK CASE
5	KZ-5000EA-E05	PIN
6	KZ-5000EA-E06	CRANK CASE GASKET
7	KZ-5000EA-E07	BOLT
8	KZ-5000EA-E08	PISTON
9	KZ-5000EA-E09	PISTON RING
10	KZ-5000EA-E10	PISTON PIN
11	KZ-5000EA-E11	PISTON PIN CIRCLIP
12	KZ-5000EA-E12	CRANK SHAFT ASSY.
13	KZ-5000EA-E13	CYLINDER
14	KZ-5000EA-E14	CYLINDER GASKET
15	KZ-5000EA-E15	BOLT
16	KZ-5000EA-E16	SPARK PLUG
17	KZ-5000EA-E17	KEY
18	KZ-5000EA-E18.1	FLYWHEEL
18.1	KZ-5000EA-E18.2	IGNITION COIL COM P.
19	KZ-5000EA-E19	GASKET
20	KZ-5000EA-E20	Screw
21	KZ-5000EA-E21	NUT
22	KZ-5000EA-E22	WIRE LEAD ASSY.
23	KZ-5000EA-E23	CLUTCH
24	KZ-5000EA-E24	SCREW SHAFT
25	KZ-5000EA-E25	WASHER B
26	KZ-5000EA-E26	WASHER
27	KZ-5000EA-E27	FLYWHEEL COVER
28	KZ-5000EA-E28	PIN
29	KZ-5000EA-E29	SCREW
30	KZ-5000EA-E30	MUFFLER

SPARE PART LIST OF KZ 5000EA

31	KZ-5000EA-E31	MUFFLER GASKET
32	KZ-5000EA-E32	STARTER REEL
33	KZ-5000EA-E33	SCREW
34	KZ-5000EA-E34	SCREW
35	KZ-5000EA-E35	SCREW
36	KZ-5000EA-E36	FUEL TANK THERMAL BAFFLE
37	KZ-5000EA-E37	STARTER
38	KZ-5000EA-E38	ADMITTING PIPE GASKET
39	KZ-5000EA-E39	ADMITTING PIPE GASKET
40	KZ-5000EA-E40	ADMITTING PIPE GASKET
41	KZ-5000EA-E41	INSULATOR
42	KZ-5000EA-E42	CARBURETOR
43	KZ-5000EA-E43	CARBURETOR GASKET
44	KZ-5000EA-E44	INSIDE AIR BOX
45	KZ-5000EA-E45	FILTER
46	KZ-5000EA-E46	OUTSIDE AIR BOX
47	KZ-5000EA-E47	BIG HEAD SCREW
48	KZ-5000EA-E48	SCREW
49	KZ-5000EA-E49	CYLINDER COVER

50	KZ-5000EA-E50	HEAT PROOF MAT
51	KZ-5000EA-E51	SCREW
52	KZ-5000EA-E52.1	FUEL TANK ASS'Y
	KZ-5000EA-E52.2	FUEL PIPE
	KZ-5000EA-E52.3	FUEL PIPE
	KZ-5000EA-E52.4	GROMMET
	KZ-5000EA-E52.5	FUEL FILTER
	KZ-5000EA-E52.6	FUEL TANK CAP
53	KZ-5000EA-E53	SUPPORT
54	KZ-5000EA-E54	FUEL TANK HEAT SHIELD
55	KZ-5000EA-E55	SCREW
56	KZ-5000EA-E56	SCREW
57	KZ-5000EA-E57	SCREW
58	KZ-5000EA-E58	SCREW
59	KZ-5000EA-E59	AIR INTAKE HOSE
60	KZ-5000EA-E60	SCREW
61	KZ-5000EA-E61	NUT
62	KZ-5000EA-E62	OIL CUP
63	KZ-5000EA-E63	FUEL TUBE
64	KZ-5000EA-E64	SCREW
65	KZ-5000EA-E65	BRACKET
66	KZ-5000EA-E66	BAFFLE
67	KZ-5000EA-E67	AIR BOX GASKET
68	KZ-5000EA-E68	SHAFT SLEEVE

Marketed by:
ratnagiri®
impex
BRINGING YOU THE FUTURE... NOW





Marketed by:
ratnagiri impex
BRINGING YOU THE FUTURE... NOW

Imported & Marketed by
RATNAGIRI IMPEX PVT LTD
Annapurna House, #1/1G,
7th Cross, New Guddadahalli
Mysore Road, Bangalore-560 026
email: marketing@ratnagiriimpex.com

www.ratnagiriimpex.com