USER MANUAL

AGRIMATE®
APNALO MUNAFA BADALO

TRANSMISSION USER MANUAL

STUBBLE MOWER

AM-SM-6048-7P-PRO




AN ISO 9001 : 2015 CERTIFIED COMPANY

TECHNICAL SPECIFICATIONS

STUBBLE MOWER	
MODEL	AM-SM-6048-7P-PRO
POWER	7HP
DISPLACEMENT	212CC
GRASS WIDTH	600MM
GRASS DEPTH	10MM
RPM	3600RPM

SPARE PARTS DIAGRAM & PARTS LIST OF AM-SM-6048-7P-PRO STUBBLE MOWER



SPARE PARTS DIAGRAM & PARTS LIST OF AM-SM-6048-7P-PRO STUBBLE MOWER

SL NO.	PART NO.	DESCRIPTION	SL NO.	PART NO.	DESCRIPTION
1	AM-SM-6048-S01	Handle Sleeve	17	AM-SM-6048-S17	Driving Clutch Cable
2	AM-SM-6048-S02	Blade Roller Clutch Handle	18	AM-SM-6048-S18	Switch
3	AM-SM-6048-S03	Blade Roller Clutch Cable	19	AM-SM-6048-S19	Outer Flange Hexagon Bolt
4	AM-SM-6048-S04	Throttle Assembly	20	AM-SM-6048-S20	Armrest Clamp Plate
5	AM-SM-6048-S05	Throttle Cable	21	AM-SM-6048-S21	Flat Gasket
6	AM-SM-6048-S06	Clutch Handle Sleeve	22	AM-SM-6048-S22	Nut
7	AM-SM-6048-S07	Clutch Handle	23	AM-SM-6048-S23	Spring Gasket
8	AM-SM-6048-S08	Outer Flange Hexagon Bolt	24	AM-SM-6048-S24	Engine
9	AM-SM-6048-S09	Clutch Handle Convex Pad	25	AM-SM-6048-S25	Driving Belt Cover Inner Plate
10	AM-SM-6048-S10	Outer Flange Hexagon Bolt	26	AM-SM-6048-S26	Hexagonal Shaft
11	AM-SM-6048-S11	Clutch Connecting Plate	27	AM-SM-6048-S27	Driving Belt Cover 1
12	AM-SM-6048-S12	Driving Belt Clutch Cable	28	AM-SM-6048-S28	Outer Flange Hexagon Bolt
13	AM-SM-6048-S13	Flange Nut	29	AM-SM-6048-S29	Driving Belt Cover 2
14	AM-SM-6048-S14	Tools Box	30	AM-SM-6048-S30	Hole Circlip
15	AM-SM-6048-S15	Flange Nut	31	AM-SM-6048-S31	Deep Groove Ball Bearing
16	AM-SM-6048-S16	Driving Clutch Handle	32	AM-SM-6048-S32	Shaft Sleeve

SPARE PARTS DIAGRAM & PARTS LIST OF AM-SM-6048-7P-PRO STUBBLE MOWER

SL NO.	PART NO.	DESCRIPTION	SL NO.	PART NO.	DESCRIPTION
33	AM-SM-6048-S33	Shaft Circlip	49	AM-SM-6048-S49	Roller Belt Tension Pulley
34	AM-SM-6048-S34	Driving Shaft	50	AM-SM-6048-S50	Roller Belt Tension Plate
35	AM-SM-6048-S35	Flat Key	51	AM-SM-6048-S51	Roller Belt Tension Plate Gasket
36	AM-SM-6048-S36	Belt	52	AM-SM-6048-S52	Outer Flange Hexagon Bolt
37	AM-SM-6048-S37	Roller Belt Cover	53	AM-SM-6048-S53	Outer Hexagon Bolt
38	AM-SM-6048-S38	Flat Key	54	AM-SM-6048-S54	Spring Gasket
39	AM-SM-6048-S39	Driving Belt Pulley	55	AM-SM-6048-S55	Flat Gasket
40	AM-SM-6048-S40	Belt	56	AM-SM-6048-S56	Roller Blade Cover Case
41	AM-SM-6048-S41	Driving Tension Plate	57	AM-SM-6048-S57	Nylon Lock Nut
42	AM-SM-6048-S42	Driving Tension Pulley	58	AM-SM-6048-S58	Flat Gasket
43	AM-SM-6048-S43	Deep Groove Ball Bearing	59	AM-SM-6048-S59	Deep Groove Ball Bearing
44	AM-SM-6048-S44	Shaft Circlip	60	AM-SM-6048-S60	Handel Cover
45	AM-SM-6048-S45	Hole Circlip	61	AM-SM-6048-S61	Deep Groove Ball Bearing
46	AM-SM-6048-S46	Driving Tension Plate Gasket	62	AM-SM-6048-S62	Roller Bearing Seat 1
47	AM-SM-6048-S47	Roller Belt Cover Inner Plate	63	AM-SM-6048-S63	Flat Gasket
48	AM-SM-6048-S48	Shaft Circlip	64	AM-SM-6048-S64	Slotted Nut

SPARE PARTS DIAGRAM & PARTS LIST OF AM-SM-6048-7P-PRO STUBBLE MOWER

SL NO.	PART NO.	DESCRIPTION	SL NO.	PART NO.	DESCRIPTION
65	AM-SM-6048-S65	Cotter Pin	81	AM-SM-6048-S81	Pulley Retainer
66	AM-SM-6048-S66	Spacer Sleeve	82	AM-SM-6048-S82	Innner Hexagon Bolt
67	AM-SM-6048-S67	Drum driven pulley	83	AM-SM-6048-S83	Clutch Support Plate
68	AM-SM-6048-S68	Outer Flange Hexagon Bolt	84	AM-SM-6048-S84	Type B Cotter Pin
69	AM-SM-6048-S69	Wheel	85	AM-SM-6048-S85	Pin Shaft
70	AM-SM-6048-S70	Nut	86	AM-SM-6048-S86	Roller
71	AM-SM-6048-S71	Wheel Bracket	87	AM-SM-6048-S87	Angle Blade
72	AM-SM-6048-S72	Connecting Plate	88	AM-SM-6048-S88	Straight Blade
73	AM-SM-6048-S73	Front Bumper Plate	89	AM-SM-6048-S89	Pin Shaft
74	AM-SM-6048-S74	Flat Gasket	90	AM-SM-6048-S90	Wheel Left
75	AM-SM-6048-S75	Bumper Connecting Rod	91	AM-SM-6048-S91	Pin Shaft
76	AM-SM-6048-S76	Rear Bumper Plate	92	AM-SM-6048-S92	Gear Box
77	AM-SM-6048-S77	Gear Lever Sleeve	93	AM-SM-6048-S93	Gear Box Gasket
78	AM-SM-6048-S78	Gear Lever	94	AM-SM-6048-S94	Wheel Right
79	AM-SM-6048-S79	Handle Seat	95	AM-SM-6048-S95	Protection Plate
80	AM-SM-6048-S80	Walking Driven Pulley	96	AM-SM-6048-S96	Adjusting Screw Rod

SPARE PARTS DIAGRAM & PARTS LIST OF AM-SM-6048-7P-PRO STUBBLE MOWER

SL NO.	PART NO.	DESCRIPTION	SL NO.	PART NO.	DESCRIPTION
97	AM-SM-6048-S97	Brake Cable			
98	AM-SM-6048-S98	Brake Pad			
99	AM-SM-6048-S99	Spacer Bush			
100	AM-SM-6048-S100	Step Bolt			
101	AM-SM-6048-S101	Brake Cable Spring			
102	AM-SM-6048-S102	Handrail Adjustment Cable			
103	AM-SM-6048-S103	Rotating Seat			
104	AM-SM-6048-S104	Handrail			
105	AM-SM-6048-S105	"Curved Gasket			
106	AM-SM-6048-S106	Hexagon Head Bolt			
107	AM-SM-6048-S107	Tension Return Spring			
108	AM-SM-6048-S108	Wheel Frame Adjustment Knob			
109	AM-SM-6048-S109	Nylon Anti Loosening Nut			
110	AM-SM-6048-S110	Bearing Seat Cover Plate			
111	AM-SM-6048-S111	Flat Gasket			
112	AM-SM-6048-S112	Outer Flange Hexagon Bolt			