

# reader # ttyout

+ Start()

+ Error()

+ Start()

WT901Sensor

- + Calibrate()
- + CalibrateMagnetometer()
- + SetBaudRate() + SetPollingRate()
- + ToggleDormant() + SetGyroscopeAutoRecalibration()
- and 8 more... # CalculateAccelerationBias()

+ SetOrientation()

witmotion::jy901::QWitmotion JY901Sensor

- RegisteredPacketTypes() SetMeasurements()
- + QWitmotion[Y901Sensor()