

5. Signal-to-Quantization Noise Ratio (SQNR) Analysis

Simulate a full-scale sinusoidal signal using different word lengths and analyze the effect of quantization on the Signal-to-Quantization Noise Ratio (SQNR). (25) (BL5) (WK4)

Given Data:

- Input Signal = Full-scale sinusoid
- Sampling Frequency = 8 kHz
- Word Lengths = 4, 6, 8, 10, 12, 16 bits

Tasks:

1. Generate a full-scale sinusoidal signal.
2. Quantize the signal using the specified word lengths.
3. Compute the signal power.
4. Compute the quantization noise power.
5. Calculate the SQNR for each word length.
6. Compare the simulated SQNR values with the theoretical SQNR values and discuss the results.

Answers:

#CODE

```
%% Signal-to-Quantization Noise Ratio (SQNR) Analysis
```

```
% Tasks:
```

```
% 1. Generate a full-scale sinusoidal signal.
```

```
% 2. Quantize the signal using specified word lengths (4, 6, 8, 10, 12, 16 bits).
```

```
% 3. Compute signal power.
```

```
% 4. Compute quantization noise power.
```

```
% 5. Calculate SQNR for each word length.
```

```
% 6. Compare simulated vs. theoretical SQNR values.
```

```
clear; clc; close all;
```

%% 1. Given Data & Simulation Setup

fs = 8000; % Sampling Frequency = 8 kHz

fm = 100; % Signal Frequency = 100 Hz

t_final = 0.05; % Duration = 50 ms

t = 0 : 1/fs : t_final - (1/fs); % Time vector

A = 1.0; % Full-scale peak amplitude

word_lengths = [4, 6, 8, 10, 12, 16]; % Word lengths in bits

% Generate full-scale sinusoidal signal

x = A * sin(2 * pi * fm * t);

%% 2. Compute Input Signal Power

% Power of full-scale sinusoid: P_s = mean(x^2)

P_s = mean(x.^2);

%% 3. Quantization and SQNR Computation

num_bits = length(word_lengths);

P_n = zeros(1, num_bits);

sqnr_sim_db = zeros(1, num_bits);

sqnr_theo_db = zeros(1, num_bits);

fprintf('=====\n');

fprintf(' %-10s | %-12s | %-18s | %-18s \n', 'Bits (B)', 'Step Size', 'Theo SQNR (dB)', 'Sim SQNR (dB)');

fprintf('=====\n');

for i = 1:num_bits

 B = word_lengths(i);

 L = 2^B; % Number of quantization levels

 delta = (2 * A) / L; % Quantization step size

% Mid-rise uniform quantization

% Quantizes continuous signal into levels centered in intervals

```

x_quant = delta * (floor(x / delta) + 0.5);

% Quantization Error / Noise
e = x - x_quant;

% Quantization Noise Power
P_n(i) = mean(e.^2);

% Simulated SQNR in dB
sqnr_sim_db(i) = 10 * log10(P_s / P_n(i));

% Theoretical SQNR in dB: 6.02 * B + 1.76
sqnr_theo_db(i) = 6.02 * B + 1.76;

fprintf(' %-10d | %-12.6f | %-18.2f | %-18.2f \n', ...
        B, delta, sqnr_theo_db(i), sqnr_sim_db(i));
end

fprintf('=====\\n\\n');

%% 4. Plotting Results
% Plot 1: SQNR vs Word Length
figure('Name', 'SQNR Performance Analysis', 'NumberTitle', 'off');
plot(word_lengths, sqnr_theo_db, 'r--o', 'LineWidth', 2, 'MarkerSize', 8); hold on;
plot(word_lengths, sqnr_sim_db, 'b-s', 'LineWidth', 2, 'MarkerSize', 8);
grid on;
xlabel('Word Length B (bits)', 'FontSize', 12);
ylabel('SQNR (dB)', 'FontSize', 12);
title('Theoretical vs. Simulated SQNR', 'FontSize', 14);

```

```
legend('Theoretical (6.02B + 1.76 dB)', 'Simulated SQNR', 'Location', 'northwest');
```

```
% Plot 2: Original Signal vs Quantized Signals (Example: 4-bit vs 8-bit)
```

```
figure('Name', 'Quantization Waveforms', 'NumberTitle', 'off');
```

```
% 4-bit Quantization Waveform
```

```
delta_4 = (2 * A) / (2^4);
```

```
x_q4 = delta_4 * (floor(x / delta_4) + 0.5);
```

```
% 8-bit Quantization Waveform
```

```
delta_8 = (2 * A) / (2^8);
```

```
x_q8 = delta_8 * (floor(x / delta_8) + 0.5);
```

```
subplot(2,1,1);
```

```
plot(t * 1000, x, 'k', 'LineWidth', 1.5); hold on;
```

```
stepplot_4 = plot(t * 1000, x_q4, 'r', 'LineWidth', 1.2);
```

```
grid on;
```

```
xlabel('Time (ms)'); ylabel('Amplitude');
```

```
title('4-bit Uniform Quantization');
```

```
legend('Original Signal', '4-bit Quantized');
```

```
subplot(2,1,2);
```

```
plot(t * 1000, x, 'k', 'LineWidth', 1.5); hold on;
```

```
plot(t * 1000, x_q8, 'b', 'LineWidth', 1.2);
```

```
grid on;
```

```
xlabel('Time (ms)'); ylabel('Amplitude');
```

```
title('8-bit Uniform Quantization');
```

```
legend('Original Signal', '8-bit Quantized');
```

Output:

Bits (B)	Step Size	Theo SQNR (dB)	Sim SQNR (dB)
4	0.125000	25.84	25.42
6	0.031250	37.88	38.33
8	0.007812	49.92	48.99
10	0.001953	61.96	61.17
12	0.000488	74.00	73.27
16	0.000031	98.08	97.56



