PAR lamps LED digital display instructions

1.DMX512 Channel Description

NO.	Function	Explain	
1-Passage	Total dimming	0-255	R、G、B、total dimming, linear dimming from dark to light
2-Channel	R dimming	0-255	R dimming, linear dimming from dark to light
3-Channel	G dimming	0-255	G dimming, linear dimming from dark to light
4-Channel	B dimming	0-255	B dimming, linear dimming from dark to light
5		0-3	No Strobe
		4-255	Strobe
6		0-49	No1-7 Channel Effect
		50-99	Jump Change
		100-149	Gradient Change
		150-199	Pluse Change
		200-255	Sound Control
7		0-255	Effect Speed Corresponds to the speed of the 6-channel function,from slow to fast

2.Menu Show

d001-d512	DMX DMX address code
CL00-CL99	0-99 Pulse Change auto mode, speed 0-99 file
CE00-CE99	0-99 Jump Change auto mode, speed 0-99 file
CP00-CP99	0-99 Gradient change auto mode,speed 0-99 file
bEbE	Sound Control
R00-R255	0-255 Red from dark to bright,0-255 adjustable
G00-G255	0-255 Green from dark to bright,0-255 adjustable
B00-B255	0-255 Blue from dark to bright,0-255 adjustable
CF00-CF99	0-99 StrobeMode, Speed from slow to
Co00-Co06	Control Selection

CF CE CL CP

CF Strobe CE Gradient CL Jump Change CP Pluse change