

Handbook NOODEL - 33 NOde COmfort MoDEL

Aachen, November 2018

Dr.-Ing. Rita Streblow

E.ON Energy Research Center | ERC Institute for Energy Efficient Buildings and Indoor Climate | EBC Mathieustraße 10, 52074 Aachen

NOODEL

NOODEL (33 NOde COmfort MoDEL) consists of a thermo-physiological human body model and a psychological model for predicting thermal sensation and comfort derived from the physiological state of the body. NOODEL allows the analysis of thermal comfort within different indoor environments. The model was developed using literature data and own test person experiments in mixed and displacement ventilation systems. The test cases represent only a part of interior situations. Validation cases show a good agreement between calculated and experimental data for temperature drifts and temperature jumps at medium temperature levels. For more complex interior situations, no conclusive statement on the quality of the model can be made with the current data sets. However, the model is continuously extended by new experimental data.

NOODEL Library

The Modelica NOODEL library consists of different packages.

BaseClasses

The package BaseClasses includes the main basic classes for the passive system of the human body including convective and conductive heat transfer.

Components

The package Components integrates the packages compartments and segments.

Compartments

NOODEL is a multi segment thermal comfort model. Each body segment is subdivided into a skin and a core layer. All segments are interconnected by a central blood compartment. The two layers include the basic functions of the passive system and the local calculation of the error signal to activate the active system.

Segments

NOODEL consists of 16 body parts ((head, chest, back, pelvis, shoulder, arm, hand, thigh, leg, foot). Based on a partial bodypart model the specific body parts are described with its specific surface area, weight, set point temperatures and coefficients for the active and passive system.

Functions

The package *Functions* includes the functions of the psychological model. The psychological model used here derives the feeling of comfort from the skin temperature determined by the physiological model. A distinction is made between the local thermal sensation TSI of the individual body parts and the thermal sensation for the entire body TSo. The evaluation is based on a 7-point scale from -3 for cold to 3 for warm, as in the survey of the test group.

The local thermal comfort TCl and the global comfort TCo can be derived from the thermal sensation. The evaluation is also based on a 7-point scale from -3 for very uncomfortable to 3 for very comfortable.

Interfaces

The package *Interfaces* includes all different kinds of connectors. It also includes the *Parameter* component which provides system-wide settings, such as ambient conditions, intial skin and core temperature and position of the human body.

Model

The Model package includes the NOODEL model

Non SI units

The model includes several non SI units which are defined in this package.

Application

The given model *NOODEL standalone* in the package *Model* is developed to run as a standalone model which means all boundary conditions of the environment are specified.




Figure 1: Noodel model in the graphical user interface

The boundary conditions are specified within a text file. The file has to be defined within the *InputData* block under *FileName*. Some examples of text files can be found within the folder *DataBase*. The text files specify the boundary conditions of different validation test cases from literature.




Figure 2: Definition of the file with the input data

Structure of the InputData text file

The first two lines are fixed. With table(x,y) the dimensions of the matrix are given. X has to be adjusted for the individual cases as it gives the number of rows which correspond to the number of given timesteps.

#1 double table(x, 132)

The matrix has 132 columns. Within the matrix the order of the 16 body segments is always the following

head, chest, back, pelvis, right shoulder, left shoulder, right arm, left arm, right hand, left hand, right thigh, left thigh, right leg, left leg, right foot, left foot

Figure 3: Extraction of the input text file

The columns have the following data:

1	Time step in seconds
2 – 17	Air temperature in °C at all 16 body segments
18 – 33	Radiative temperature in °C at all 16 body segments
34 – 49	Air velocity in m/s at all 16 body segments
50	relative air humidity
51	Metabolic rate in met
52 – 67	Local clothing value in clo at all 16 body segments
68 – 83	Relative local surface area in contact with material
84 – 99	Local contact temperature of material in °C
100 – 115	Relative local surface area exposed to solar irradiation
116 – 131	Solar irradiation on local body part in W
132 Position:	0 – sitting, 1 - standing

Under *Parameters* the initial skin and core temperature can be given.




Figure 4: Specification of initial skin and core temperature within Parameters

Evaluation

TC Overall – Overall thermal comfort on a seven point scale with -3 very uncomfortable to 3 very comfortable

TS overall – Overall thermal sensation on a seven point scale with -3 cold to 3 hot

TCl – Local thermal comfort for all 16 body parts

TSI – Local thermal sensation for all 16 body parts