



AIRPORT INFORMATION

OSLO AIRPORT - OSL - ENGM

HRS of operation (LT)

Airport:	H24
Customs:	H24
Immigration:	H24
Fuel services:	H24
Met office:	H24
FBO Terminal:	06:00 - 23:00
RMK: 24 HRS notice if extension is required	
FBO Office:	H24

FBO-terminal facilities

Security screening:	Yes
Customs:	Yes
Immigration:	Yes
Check-in service:	Yes
Baggage drop:	Yes
Lounges:	Yes
Rest rooms:	Yes
Wheelchair:	Yes
Car parking:	Yes

FBO services

VIP transport
Board to board service
VIP-catering
Aircraft charter

Crew transport
Slot coordination
Accommodation
Flight planning/supervision

Towing
A/C Parking
Fuelling
Cabin cleaning

Airport facilities

Airport elevation:	681 ft
Fire and rescue:	CAT 9 / H24
Fuel type:	Jet A1 / 100 LL / F34
De-ice:	Freq: 121,850 Mhz
Hangar:	Limited space
Met office:	Tel: +47 64 81 90 00
Runway surfaces:	CONC + ASPH
RWY 01L/19R:	3600 x 45 m
RWY 01R/19L:	2950 x 45 m
Transponder:	SSR compulsory IFR/VFR
SITA:	OSLACXH

FBO contact - Access Oslo AS

Telephone:	+47 91 222 999
E-mail:	ops@accessoslo.no
Freq:	131,425 Mhz
Address:	General Aviation Terminal Oslo Airport West Hans Gaarders veg 2060 Gardermoen, Norway

FBO facilities

Check-in desk
Meeting rooms
Internet access


New VIP-lounges
New crew lounge
Briefing rooms

FBO equipment

Towing truck
Lavatory truck
Water truck

GA-tow bars
Air stair
GPU115/28 V

Airport FBO map





VIP - TERMINAL

OSLO AIRPORT - OSL - ENGM


Reception area



Apron



Terminal



Crew lounge



access
OSLO
NEWS

Access Oslo opened the new FBO at Torp Airport May 2016
Brand new VIP and crew lounges at Oslo airport
New website to be launched October 2016

How to get there

Hans Gaarders Veg
2060 Gardermoen

Driving time to
Oslo centre: 0:35 min

