












### Power Bus Capacitance







Rack-Manager

Sheet: /Power Input/  
File: power\_input.kicad\_sch

**Title: Power Input Stage**

Size: A3 Date: 2025-10-30  
KiCad E.D.A. 9.0.6-rc2

Rev: v0.1  
Id: 2/6



Rack-Manager

Sheet: /DC-DC/  
File: DCDC.kicad\_sch


**Title: DC-DC converter Stage**









Size: A4 Date: 2025-10-30

KiCad E.D.A. 9.0.6-rc2

**Rev: v0.1**

Id: 3/6





|   |   |   |   |   |   |
|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 |
| A |   |   |   |   | A |
| B |   |   |   |   | B |
| C |   |   |   |   | C |
| D |   |   |   |   | D |
| 1 | 2 | 3 | 4 | 5 | 6 |

|                                          |                  |           |
|------------------------------------------|------------------|-----------|
| Rack-Manager                             |                  |           |
| Sheet: /RS-485/<br>File: rs485.kicad_sch |                  |           |
| Title:                                   |                  |           |
| Size: A4                                 | Date: 2025-10-30 | Rev: v0.1 |
| KiCad E.D.A. 9.0.6-rc2                   |                  | Id: 6/6   |