














Rack-Manager		
Sheet: /Power Input/ File: power_input.kicad_sch		
Title: Power Input Stage		
Size: A3	Date: 2025-10-30	Rev: v0.1
KiCad E.D.A. 9.0.6-rc2		Id: 2/6



Rack-Manager

Sheet: /DC-DC/
File: DCDC.kicad_sch


Title: DC-DC converter Stage









Size: A4 Date: 2025-10-30

KiCad E.D.A. 9.0.6-rc2

Rev: v0.1

Id: 3/6





	1	2	3	4	5	6
A						
B						
C						
D						
	1	2	3	4	5	6

Rack-Manager		
Sheet: /RS-485/ File: rs485.kicad_sch		
Title:		
Size: A4	Date: 2025-10-30	Rev: v0.1
KiCad E.D.A. 9.0.6-rc2		Id: 6/6