


CONTROL SYSTEM (MANUAL)



CS-00342

(1) Knob

(2) Lever

(3) Cushion rubber

(4) Boot

(5) Stay

(6) Bushing B

(7) Joint

(8) Rod

CS-2