


Toggle the table of contents

# p-n junction

A **p–n junction** is a boundary or interface between two types of semiconductor materials, p-type and n-type, inside a single crystal of semiconductor. The "p" (positive) side contains an excess of holes, while the "n" (negative) side contains an excess of electrons in the outer shells of the electrically neutral atoms there. This allows electrical current to pass through the junction only in one direction. The p-n junction is created by doping, for example by ion implantation, diffusion of dopants, or by epitaxy (growing a layer of crystal doped with one type of dopant on top of a layer of crystal doped with another type of dopant).



A p—n junction. The circuit symbol is shown: the triangle corresponds to the p side.


p—n junctions are elementary "building blocks" of <u>semiconductor electronic devices</u> such as <u>diodes</u>, <u>transistors</u>, <u>solar cells</u>, <u>light-emitting diodes</u> (LEDs), and <u>integrated circuits</u>; they are the active sites where the electronic action of the device takes place. For example, a common type of <u>transistor</u>, the <u>bipolar junction transistor</u> (BJT), consists of two p—n junctions in series, in the form n—p—n or p—n—p; while a diode can be made from a single p-n junction. A <u>Schottky junction</u> is a special case of a p—n junction, where metal serves the role of the n-type semiconductor.

# History

The invention of the p–n junction is usually attributed to American physicist <u>Russell Ohl</u> of <u>Bell Laboratories</u> in 1939. Two years later (1941), <u>Vadim Lashkaryov</u> reported discovery of p–n junctions in  $Cu_2O$  and silver sulphide <u>photocells</u> and selenium rectifiers.

# **Properties**

The p—n junction possesses a useful property for modern semiconductor electronics. A p-doped semiconductor is relatively <u>conductive</u>. The same is true of an n-doped semiconductor, but the junction between them can become <u>depleted</u> of <u>charge carriers</u>, and hence non-conductive, depending on the relative voltages of the two semiconductor regions. By manipulating this non-conductive layer, p—n junctions are commonly used as <u>diodes</u>: circuit elements that allow a flow of <u>electricity</u> in one direction but not in the other (opposite) direction.



Silicon atoms (Si) enlarged about 45,000,000x

*Bias* is the application of a voltage relative to a p—n junction region:

- Forward bias is in the direction of easy current flow
- Reverse bias is in the direction of little or no current flow.

The forward-bias and the reverse-bias properties of the p—n junction imply that it can be used as a <u>diode</u>. A p—n junction diode allows electric charges to flow in one direction, but not in the opposite direction; negative charges (electrons) can easily flow through the junction from n to p but not from p to n, and the

reverse is true for holes. When the p—n junction is forward-biased, electric charge flows freely due to reduced resistance of the p—n junction. When the p—n junction is reverse-biased, however, the junction barrier (and therefore resistance) becomes greater and charge flow is minimal.

## **Equilibrium (zero bias)**

In a p—n junction, without an external applied voltage, an equilibrium condition is reached in which a potential difference forms across the junction. This potential difference is called *built-in potential*  $V_{bi}$ .

At the junction, some of the free electrons in the n-type wander into the p-type due to random thermal migration. As they diffuse into the p-type they combine with holes, and cancel each other out. In a similar way some of the positive holes in the p-type wander into the n-type and combine with free electrons, and cancel each other out. The positively charged, donor, dopant atoms in the n-type are part of the crystal, and cannot move. Thus, in the n-type, a region near the junction becomes positively charged. The negatively charged, acceptor, dopant atoms in the p-type are part of the crystal, and cannot move. Thus, in the p-type, a region near the junction becomes negatively charged. The result is a region near the junction that acts to repel the mobile charges away from the junction through the electric field that these charged regions create. The regions near the p-n interface lose their neutrality and most of their mobile carriers, forming the space charge region or depletion layer (see figure A).




Figure A. A p—n junction in thermal equilibrium with zero-bias voltage applied. Electron and hole concentration are reported with blue and red lines, respectively. Gray regions are charge-neutral. Light-red zone is positively charged. Light-blue zone is negatively charged. The electric field is shown on the bottom, the electrostatic force on electrons and holes and the direction in which the diffusion tends to move electrons and holes. (The log concentration curves should actually be smoother with slope varying with field strength.)

The <u>electric field</u> created by the space charge region opposes the diffusion process for both electrons and holes. There are two concurrent phenomena: the diffusion process that tends to generate more space charge, and the electric field generated by the space charge that tends to counteract the diffusion. The carrier concentration profile at equilibrium is shown in <u>figure A</u> with blue and red lines. Also shown are the two counterbalancing phenomena that establish equilibrium.

The space charge region is a zone with a net charge provided by the fixed ions (donors or acceptors) that have been left *uncovered* by majority carrier diffusion. When equilibrium is reached, the charge density is approximated by the displayed step function. In fact, since the y-axis of figure A is log-scale, the region is almost completely depleted of majority carriers (leaving a charge density equal to the net doping level), and the edge between the space charge region and the neutral region is quite sharp (see figure B, Q(x) graph). The space charge region has the same magnitude of charge on both sides of the p—n interfaces, thus it extends farther on the less doped side in this example (the n side in figures A and B).

#### **Forward bias**


In forward bias, the p-type is connected with the positive terminal and the n-type is connected with the negative terminal. The panels show **energy band diagram**, **electric field**, and **net charge density**. Both p and n junctions are doped at a 1e15 cm<sup>-3</sup> (160  $\mu$ C/cm<sup>3</sup>) doping level, leading to built-in potential of ~0.59 V. Reducing depletion width can be inferred from the shrinking carrier motion across the p-n junction, which as a consequence reduces electrical resistance. Electrons that cross the p-n junction into the

p-type material (or holes that cross into the n-type material) diffuse into the nearby neutral region. The amount of minority diffusion in the near-neutral zones determines the amount of current that can flow through the diode.


Only <u>majority carriers</u> (electrons in n-type material or holes in p-type) can flow through a semiconductor for a macroscopic length. With this in mind, consider the flow of electrons across the junction. The forward bias causes a force on the electrons pushing them from the N side toward the P side. With forward bias, the depletion region is narrow enough that electrons can cross the junction and *inject* into the p-type material. However, they do not continue to flow through the p-type material indefinitely, because it is energetically favorable for them to recombine with holes. The average length an electron travels through the p-type material before recombining is called the *diffusion length*, and it is typically on the order of micrometers. [3]

Although the electrons penetrate only a short distance into the p-type material, the electric current continues uninterrupted, because holes (the majority carriers) begin to flow in the opposite direction. The total current (the sum of the electron and hole currents) is constant in space, because any variation would cause charge buildup over time (this is Kirchhoff's current law). The flow of holes from the p-type region into the n-type region is exactly analogous to the flow of electrons from N to P (electrons and holes swap roles and the signs of all currents and voltages are reversed).

Therefore, the macroscopic picture of the current flow through the diode involves electrons flowing through the ntype region toward the junction, holes flowing through the ptype region in the opposite direction toward the junction, and



**Figure B.** A p—n junction in thermal equilibrium with zero-bias voltage applied. Under the junction, plots for the charge density, the electric field, and the voltage are reported. (The log concentration curves should actually be smoother, like the voltage.)




PN junction operation in forward-bias mode, showing reducing depletion width.

the two species of carriers constantly recombining in the vicinity of the junction. The electrons and holes travel in opposite directions, but they also have opposite charges, so the overall current is in the same direction on both sides of the diode, as required.

The <u>Shockley diode equation</u> models the forward-bias operational characteristics of a p—n junction outside the avalanche (reverse-biased conducting) region.

#### Reverse bias

Connecting the *p-type* region to the *negative* terminal of the voltage supply and the *n-type* region to the *positive* terminal corresponds to reverse bias. If a diode is reverse-biased, the voltage at the <u>cathode</u> is comparatively higher than at the <u>anode</u>. Therefore, very little current flows until the diode breaks down. The connections are illustrated in the adjacent diagram.



A silicon p-n junction in reverse bias

Because the p-type material is now connected to the negative terminal of the power supply, the 'holes' in the p-type material are pulled away from the junction, leaving behind charged ions and causing the width of the depletion region to increase. Likewise, because the n-type region is connected to the positive terminal, the electrons are pulled away from the junction, with similar effect. This increases the voltage barrier causing a high resistance to the flow of charge carriers, thus allowing minimal electric current to cross the p-n junction. The increase in resistance of the p-n junction results in the junction behaving as an insulator.

The strength of the depletion zone electric field increases as the reverse-bias voltage increases. Once the electric field intensity increases beyond a critical level, the p—n junction depletion zone breaks down and current begins to flow, usually by either the <u>Zener</u> or the <u>avalanche breakdown</u> processes. Both of these breakdown processes are non-destructive and are reversible, as long as the amount of current flowing does not reach levels that cause the semiconductor material to overheat and cause thermal damage.

This effect is used to advantage in Zener diode regulator circuits. Zener diodes have a low <u>breakdown</u> <u>voltage</u>. A standard value for breakdown voltage is for instance 5.6 V. This means that the voltage at the cathode cannot be more than about 5.6 V higher than the voltage at the anode (though there is a slight rise with current), because the diode breaks down, and therefore conduct, if the voltage gets any higher. This, in effect, limits the voltage over the diode.

Another application of reverse biasing is <u>Varactor</u> diodes, where the width of the <u>depletion zone</u> (controlled with the reverse bias voltage) changes the capacitance of the diode.

# **Governing equations**

#### Size of depletion region

For a p-n junction, let  $C_A(x)$  be the concentration of negatively-charged acceptor atoms and  $C_D(x)$  be the concentrations of positively-charged donor atoms. Let  $N_0(x)$  and  $P_0(x)$  be the equilibrium concentrations of electrons and holes respectively. Thus, by Poisson's equation:

$$-rac{\mathrm{d}^2 V}{\mathrm{d}x^2} = rac{
ho}{arepsilon} = rac{q}{arepsilon} \left[ (P_0 - N_0) + (C_D - C_A) 
ight]$$

where V is the <u>electric potential</u>,  $\rho$  is the <u>charge density</u>,  $\varepsilon$  is <u>permittivity</u> and q is the magnitude of the electron charge.

For a general case, the dopants have a concentration profile that varies with depth x, but for a simple case of an abrupt junction,  $C_A$  can be assumed to be constant on the p side of the junction and zero on the n side, and  $C_D$  can be assumed to be constant on the n side of the junction and zero on the p side. Let  $d_p$  be the width of the depletion region on the p-side and  $d_n$  the width of the depletion region on the n-side. Then, since  $P_0 = N_0 = 0$  within the depletion region, it must be that

$$d_p C_A = d_n C_D$$

because the total charge on the p and the n side of the depletion region sums to zero. Therefore, letting D and  $\Delta V$  represent the entire depletion region and the potential difference across it,

$$\Delta V = \int_D \int rac{q}{arepsilon} \left[ (P_0 - N_0) + (C_D - C_A) 
ight] \, \mathrm{d}x \, \mathrm{d}x = rac{C_A C_D}{C_A + C_D} rac{q}{2arepsilon} (d_p + d_n)^2$$

And thus, letting d be the total width of the depletion region, we get

$$d = \sqrt{rac{2arepsilon}{q}rac{C_A + C_D}{C_A C_D}\Delta V}$$

 $\Delta V$  can be written as  $\Delta V_0 + \Delta V_{\rm ext}$ , where we have broken up the voltage difference into the equilibrium plus external components. The equilibrium potential results from diffusion forces, and thus we can calculate  $\Delta V_0$  by implementing the Einstein relation and assuming the semiconductor is nondegenerate (i.e., the product  $P_0 N_0 = n_i^2$  is independent of the Fermi energy):

$$\Delta V_0 = rac{kT}{q} \ln\!\left(rac{C_A C_D}{P_0 N_0}
ight) = rac{kT}{q} \ln\!\left(rac{C_A C_D}{n_i^2}
ight)$$

where T is the temperature of the semiconductor and k is Boltzmann constant. [4]

## **Current across depletion region**

The <u>Shockley ideal diode equation</u> characterizes the current across a p—n junction as a function of external voltage and ambient conditions (temperature, choice of semiconductor, etc.). To see how it can be derived, we must examine the various reasons for current. The convention is that the forward (+) direction be pointed against the diode's built-in potential gradient at equilibrium.

- Forward current  $(\mathbf{J}_F)$ 
  - Diffusion current: current due to local imbalances in carrier concentration n, via the equation  $\mathbf{J}_D \propto -q \nabla n$
- Reverse current ( $\mathbf{J}_R$ )
  - Field current
  - Generation current

#### See also

- Alloy-junction transistor
- Capacitance-voltage profiling
- Deep-level transient spectroscopy
- Delocalized electron
- Diode modelling

- Field-effect transistor
- n-p-n transistor
- p—n—p transistor
- Semiconductor detector
- Semiconductor device
- Transistor-transistor logic

#### References

- 1. Riordan, Michael; Hoddeson, Lillian (1988). Crystal Fire: The Invention of the Transistor and the Birth of the Information Age (https://books.google.com/books?id=SZ6wm5ZSUmsC&pg=PA92). W. W. Norton & Company. pp. 88–97. ISBN 978-0-393-31851-7.
- 2. Lashkaryov, V. E. (2008) [1941]. "Investigation of a Barrier Layer by the Thermoprobe Method" (https://web.archive.org/web/20150928014344/http://ujp.bitp.kiev.ua/files/journals/5 3/si/53SI11p.pdf) (PDF). *Ukr. J. Phys.* **53** (special edition): 53–56. ISSN 2071-0194 (https://www.worldcat.org/issn/2071-0194). Archived from the original (http://ujp.bitp.kiev.ua/files/journals/53/si/53SI11p.pdf) (PDF) on 2015-09-28.
- 3. Hook, J. R.; H. E. Hall (2001). *Solid State Physics*. John Wiley & Sons. <u>ISBN</u> <u>978-0-471-</u> 92805-8.
- 4. Luque, Antonio; Hegedus, Steven (29 March 2011). <u>Handbook of Photovoltaic Science and Engineering</u> (https://books.google.com/books?id=sLMkCsde1u4C). John Wiley & Sons. ISBN 978-0-470-97612-8.

# **Further reading**

Shockley, William (1949). "The Theory of p-n Junctions in Semiconductors and p-n Junction Transistors". *Bell System Technical Journal*. 28 (3): 435–489. doi:10.1002/j.1538-7305.1949.tb03645.x (https://doi.org/10.1002%2Fj.1538-7305.1949.tb03645.x).

## **External links**

- The PN Junction. How Diodes Work? (English version) (https://www.youtube.com/watch?v= JBtEckh3L9Q) Educational video on the P-N junction.
- "P-N Junction" (http://www.powerguru.org/2012/08/22/p-n-junction/) PowerGuru, August, 2012.

Retrieved from "https://en.wikipedia.org/w/index.php?title=P-n junction&oldid=1161406756"

Toggle limited content width