<EasyArduino.h>

Library Creator

Md Hasemi Rafsan Jani Shohan

BSC in EEE

Daffodil International University

Embedded System Engineer

Contact Click

A0	2
A1	3
A2	4
A3	5
A4	7
A5	8
A6	9
A7	10
D0	19
D1	20
D2	21
D3	22
D4	27
D5	28
D6	29
D7	30
D8	33
D9	34
D10	35
D11	36

D12	37
D13	38
D14	39
D15	40

Pin Specefication



Biasing 16F77A

Function parameter

- **digitalRead(D0);**
- **digitalWrite (D0,HIGH);**
- **digitalWrite (D0,LOW);**
- **analogRead(A0);**
- **Serial_print1(float);**
- **Serial_print2(integer);**
- **Serial_print3(string);**
- **map(x,min.max,min.max);**
- **constrain(x,min,max);**
- **delay(ms);**
- **max(a,b);**
- **min(a,b);**
- **voidloop()**
- **void setup()**
- **D0……..D15**
- **A0……..A7**

```
#include <16F877A.h>
#device ADC=8
#use delay(crystal=20Mhz)
#include <EasyArduino.h>
#fuses HS

void setup()
{

voidloop()
{
digitalWrite(D0,HIGH);
delay(500);
digitalWrite(D0,LOW);
delay(500);
}
}
```

//Code1: LED Blynk

```
#include <16F877A.h>
#device ADC=8
#use delay(crystal=20Mhz)
#include <EasyArduino.h>
#fuses HS
void setup()
{
voidloop()
{
int v = digitalRead(D8);
if(v==1)
{
digitalWrite(D0,HIGH);
}
else
{
digitalWrite(D0,LOW);
}
}
}
```

//Code2: Digital Input and Digital Output1

```
#include <16F877A.h>
#device ADC=8
#use delay(crystal=20Mhz)
#include <EasyArduino.h>
#fuses HS
void setup()
{
voidloop()
{
int v = digitalRead(D8);
digitalWrite(D0,v);
}
}
```

//Code3: Digital Input and Digital Output2

```
#include <16F877A.h>
#device ADC=8
#use delay(crystal=20Mhz)
#include <EasyArduino.h>
#fuses HS

void setup()
{

voidloop()
{
float v = analogRead(A0);
Serial_print1(v);
delay(5000);
}
}
```

//Code3: AnalogRead[0--1024] with Serial_print

```
#include <16F877A.h>
#device ADC=8
#use delay(crystal=20Mhz)
#include <EasyArduino.h>
#fuses HS

void setup()
{

voidloop()
{
float v = analogRead(A0);
v = map(v,0,1024,0,100); // 0---1024 range to set 0--100
Serial_print1(v);
delay(5000);
}
}
```

//Code4: MAP Function with Serial_print

```
#include <16F877A.h>
#device ADC=8
#use delay(crystal=20Mhz)
#include <EasyArduino.h>
#fuses HS

void setup()
{

voidloop()
{
float v = analogRead(A0);
v = constrain(v,0,100); // (return 0)0< v >100(return 100)
Serial_print1(v);
delay(5000);
}
}
```

//Code5: Constrain Function with Serial_print

```
#include <16F877A.h>
#device ADC=10
#use delay(crystal=20Mhz)
#include <EasyArduino.h>
# fuses HS
# include <lcd.c>

void main(){
lcd_init();

 while(TRUE){
    float i = 2.22;
    char cc[] = "abcd";
    int in = 12;
    //lcd_print1(i);
    lcd_print2(in);
    //lcd_print3(cc);
    delay(500);
   }
}
```

//Code6: LCD Display operating


UART 877 - ISIS Professional (Animating)
File View Edit Tools Design Graph Source Debug Library Template System Help
DEVICES
2WATT220R
BUTTON
LED-BLUE
LM016L
PIC16F877A
POT
POT-LIN
U1
R1
220R
D1
LED-BLUE
PIC16F877A
6 Message(s)
PAUSED: 00:00:05.100000
Search
10:18 AM

//Code1


UART 877 - ISIS Professional (Animating)
File View Edit Tools Design Graph Source Debug Library Template System Help
INSTRUMENTS
OSCILLOSCOPE
LOGIC ANALYSER
COUNTER TIMER
VIRTUAL TERMINAL
SPI DEBUGGER
I2C DEBUGGER
SIGNAL GENERATOR
PATTERN GENERATOR
DC VOLTMETER
DC AMMETER
AC VOLTMETER
AC AMMETER
U1
R1
220R
D1
LED-BLUE
PIC16F877A
6 Message(s)
ANIMATING: 00:00:09.450000 (CPU load 43%)
Search
10:33 AM

//Code2



//Code3,4,5



//Code6



//Code6

//User Instruction//

- **Use PIC 16F877A Microcontroller**
- **Use PIC C Compiler**

Library Download Link