A calculative amalgamation of available sound sensor and knowledge of Python programming with regard to have a real time surveillance on the random and disturbing sound intensities around the  $\bf No$  Noise and/or Low Noise Areas in a region e.g. Hospitals, Schools, Sensitive areas in a region, Research labs, etc. and sending a real time alert to the concerned Police officials about any disturbing noise created in any of the places or areas above mentioned via Telegram Messaging App.

## Things used in this project:

#### Hardware Components

- 1. Bolt WiFi Module
- 2. Sound Detection Sensor Module.

# Software Apps and Online Services:

1. Telegram Messaging App.

### Hardware setup:

Step 1]Connect the sound sensor with the Bolt WiFi module as per the following:

- 1. **AO Pin** (Bolt IoT Wi-Fi Module- GPIO) is connected to **AO Pin** (Sound Sensor).
- 2. **GND Pin** (Bolt IoT Wi-Fi Module) is connected to **GND Pin** (Sound Sensor).

  3. **5V Pin** (Bolt IoT Wi-Fi Module) is connected to **"+" Pin** (Sound Sensor).

Step 21 Power up the Bolt WiFi module using the USB cable

## Software setup:

### Creating a Telegram Channel:

- Open your Telegram App and swipe left open the Main Menu and tap on the feature New Channel.
- Give a suitable name to the channel and provide description to it.
- Set the channel as Public Channel and provide a permanent link to it by giving a suitable name. **Note:** Space between words is not allowed.
- Now we need to create a Telegram Bot.

## Creating a Telegram Bot:

- After creating the Telegram Channel come back to the home page of the Telegram and search for the **BotFather** in the search menu.
- After opening the BotFather enter the command /start to create the bot.
- To create a new bot enter the command **/newbot** and give a suitable name to the hot
- Secondly we need to give the username to the bot created it should be ending with the bot e.g.  ${\bf usernamebot}$
- Now a API Key will get generated store that API Key as it have to be used in the coding.

# Linking the Telegram Channel and Telegram Bot:

- Now that we have created both Telegram Channel and Telegram Bot next we need to link them both together.
- To do that open your channel and tap on the channel name and then click on the Administrator button and search for the bot name you have created.

# Coding:

The you. We use this information in order to improve and custodies are used to collect information about how you interact with our website and allow us the you. We use this information in order to improve and customize your browsing experience and for analytics and metrics about our visitors this website and other media. To find out more about the coolies we use, see our Privacy Policy.



To create above two mention files, executive the following steps:

Open the Digital Ocean Ubuntu server (For Windows /Mac Operating System) or open the terminal in the Ubuntu Operating System.

Step 1] We need to create a directory (folder) to store the two coding files mentioned above. To create a directory named alert, type out the following command

sudo mkdir alert

Step 2] Next we have to enter the directory that we just created. To enter the  $\,$ directory named alert type out the following command:

Step 3] After entering the folder first we need to create the configuration python file which will hold all the backend details of the Bolt IoT Wi-Fi Module and Telegram.

```
To create the configuration python file in the folder which was created first type out the following command for creating the file with extension .py;
```

sudo nano configuration.py

Step 4] After the above mentioned file enter the following data into the file. Make sure that you add the updated Bolt API key, device id and Telegram details:

"""Configurations for Telegram alert message"""

BOLT\_API\_KEY = "XXXXXXXXXXX #This is your Bolt cloud API
Key.

DEVICE\_ID = "XXXXXXXXXX #This is the ID number of your
Bolt device.

TELEGRAM\_BOT\_ID = "botXXXXXXXXX" #This is the bot ID of the bot created in the Telegram. Paste

THRESHOLD = 80 #Threshold beyond which the alert should be sent.

Step 5] Save the file by clicking "ctrl+x" and press enter. Next create another file which will include the main coding of the facility.

sudo nano alert.py


```
Step 6] Enter the following code into the newly created file
 import json
                                   #library for handling JSON data
#module for sleep operation
 import time
 from boltiot import Bolt #importing Bolt from boltiot
                                       module
                                    #configuration file
 import configuration
 mybolt = Bolt(configuration.BOLT_API_KEY,configuration.DEVICE_I
def get_sound_sensor_value_from_pin(pin):
 response = mybolt.analogRead(pin)
 data = json.loads(response)
      if data["success"] != 1:
            print("Request not successful")
              print("This is the response->", data)
             return -999
         sound_sensor_value = int(data["value"])
         return sound_sensor_value
 except Exception as e:
 print("Something went wrong when returning the sensor value")
         print(e)
      return -999
 def send_telegram_message(message):
 url = "https://api.telegram.org/" + configuration.TELEGRAM_BOT_ID + "/sendMessage"
 data = {
          "chat_id": configuration.TELEGRAM_CHAT_ID,
          "text": message
         response = requests.request(
              "GET",
             url,
             params = data
         print("This is the Telegram response")
         print(response.text)
         telegram_data = json.loads(response.text)
 return telegram_data["OK"]
     except Exception as
 print("An error occurred in sending the alert message via Telegram")
        print(e)
         return False
 while True:
    sound_sensor_value = get_sound_sensor_value_from_pin("A0")
print("The current sensor reading is:", sound_sensor_value)
    if sound_sensor_value == -999:
         print("Request was unsuccessful. Skipping.")
     time.sleen(10)
         continue
     #Step 3
    if sound_sensor_value >= configuration.THRESHOLD:
 print("Sensor value has exceeded threshold")
 message = "Alert! Noise disturbance around the XYZ Hospital. Random and unidentified sound intensity has crossed " + str(configuration.THRESHOLD) + str("dB") + \
"The current sound sensor reading is " + str(sound_sensor_value + str("dB") + str("To, The Police Incharge, Immediate action required. Thankyou.")
 telegram_status = send_telegram_message(message)
 print("This is the Telegram status:", telegram_status)
 # Step 4
 time.sleep(50) #Time interval to get the status update.
```

Step 7] Exit the code editor using "ctrl+x" and then run the code that you have written using the following command.

sudo python3 alert.py

Conclusion

An alert message is expected on your Telegram channel. Possible output as follows also the alert message can be customised as per the requirement:



### Want to build more such IoT and ML projects? Want to learn IoT and ML from basics?

Check out the Bolt IoT and ML training. This online video training is excellent for those who want to start with IoT and ML because it teaches you to build projects from the basics. Click on the button below to know more about the training.

Q 57 ®







