

Setting the display time

Perform one or more of the following actions to set the time the display shows while it is idle.

- a . Disable Set time automatically.
- b . Select Date.
- c . Specify the date, and then select OK.
- d . Select Time.
- e . Specify the time, and then select OK.