

Table of contents

Getting started	2
Changing the input	2
Care and cleaning	3

Getting started

The display supports a wide range of input sources and can be mounted in either orientation. Before installing it, check that the mounting surface can carry at least four times the weight of the display.

Changing the input

To change the input source, open the System Settings menu, select Input, and choose the source you want to use. The display remembers the last source that was selected and returns to it the next time it is powered on.

4. Navigate to the bottom of the page and choose the desired action.

Care and cleaning

Clean the screen with a soft, dry cloth. Never spray liquid directly onto the display surface, and never use cleaning products that contain alcohol.

Q&A

Why is there no picture? Check that the cable is connected. See page 3.