



MANUAL TOOLS COMPANY

Manufacturer of Coke Oven Machinery



30+ YEARS OF
EXCELLENCE

Ravindra Kr. Agarwal, Prop.

Dhanbad, Jharkhand | manualtoolsco.com



COAL CHARGING CAR

TOP FEED - COKE OVEN MACHINERY SERIES



KEY CAPABILITY:

A rail-mounted charging car (larry car) for top charging of coke ovens. Four conical hoppers deliver measured coal into the oven chambers.

PERFORMANCE

- ✓ Hopper Capacity: 4 / 8 / 15 / 20 Tons
- ✓ Long Travel Motor: 15 HP
- ✓ Travel Speed: 60 - 80 m/min
- ✓ Charging Mouths: 4 Nos.

CONSTRUCTION

- ✓ 4 Conical Hoppers, 8 mm Plate
- ✓ Worm Reducer Travel Gearbox
- ✓ Motorised Slide Gates (3 HP)
- ✓ Manual Override for Power Failure

PRODUCT GALLERY



REQUEST A QUOTATION: +91 9430707348



HOW IT WORKS

1. Bunker Filling

The car stops under the coal tower and its 4 hoppers are filled with a measured coal blend.

2. Alignment

The car travels to the empty oven; telescopic sleeves align with the charging holes to limit smoke leakage.

3. Gravity Discharge

The bottom slide gates open and coal flows into the oven by gravity.

APPLICATIONS

Coke Ovens	Top-charged by-product recovery coke oven batteries.
Steel Plants	Continuous production of metallurgical coke.

COMMON QUESTIONS

Q. What travel system is used?

A. Rail-mounted track wheels driven by a 15 HP slip-ring or squirrel cage motor.

Q. How many charging mouths?

A. Standard configuration is 4, matching the 4 charging holes on the oven top.

Q. Is the discharge automated?

A. Slide gates are motorised (3 HP) for semi-automatic operation, with a manual override wheel.

Q. What safety features are included?

A. Hydraulic buffers, electromagnetic brakes, travel alarms and operator cabin heat shields.

Q. Can it handle wet coal?

A. Yes, the steep conical hoppers help wet coal flow.

REQUEST A QUOTATION: +91 9430707348