

Site Supervisor — Subcontractor Safety Induction

Company: BuildRight Construction | Doc ID: SITE-IND-005 | Version: 2.4 | Effective: 2026-01-05 | Owner: Safety & Compliance

Purpose & scope

Mandatory induction checklist for BuildRight Construction site supervisors when onboarding subcontractor crews to active job sites. Covers orientation, PPE, hazard briefing, and sign-in before any work begins.

Key terms

Competent person: OSHA-defined individual who can identify hazards and has authority to stop work.

Toolbox talk: 10-minute daily safety briefing documented on form TT-001.

Hot work permit: Required for welding, cutting, or grinding within 35 feet of combustibles.

Standard procedure

1. Verify subcontractor COI and signed master agreement before turnstile access.
2. Collect daily sign-in sheet with worker names, employer, trade, and emergency contact.
3. Issue site-specific orientation: laydown areas, restricted zones, restroom, muster point.
4. Confirm PPE minimum: hard hat, safety glasses, hi-vis vest, steel toes — task-specific add-ons (fall protection, respirator).
5. Walk critical hazards on site map: excavations, overhead work, crane swing radius, energized panels.
6. Subcontractor foreman signs induction form IND-005 before crew enters work zone.

Approved phrases (supervisor to crew)

"Before you start – stop work authority means anyone on this site can halt a task if something looks unsafe."

"Crane lift at ten hundred – stay clear of the barricaded zone on the east elevation until all-clear on radio."

"Your fall protection anchors are on the north parapet only – do not tie off to guardrail."

"If you don't have a hot work permit on your belt, welding stops – no exceptions."

Scenarios

Scenario A — New electrical sub, live panel nearby: Supervisor verifies qualified electrician license, establishes LOTO boundary, assigns spotter, documents in daily log.

Scenario B — Sub arrives without hard hats: Work stopped at gate; supervisor provides loaner PPE if available or denies entry until compliant.

Scenario C — Near-miss reported by laborer: Supervisor holds crew, conducts immediate toolbox talk on struck-by hazards, files near-miss before resuming.

Escalation matrix

Event	Notify
Missing COI	Project manager — no site access
Serious injury	911 + PM + corporate safety within 1 hour
Environmental spill	Environmental consultant + stop work in zone
Sub non-compliance after warning	Remove from site; document in subcontractor scorecard

Do / Don't

Do: Lead by example with PPE; update hazard board when conditions change; photograph induction signatures.

Don't: Allow "we'll get helmets later"; skip sign-in for familiar crews; permit work during lightning within 30 miles per policy.