
INTRODUCTION

- Every different processor has its own design
 (different registers, buses, micro-operations, machine instructions, etc)
- Modern processor is a very complex device
- It contains
 - Many registers
 - Multiple arithmetic units, for both integer and floating point calculations
 - The ability to pipeline several consecutive instructions to speed execution
 - Etc.
- However, to understand how processors work, use a simplified processor model
- This is similar to what real processors were like ~25 years ago

THE BASIC COMPUTER

- The Basic Computer has two components, a processor and memory
- The memory has 4096 words in it
 - $-4096 = 2^{12}$, so it takes 12 bits to select a word in memory
- Each word is 16 bits long




INSTRUCTIONS

- Program
 - A sequence of (machine) instructions
- (Machine) Instruction
 - A group of bits that tell the computer to perform a specific operation (a sequence of micro-operation)
- The instructions of a program, along with any needed data are stored in memory
- The CPU reads the next instruction from memory
- It is placed in an Instruction Register (IR)
- Control circuitry in control unit then translates the instruction into the sequence of microoperations necessary to implement it

INSTRUCTION FORMAT


- A computer instruction is often divided into two parts
 - An opcode (Operation Code) that specifies the operation for that instruction
 - An address that specifies the registers and/or locations in memory to use for that operation
- In the Basic Computer, since the memory contains 4096 (= 2¹²) words, we needs 12 bit to specify which memory address this instruction will use
- In the Basic Computer, bit 15 of the instruction specifies the addressing mode (0: direct addressing, 1: indirect addressing)
- Since the memory words, and hence the instructions, are
 16 bits long, that leaves 3 bits for the instruction's opcode

Instruction Format



ADDRESSING MODES

- The address field of an instruction can represent either
 - Direct address: the address in memory of the data to use (the address of the operand), or
 - Indirect address: the address in memory of the address in memory of the data to use



- Effective Address (EA)
 - The address, that can be directly used without modification to access an operand for a computation-type instruction, or as the target address for a branch-type instruction. EA is 457 in first and 1350 in second figure.

PROCESSOR REGISTERS


- A processor has many registers to hold instructions, addresses, data, etc
- The processor has a register, the *Program Counter* (PC) that holds the memory address of the next instruction
 - Since the memory in the Basic Computer only has 4096 locations, the PC only needs 12 bits
- In a direct or indirect addressing, the processor needs to keep track of what locations in memory it is addressing: The Address Register (AR) is used for this
 - The AR is a 12 bit register in the Basic Computer
- When an operand is found, using either direct or indirect addressing, it is placed in the *Data Register* (DR). The processor then uses this value as data for its operation
- The Basic Computer has a single general purpose processing register – the Accumulator (AC)

PROCESSOR REGISTERS

- The significance of a general purpose register is that it can be used for loading operands and storing results
 - e.g. load AC with the contents of a specific memory location; store the contents of AC into a specified memory location
- Often a processor will need a scratch register to store intermediate results or other temporary data; in the Basic Computer this is the *Temporary Register* (TR)
- The Basic Computer uses a very simple model of input/output (I/O) operations
 - Input devices are considered to send 8 bits of character data to the processor
 - The processor can send 8 bits of character data to output devices
- The Input Register (INPR) holds an 8 bit character gotten from an input device
- The Output Register (OUTR) holds an 8 bit character to be send to an output device

BASIC COMPUTER REGISTERS


Registers in the Basic Computer




List of Registers

DR	16	Data Register	Holds memory operand
AR	12	Address Register	Holds address for memory
AC	16	Accumulator	Processor register
IR	16	Instruction Register	Holds instruction code
PC	12	Program Counter	Holds address of instruction
TR	16	Temporary Register	Holds temporary data
INPR	8	Input Register	Holds input character
OUTR	8	Output Register	Holds output character

- The registers in the Basic Computer are connected using a bus
- This gives a savings in circuitry over complete connections between registers





 Three control lines, S₂, S₁, and S₀ control which register the bus selects as its input

S ₂ S ₁ S ₀	Register
0 0 0	Х
0 0 1	AR
0 1 0	PC
0 1 1	DR
1 0 0	AC
1 0 1	IR
1 1 0	TR
1 1 1	Memory

- Either one of the registers will have its load signal activated, or the memory will have its read signal activated
 - Will determine where the data from the bus gets loaded
- The 12-bit registers, AR and PC, have 0's loaded onto the bus in the high order 4 bit positions
- When the 8-bit register OUTR is loaded from the bus, the data comes from the low order 8 bits on the bus

BASIC COMPUTER INSTRUCTIONS

Basic Computer Instruction Format


Memory-Reference Instructions (OP-code = 000 ~ 110)

<u> 15</u>	14	12 1	11 0
I	Opo	code	Address

Register-Reference Instructions (OP-code = 111, I = 0)

Input-Output Instructions

(OP-code = 111, I = 1)



In Memory-Reference Instructions, I is equal to 0 for direct address and to 1 for indirect address.

BASIC COMPUTER INSTRUCTIONS

Hex Code			
Symbol	<i>I</i> = 0	<i>I</i> = 1	Description
AND	0xxx	8xxx	AND memory word to AC
ADD	1xxx	9xxx	Add memory word to AC
LDA	2xxx	Axxx	Load AC from memory
STA	3xxx	Bxxx	Store content of AC into memory
BUN	4xxx	Cxxx	Branch unconditionally
BSA	5xxx	Dxxx	Branch and save return address
ISZ	6xxx	Exxx	Increment and skip if zero
CLA	78	00	Clear AC
CLE	74	00	Clear E
CMA	72	00	Complement AC
CME	71	00	Complement E
CIR	70	80	Circulate right AC and E
CIL	7040		Circulate left AC and E
INC	7020		Increment AC
SPA	7010		Skip next instr. if AC is positive
SNA	7008		Skip next instr. if AC is negative
SZA	7004		Skip next instr. if AC is zero
SZE	7002		Skip next instr. if E is zero
HLT	7001		Halt computer
INP	F8	00	Input character to AC
OUT	F400		Output character from AC
SKI	F200		Skip on input flag
SKO	F100		Skip on output flag
ION	F080		Interrupt on
IOF	F040		Interrupt off

INSTRUCTION SET COMPLETENESS

Set of instructions using which user can construct machine language programs to evaluate any computable function.

Instruction Types

Functional Instructions

- Arithmetic, logic, and shift instructions
- ADD, CMA, INC, CIR, CIL, AND, CLA

Transfer Instructions

- Data transfers between the main memory and the processor registers
- LDA, STA

Control Instructions


- Program sequencing and control
- BUN, BSA, ISZ

Input/Output Instructions

- Input and output
- INP, OUT

TIMING AND CONTROL


Control unit of Basic Computer



TIMING SIGNALS

- Generated by 4-bit sequence counter and 4×16 decoder
- The SC can be incremented or cleared.
- Example: $T_0, T_1, T_2, T_3, T_4, T_0, T_1, \dots$

Assume: At time T_4 , SC is cleared to 0 if decoder output D3 is active.



INSTRUCTION CYCLE

- In Basic Computer, a machine instruction is executed in the following cycle:
 - 1. Fetch an instruction from memory
 - 2. Decode the instruction and calculate effective address (EA)
 - 3. Read the EA from memory if the instruction has an indirect address (Fetch operand)
 - 4. Execute the instruction
- After an instruction is executed, the cycle starts again at step 1, for the next instruction


FETCH and DECODE

Fetch and Decode


T0: AR \leftarrow PC (S₀S₁S₂=010, T0=1)

T1: $IR \leftarrow M [AR], PC \leftarrow PC + 1 (S0S1S2=111, T1=1)$

T2: D0, ..., D7 \leftarrow Decode IR(12-14), AR \leftarrow IR(0-11), I \leftarrow IR(15)



DETERMINE THE TYPE OF INSTRUCTION



D'7IT3: $AR \leftarrow M[AR]$

D'7l'T3: Nothing

D7l'T3: Execute a register-reference instr.

D7IT3: Execute an input-output instr.

REGISTER REFERENCE INSTRUCTIONS

Register Reference Instructions are identified when

- $D_7 = 1$, I = 0
- Register Ref. Instr. is specified in b₀ ~ b₁₁ of IR
- Execution starts with timing signal T₃

```
TABLE 5-3 Execution of Register-Reference Instructions
D_7I'T_3 = r (common to all register-reference instructions)
 IR(i) = B_i [bit in IR(0-11) that specifies the operation]
                                                                  Clear SC
                SC \leftarrow 0
                                                                  Clear AC
        rB_{11}: AC \leftarrow 0
CLA
                                                                  Clear E
CLE rB_{10}: E \leftarrow 0
                                                                   Complement AC
CMA rB_9: AC \leftarrow \overline{AC}
                                                                   Complement E
CME rB_8: E \leftarrow \overline{E}
CIR rB_7: AC \leftarrow \text{shr } AC, AC(15) \leftarrow E, E \leftarrow AC(0)
                                                                   Circulate right
CIL rB_6: AC \leftarrow \text{shl } AC, AC(0) \leftarrow E, E \leftarrow AC(15)
                                                                   Circulate left
                                                                   Increment AC
                AC \leftarrow AC + 1
INC rB<sub>5</sub>:
SPA rB_4: If (AC(15) = 0) then (PC \leftarrow PC + 1)
                                                                   Skip if positive
                 If (AC(15) = 1) then (PC \leftarrow PC + 1)
                                                                   Skip if negative
SNA rB_3:
                 If (AC = 0) then PC \leftarrow PC + 1)
                                                                   Skip if AC zero
        rB_2:
SZA
                 If (E = 0) then (PC \leftarrow PC + 1)
                                                                   Skip if E zero
SZE
         rB_1:
                 S \leftarrow 0 (S is a start-stop flip-flop)
                                                                   Halt computer
HLT
         rB_0:
```

MEMORY REFERENCE INSTRUCTIONS

Symbol	Operation Decoder	Symbolic Description	
AND	D_0	$AC \leftarrow AC \land M[AR]$	
ADD	$D_1^{}$	$AC \leftarrow AC + M[AR], E \leftarrow C_{out}$	
LDA	D_2	AC ← M[AR]	
STA	D_3	M[AR] ← AC	
BUN	$D_\mathtt{A}^{u}$	PC ← AR	
BSA	D_5	$M[AR] \leftarrow PC, PC \leftarrow AR + 1$	
ISZ	D_6°	$M[AR] \leftarrow M[AR] + 1$, if $M[AR] + 1 = 0$ then $PC \leftarrow PC+1$	

- The effective address of the instruction is in AR and was placed there during timing signal T_2 when I = 0, or during timing signal T_3 when I = 1
- Memory cycle is assumed to be short enough to complete in a CPU cycle
- The execution of MR instruction starts with T₄

AND to AC

 D_0T_4 : DR \leftarrow M[AR] Read operand D_0T_5 : AC \leftarrow AC \land DR, SC \leftarrow 0 AND with AC

ADD to AC

 D_1T_4 : DR \leftarrow M[AR] Read operand

 D_1T_5 : AC \leftarrow AC + DR, E \leftarrow C_{out}, SC \leftarrow 0 Add to AC and store carry in E (Extended Accumulator)

MEMORY REFERENCE INSTRUCTIONS

```
LDA: Load to AC D_2T_4\colon \ DR \leftarrow M[AR] \\ D_2T_5\colon \ AC \leftarrow DR, \ SC \leftarrow 0 STA: Store AC D_3T_4\colon \ M[AR] \leftarrow AC, \ SC \leftarrow 0
```

BUN: Branch Unconditionally

This instruction transfers the program to the instruction specified by the effective address. Remember that PC holds the address of the instruction to be read from memory in the next instruction cycle. PC is incremented at time T_1 to prepare it for the address of the next instruction in the program sequence. The BUN instruction allows the programmer to specify an instruction out of sequence and we say that the program branches (or jumps) unconditionally. The instruction is executed with one microoperation:

$$D_4T_4$$
: $PC \leftarrow AR$, $SC \leftarrow 0$

The effective address from AR is transferred through the common bus to PC. Resetting SC to 0 transfers control to T_0 . The next instruction is then fetched and executed from the memory address given by the new value in PC.

$$D_{4}T_{4}$$
:PC \leftarrow AR, SC \leftarrow 0

BSA: Branch and Save Return Address


This instruction is useful for branching to a portion of the program called a subroutine or procedure. When executed, the BSA instruction stores the address of the next instruction in sequence (which is available in *PC*) into a memory location specified by the effective address. The effective address plus one is then transferred to *PC* to serve as the address of the first instruction in the subroutine. This operation was specified in Table 5-4 with the following register transfer:

$$M[AR] \leftarrow PC, PC \leftarrow AR + 1$$

BSA:

 D_5T_4 : M[AR] \leftarrow PC, AR \leftarrow AR + 1

 D_5T_5 : PC \leftarrow AR, SC \leftarrow 0



MEMORY REFERENCE INSTRUCTIONS

ISZ: Increment and Skip-if-Zero

 D_6T_4 : DR \leftarrow M[AR] D_6T_5 : DR \leftarrow DR + 1

 D_6T_6 : M[AR] \leftarrow DR, if (DR = 0) then (PC \leftarrow PC + 1), SC \leftarrow 0

ISZ: Increment and Skip if Zero


This instruction increments the word specified by the effective address, and if the incremented value is equal to 0, PC is incremented by 1. The programmer usually stores a negative number (in 2's complement) in the memory word. As this negative number is repeatedly incremented by one, it eventually reaches the value of zero. At that time PC is incremented by one in order to skip the next instruction in the program.

Since it is not possible to increment a word inside the memory, it is necessary to read the word into DR, increment DR, and store the word back into memory. This is done with the following sequence of microoperations:

 D_6T_4 : $DR \leftarrow M[AR]$ D_6T_5 : $DR \leftarrow DR + 1$

 D_6T_6 : $M[AR] \leftarrow DR$, if (DR = 0) then $(PC \leftarrow PC + 1)$, $SC \leftarrow 0$

FLOWCHART FOR MEMORY REFERENCE INSTRUCTIONS




INPUT-OUTPUT AND INTERRUPT

A Terminal with a keyboard and a Printer

Input-Output Configuration

INPR Input register - 8 bits
OUTR Output register - 8 bits
FGI Input flag - 1 bit
FGO Output flag - 1 bit
IEN Interrupt enable - 1 bit




- The terminal sends and receives serial information
- The serial info. from the keyboard is shifted into INPR
- The serial info. for the printer is stored in the OUTR
- INPR and OUTR communicate with the terminal serially and with the AC in parallel.
- The flags are needed to *synchronize* the timing difference between I/O device and the computer


PROGRAM CONTROLLED DATA TRANSFER

-- CPU --

loop: If FGI = 0 goto loop $AC \leftarrow INPR, FGI \leftarrow 0$

/* Output */ /* Initially FGO = 1 */
loop: If FGO = 0 goto loop
OUTR \leftarrow AC, FGO \leftarrow 0





INPUT-OUTPUT INSTRUCTIONS

CPU Side

$$D_7IT_3 = p$$

IR(i) = B_i, i = 6, ..., 11

Clear SC $SC \leftarrow 0$ p: pB_{11} : $AC(0-7) \leftarrow INPR, FGI \leftarrow 0$ INP Input char. to AC OUTR \leftarrow AC(0-7), FGO \leftarrow 0 OUT pB₁₀: Output char. from AC pB_9 : if(FGI = 1) then (PC \leftarrow PC + 1) SKI Skip on input flag pB_8 : if(FGO = 1) then (PC \leftarrow PC + 1) Skip on output flag SKO pB_7 : IEN $\leftarrow 1$ ION Interrupt enable on pB_6 : IEN \leftarrow 0 Interrupt enable off IOF


PROGRAM-CONTROLLED INPUT/OUTPUT

- Program-controlled I/O
 - Continuous CPU involvement I/O takes valuable CPU time
 - CPU slowed down to I/O speed
 - Simple
 - Least hardware

INTERRUPT INITIATED INPUT/OUTPUT

- Open communication only when some data has to be passed --> interrupt.
- The I/O interface instead of the CPU monitors the I/O device.
- When the interface founds that the I/O device is ready for data transfer, it generates an interrupt request to the CPU
- Upon detecting an interrupt, the CPU stops momentarily the task it is doing, branches to the service routine to process the data transfer, and then returns to the task it was performing.
- * IEN (Interrupt-enable flip-flop)
 - can be set and cleared by instructions
 - when cleared, the computer cannot be interrupted


FLOWCHART FOR INTERRUPT CYCLE




- The interrupt cycle is a HW implementation of a branch and save return address operation.
- At the beginning of the next instruction cycle, the instruction that is read from memory is in address 1.
- At memory address 1, the programmer must store a branch instruction that sends the control to an interrupt service routine
- The instruction that returns the control to the original program is "indirect BUN 0"

REGISTER TRANSFER OPERATIONS IN INTERRUPT CYCLE

Memory





Register Transfer Statements for Interrupt Cycle

- R F/F
$$\leftarrow$$
 1 if IEN (FGI + FGO)T₀'T₁'T₂'
 \Leftrightarrow T₀'T₁'T₂' (IEN)(FGI + FGO): R \leftarrow 1

- The fetch and decode phases of the instruction cycle must be modified → Replace T₀, T₁, T₂ with R'T₀, R'T₁, R'T₂
- The interrupt cycle:

 RT_0 : $AR \leftarrow 0$, $TR \leftarrow PC$

 RT_1 : $M[AR] \leftarrow TR$, $PC \leftarrow 0$

RT₂: $PC \leftarrow PC + 1$, $IEN \leftarrow 0$, $R \leftarrow 0$, $SC \leftarrow 0$