



CONTROLLED ENTERPRISE DOCUMENT

TBT-03.01 | Concrete Pouring And Silica Exposure

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-03.01 | Concrete Pouring And Silica Exposure

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-03.01: Concrete Pouring & Silica Exposure

CSI Division: Div 03 | OSHA Reference: 29 CFR 1926.1153

Delivery: Mandatory for all concrete, masonry, and flatwork crews.

DIRECTIVE — Policy Standard

All dry cutting, grinding, or chipping of concrete must utilize integrated water delivery systems or HEPA-filtered vacuums to suppress respirable crystalline silica dust.

GENERAL ORDER — Procedure

Workers pouring wet concrete must wear alkali-resistant gloves and rubber boots. Workers cutting cured concrete must follow the Table 1 silica controls. Dry sweeping of concrete dust is strictly prohibited.

Key Hazards & Mitigation (The 'What If'):

- Concrete Burns: If wet concrete breaches a worker's boot, they must stop work immediately, remove the boot, and wash the skin with clean water and pH-neutral soap to prevent chemical burns.
- Dry Cutting Subcontractor: If a masonry sub arrives to cut block without a water saw, the MH Foreman must stop their work. No dry cutting is permitted without a specific written exposure control plan.
- Pump Truck Blowout: If a concrete pump line bursts, clear the splash zone immediately. Do not attempt to grab the whipping hose. Shut down the pump at the truck.

FIELD INSTRUCTION — Execution

FIELD INSTRUCTION: Foremen must verify that all cutting equipment staged for today's shift has functioning water attachments or HEPA vacuums. Log attendance on MISH-F-10.1.

Attendance Roster (Log on MISH-F-10.1):

Print Name	Signature	Company/Trade