



CONTROLLED ENTERPRISE DOCUMENT

TBT-09.03 | Painting Scaffolds And Chemical Storage

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-09.03 | Painting Scaffolds And Chemical Storage

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-09.03: Painting Scaffolds & Chemical Storage

CSI Division: Div 09 | Track Assignment: Track 3 MEP & Interior

DIRECTIVE

Baker scaffolds used for painting must have all wheels locked before climbing. Paint and solvents must be stored in approved flammable cabinets at the end of the shift.

GENERAL ORDER

Do not overreach from the scaffold—move the scaffold instead. Clean up all spills immediately to prevent slip hazards.

Key Hazards & Mitigation (The 'What If')

- Worker reaches too far and tips the baker scaffold — keep your belt buckle within the scaffold rails.
- Oily rags left in a pile — dispose of in a designated, self-closing metal safety can to prevent spontaneous combustion.
- Scaffold wheels unlocked while painting — stop work, lock all four casters before ascending.

FIELD INSTRUCTION

Foreman: Inspect the flammable storage cabinet at the end of the shift to ensure all solvents and paints are secured.

Attendance Roster (MISH-F-10.1)

Print Name	Signature	Date