



CONTROLLED ENTERPRISE DOCUMENT

TBT-11.03 | Heavy Equipment Blind Spots

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-11.03 | Heavy Equipment Blind Spots

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-11.03: Heavy Equipment Blind Spots & Spotter Communication

CSI Division: Div 11 | OSHA Reference: 29 CFR 1926.602

Delivery: Mandatory for all crews working in the vicinity of active heavy equipment.

DIRECTIVE — Policy Standard

No ground personnel shall enter the swing radius or travel path of heavy equipment without making positive eye contact with the operator and receiving a clear signal to approach.

GENERAL ORDER — Procedure

Operators must lower the bucket/blade to the ground and take their hands off the controls before ground personnel approach the machine. Spotters must use standard hand signals, not shouting.

Key Hazards & Mitigation (The 'What If'):

- The Pinch Point: If a worker steps between an excavator's counterweight and a concrete wall, they are in a fatal pinch point. Maintain a minimum 2-foot clearance from all fixed objects.
- The Backup Alarm: If an operator puts a machine in reverse and the backup alarm does not sound, the machine must be deadlined (LOTO) until the mechanic repairs it. Do not rely solely on the spotter.
- Approaching from the Rear: If a worker approaches a loader from behind, the operator cannot see them. Always approach from the front quarter and wait for the operator's nod.

FIELD INSTRUCTION — Execution

FIELD INSTRUCTION: Foremen must physically walk the crew around the excavator today to demonstrate the operator's blind spots. Log attendance on MISH-F-10.1.

Attendance Roster (Log on MISH-F-10.1):

Print Name	Signature	Company/Trade