



CONTROLLED ENTERPRISE DOCUMENT

TBT-22.01 | Confined Space Entry

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-22.01 | Confined Space Entry

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-22.01: Confined Space Entry

CSI Division: Div 22 | OSHA Reference: 29 CFR 1926.1207
Delivery: Mandatory before any worker enters a permit-required confined space.

DIRECTIVE — Policy Standard

Entry into a permit-required confined space is strictly prohibited without a fully executed entry permit, atmospheric testing, and a dedicated attendant stationed outside the space.

GENERAL ORDER — Procedure

The space must be tested for oxygen levels, combustible gases, and toxic gases before entry and continuously monitored during the work. The attendant must never enter the space for rescue.

Key Hazards & Mitigation (The 'What If'):

- Atmospheric Alarm: If the multi-gas monitor alarms, all entrants must evacuate the space immediately. Do not wait to see if the alarm clears.
- Attendant Distraction: If the attendant leaves their post to grab a tool or use the restroom, the entrants must exit the space. The attendant must remain at the opening 100% of the time.
- Rescue Attempt: If an entrant collapses inside the space, the attendant must NOT enter. The attendant must call for the designated rescue team and use the non-entry retrieval system (tripod/winch).

FIELD INSTRUCTION — Execution

FIELD INSTRUCTION: Foremen must verify the entry permit, calibrate the gas monitor, and confirm the rescue plan before allowing entry. Log attendance on MISH-F-10.1 and complete MISH-F-32.1.

Attendance Roster (Log on MISH-F-10.1):

Print Name	Signature	Company/Trade