



CONTROLLED ENTERPRISE DOCUMENT

TBT-22.02 | Pipe Testing And Pressurization

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-22.02 | Pipe Testing And Pressurization

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-22.02: Pipe Testing & Pressurization

CSI Division: Div 22 | OSHA Reference: 29 CFR 1926.302

Delivery: Mandatory for plumbing and mechanical crews conducting pressure tests.

DIRECTIVE — Policy Standard

Pneumatic (air) testing of PVC or CPVC pipe is strictly prohibited due to the risk of explosive fragmentation. Hydrostatic (water) testing is the required method for plastic piping.

GENERAL ORDER — Procedure

During any pressure test (air or water), a danger zone must be established. Non-essential personnel must be cleared from the area, and pressure must be increased in slow, controlled increments.

Key Hazards & Mitigation (The 'What If'):

- Cap Blowout: If a test cap fails at 150 PSI, it becomes a lethal projectile. Never stand directly in front of a test cap or valve while the system is under pressure.
- Pneumatic Steel Test: If testing steel pipe with air, the stored energy is massive. If a weld fails, the shockwave can cause severe acoustic trauma and structural damage. Clear the floor.
- Bleeding Pressure: If the test is complete, the pressure must be bled off slowly through a designated relief valve. Never loosen a fitting to 'crack' the pressure.

FIELD INSTRUCTION — Execution

FIELD INSTRUCTION: Foremen must review the test plan, verify the gauge calibration, and establish the barricade zone before turning on the pump/compressor. Log attendance on MISH-F-10.1.

Attendance Roster (Log on MISH-F-10.1):

Print Name	Signature	Company/Trade