



CONTROLLED ENTERPRISE DOCUMENT

TBT-26.02 | Arc Flash And Energized Work

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-26.02 | Arc Flash And Energized Work

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-26.02: Arc Flash & Energized Work

CSI Division: Div 26 | OSHA Reference: NFPA 70E

Delivery: Mandatory for all electrical crews and personnel working near live panels.

DIRECTIVE — Policy Standard

Working on energized circuits (live work) is strictly prohibited unless de-energizing introduces additional or increased hazards, and only with written approval from the Chief Superintendent.

GENERAL ORDER — Procedure

When live work is authorized, an Arc Flash boundary must be established. Only qualified electricians wearing the specific Cal/cm2 rated Arc Flash PPE dictated by the panel's warning label may enter the boundary.

Key Hazards & Mitigation (The 'What If'):

- **Dropped Tool:** If an uninsulated screwdriver is dropped across live bus bars, it will trigger an arc flash explosion. Only use 1000V-rated insulated tools within the boundary.
- **Missing Labels:** If an old panel has no Arc Flash warning label, it must be treated as Category 4 (highest risk) until an engineer calculates the fault current.
- **Cotton Clothing:** If an electrician is wearing a polyester blend shirt under their Arc Flash suit, the extreme heat will melt the polyester into their skin. 100% cotton base layers are mandatory.

FIELD INSTRUCTION — Execution

FIELD INSTRUCTION: Foremen must verify that no live work is scheduled today without a signed Energized Work Permit. Log attendance on MISH-F-10.1.

Attendance Roster (Log on MISH-F-10.1):

Print Name	Signature	Company/Trade