



CONTROLLED ENTERPRISE DOCUMENT

TBT-31.03 | Rigging And Hoisting With Excavators

MH Construction, INC Enterprise Management System

Document family: TOOLBOX TALK LIBRARY

Document title: TBT-31.03 | Rigging And Hoisting With Excavators

Version: 1.0 | Lifecycle: Rough Draft

Use only after required functional, technical, field-usability, and approval gates are complete.

Control: Version 1.0 | Status Rough Draft | Author and Chief Editor: Matt Ramsey | Co-Editor: Todd Shoeff | Final Approver: Jeremy Thamert

TBT-31.03: Rigging & Hoisting with Excavators

CSI Division: Div 31 | OSHA Reference: 29 CFR 1926.251

Delivery: Mandatory for pipe-laying and trenching crews.

DIRECTIVE — Policy Standard

Excavators used for hoisting materials (e.g., trench boxes, concrete pipe) must use factory-engineered lifting points. Rigging from the bucket teeth or wrapping chains around the stick is prohibited.

GENERAL ORDER — Procedure

All rigging equipment (slings, shackles, chains) must be inspected before each shift. Any rigging with missing tags, stretched links, or fraying must be cut and thrown away.

Key Hazards & Mitigation (The 'What If'):

- Improvised Rigging: If a worker tries to loop a nylon strap over the thumb of the excavator to lift a manhole, stop them. Use the engineered lift eye welded to the bucket linkage.
- Shock Loading: If a pipe gets stuck in the trench mud and the operator jerks the boom to free it, the rigging will experience shock loading and may snap. Apply slow, steady tension.
- Working Under the Load: If a worker steps under a suspended trench box to guide it into place, they are in a fatal crush zone. Use tag lines to guide suspended loads.

FIELD INSTRUCTION — Execution

FIELD INSTRUCTION: Foremen must inspect all slings and shackles in the gang box today. Destroy any defective rigging immediately. Log attendance on MISH-F-10.1.

Attendance Roster (Log on MISH-F-10.1):

Print Name	Signature	Company/Trade