

Management System ISO 9001:2015

TÜVRheinland CERTIFIED WWW.tux.com ID 9108652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Seminar in General Education for Teachers

Pattern Development

Prof. Isagani A. Maliksi



Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED

Www.tux.com
ID 9108652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Pattern Development

- A pattern development, also called a stretchout or simply a development, is a full-size layout of an object made on a single flat plane.
- The **pattern** is the original part of the pattern development from which flat patterns can then be cut from flat sheets of material that are folded, rolled, or otherwise formed into the required shape






TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES












CAVITE CAMPUS

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines
Email: cavite@tup.edu.ph / Website: www.tup.edu.ph



Pattern for a box and cover






REPUBLIC OF THE PHILIPPINES TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES


CAVITE CAMPUS






Sheet-Metal Pattern Drafting







PATTERN FOR CASE

A two-part package with a slide-in box.

The fold lines on the drawer are positioned so that the box will slide in correctly after assembly.





Management System ISO 9001:2015

TÜVRheinland
CERTIFIED WWW.tur.com ID 9100652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Sheet-Metal Pattern Drafting

- Metal that has been formed into very thin, flat sheets is called sheet metal.
- It is available in many different thicknesses, or gauges.
- For steel, gauges are based on a weight of pounds per square foot per inch of thickness.
- Sheet metal is used to make patterns for many objects.
- The metal is shaped by bending, folding, or rolling and fastened by riveting, seaming, soldering, or welding.



TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES









The bends in this metal spatula make it easier to use.





Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
WWW.tuv.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Sheet-Metal Pattern Drafting

For each sheet-metal object, two drawings are usually made.

- 1. One is a pictorial drawing of the finished product,
- 2. Development, or pattern, that shows the shape of the flat sheet that, when rolled or folded or fastened, will form the finished object






MPUS
nariñas City, Cavite, Philippines



CAVITE CAMPUS

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines
Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Sheet-Metal Pattern Drafting



Pictorial drawing and stretchout of a sheet-metal box





Management
System
ISO 9001:2015

TÜVRheinland
GERTIFIED
WWW.tux.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Sheet-Metal Pattern Drafting

- Some metal objects without seams are formed by *die stamping or* pressing a flat sheet into shape under heavy pressure.
- Others are made by spinning.
- Die stamping and spinning stretch the metal out of its original shape and into a new one.





Management System ISO 9001:2015

TÜVRheinland
CERTIFIED
Www.tux.com
ID 910862185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Sheet-Metal Pattern Drafting



Examples of products created by (A) die stamping and (B) spinning sheet metal





Management
System
ISO 9001:2015

TÜVRheinland
GERTIFIED
WWW.tux.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Calculating Volume

- Familiar items such as pipes, storage tanks, cabinets, and boxes are designed and patterns are prepared using pattern development.
- When these items are meant to hold a specific quantity or amount of fluid, solid, or gaseous material, the designer must calculate the volume of the items to make sure they will hold the specified amount of material.





Management
System
ISO 9001:2015

TÜVRheinland
GERTIFIED
WWW.tux.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Calculating Volume

- Familiar items such as pipes, storage tanks, cabinets, and boxes are designed and patterns are prepared using pattern development.
- When these items are meant to hold a specific quantity or amount of fluid, solid, or gaseous material, the designer must calculate the volume of the items to make sure they will hold the specified amount of material.





Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED

WWW.tux.com
ID 9108627185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Calculating Volume

- For some shapes, calculating the volume is easy.
- For example, to find the volume of a cube, simply multiply the length times the width times the height.
- Calculating the volumes of other shapes requires the use of other mathematical formulas.





Management System ISO 9001:2015

TÜVRheinland GERTIFIED WWW.tux.com ib 9108602185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Calculating Volume

The volume of a right cylinder is determined using the formula:

Volume = (area of base) (height)

For **example**, the calculations to find the volume of the cylinder:

Area of base = πr^2


 $=(3.1416(2^2))$

= (3.1416)(4)

= 12.57 square inches

Volume = (12.57)(4)

= 50.28 cubic inches



RIGHT CIRCULAR CYLINDER







Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Calculating Volume

The volume of a right circular cone is determined using the formula:

Volume = (Area of base) (height)
3

Area of base = πr^2


 $=(3.1416)(2^2)$

= (3.1416)(4)

= 12.57 square inches

Volume = (12.57) (6) 3

= 25.14 cubic inches



RIGHT CIRCULAR CONE







Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

- Sheet-metal patterns, like all other patterns, are developed using principles of surface geometry.
- Two general classes of surfaces are plane (flat) and curved.
- The six faces of a cube are plane surfaces.
- The top and bottom of a cylinder are also plane surfaces.







REPUBLIC OF THE PHILIPPINES **TECHNOLOGICAL** UNIVERSITY OF THE PHILIPPINES

CAVITE CAMPUS









- The six faces of a cube are plane surfaces.
- The top and bottom of a cylinder are also plane surfaces.
- However, the side surface of the cylinder is curved



Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
WWW.tuv.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

- Curved surfaces that can be rolled in contact with a plane surface, such as cylinders and cones, are called *single-curved surfaces*.
- Exact pattern developments can be made for them.
- The other curved surface is called double curved and is found on spheres and spheroids.
- Because exact pattern developments cannot be made for objects with double-curved surfaces, drafters **approximate**.





REPUBLIC OF THE PHILIPPINES TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES





Surface Geometry





Pattern for a cube






REPUBLIC OF THE PHILIPPINES TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES


CAVITE CAMPUS













ICOSAHEDRON





DODECAHEDRON





Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
WWW.tuv.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

- To understand pattern development better, lay these patterns out on paper.
- Then cut them out and fold them to make the solids.
- Secure the joints with tape.
- Any solid that has plane surfaces can be made in the same way.







Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Finishing a Pattern

- In dealing with sheet-metal patterns, drafters must also know about the processes of wiring, hemming, and seaming and the material quantity required for each process.
- Wiring is one method to reinforce open ends of an item by enclosing a wire in its edge.
- To allow for wiring, a drafter must add a band of material to the pattern equal to 2.5 times the wire's diameter.






Management System ISO 9001:2015

TÜVRheinland CERTIFIED WWW.tur.com ID 910065155

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Finishing a Pattern



Methods of wiring, seaming, and hemming



Management System ISO 9001:2015

TÜVRheinland
CERTIFIED WWw.tur.com ID 9100652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Finishing a Pattern

- **Hemming** is another way to stiffen edges of a sheet-metal product by folding the edges.
- Single- and double-hemmed edges are shown in Figures 14-10B and C.
- Edges can also be fastened by soldering on lap seams (Figure 14-10D), flat lock seams Figure 14-10E, or grooved seams Figure 14-10F.
- Figure 14-10G and H for other types of seams and laps. The material required for each process depends on the thickness, the fastening method, and the application. In most cases, the corners of the lap are notched to make a neater joint.





Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

• The type of development needed for an individual object depends on the object's shape.

The three basic types are:

- a. Parallel-line Development
- b. Radial-line Development
- c. Triangulation.





Management System ISO 9001:2015


TÜVRheinland CERTIFIED Www.tuv.com ID 9108652185


Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

a. Parallel-Line Development

 Making a pattern by drawing the edges of an object as parallel lines is known as parallel-line development.





Parallel-line Development




Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
Www.tuv.com
ID 9104622185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments



A pattern for a prism, showing stretchout line and lap







Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

• In the patterns for prisms and cylinders, the **stretchout line**, which shows the full length of the pattern when it is completely unfolded, is straight, and the **measuring lines**, or vertical construction lines, are perpendicular to it and parallel to each other.





Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
WWW.tuv.com
ID 9108652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

b. Radial-Line Development

- The edges on cones and pyramids are not parallel.
- Therefore, the stretchout line is not a continuous straight line.
- Also, instead of being parallel to each other, measuring lines radiate from a single point.
- This type of development is called radial-line development.







Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

- Imagine the curved surface of a cone as being made up of an infinite number of triangles, each running the height of the cone.
- To understand the development of the pattern, imagine rolling out each of these triangles, one after another, on a plane (flat surface).







Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

- The resulting pattern would look like a sector of a circle. Its radius would be
 equal to an element of the cone, that is, a line from the cone's tip to the rim of
 its base.
- Its arc would be the length of the rim of the cone's base.






Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
WWW.tuv.com
ID 9108652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

- The resulting pattern would look like a sector of a circle. Its radius would be
 equal to an element of the cone, that is, a line from the cone's tip to the rim of
 its base.
- Its arc would be the length of the rim of the cone's base.



Developed Surface of A Cone





Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
Www.tuv.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Types of Developments

c. Triangulation

- Some surfaces, such as double-curved surfaces, cannot be developed exactly.
- The method used to make approximate developments of these surfaces is known as **triangulation**.
- It involves dividing the surface into triangles, finding the true lengths of the sides, and then constructing the triangles in regular order on a plane.
- Because the triangles have one short side, on the plane they approximate the curved surface.



Management System ISO 9001:2015

TÜVRheinland CERTIFIEO WWW.tur.com ID 9100652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Transition Pieces

- A piece that is used to connect pipes, such as hot- and cold-air ducts, and openings of different shapes, sizes, or positions is known as a **transition piece**.
- Transition pieces have a surface that is a combination of different forms, including planes, curves, or both, and are usually developed by triangulation.





TÜVRheinland
CERTIFIED
WWw.tuv.c
D 910865

CAVITE CAMPUS

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines
Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Transition Pieces



Examples of transition pieces



REPUBLIC OF THE PHILIPPINES TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES


CAVITE CAMPUS

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines
Email: cavite@tup.edu.ph / Website: www.tup.edu.ph



Examples: Prism

1. Draw the front and top views full size.







REPUBLIC OF THE PHILIPPINES TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES CAVITE CAMPUS

TÜVRheinland
CERTIFIED


Management
System
ISO 9001:2015

WWW.tux.com
ID 9108692185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Prism

- 2. Draw the stretchout line (SL).
- Find the lengths of sides 1-2, 2-3, 3-4, and 4-1 in the top view.
- Mark off these lengths on the SL.











Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Prism

- 3. At points 1, 2, 3, 4, and 1 on the SL, draw vertical crease (fold or bend) lines.
- Make them equal in length to the height of the prism.










Management System ISO 9001:2015


TÜVRheinland CERTIFIED WWW.tuv.com to 9108652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Prism

- 4. Project the top line of the pattern from the top of the front view. Make it parallel to the SL.
- Darken all outlines until they are sharp and black.
- Use a small circle or X to identify a fold line.












Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Prism

5. Add the top and bottom to the pattern by transferring distances 1-4 and 2-3 from the top view.





Management
System
ISO 9001:2015
CERTIFIED
Whytherape of the projection of the projec


Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Prism

6. Add laps or tabs as necessary for the assembly of the prism.

The size of the laps will vary depending on how they are to be fastened and the

type of material used.



Parallel Line Development of a Prism





Management System ISO 9001:2015

TÜVRheinland CERTIFIED WWW.tur.com ID 9100652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Truncated Prism

- A slight variation is the pattern for a truncated prism.
- To draw it, first make the front, top, and auxiliary views at full size. Label points as shown.
- The next two steps are the same as steps 2 and 3.
- Then project horizontal lines from points A-B and C-D on the front view to locate points on the pattern.
- Connect the points to complete the top line of the pattern.
- Add the top and bottom as shown. Tabs may be added.




Management
System
ISO 9001:2015

TÜVRheinland
CERTIFIED
Www.tux.com
ID 3108652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Truncated Prism






Management System ISO 9001:2015


TÜVRheinland CERTIFIED www.tuv.com ID 9100052185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Cylinder

- A cylinder is made by rolling the cylinder out on a plane surface. In the pattern for cylinders, the stretchout line is straight and equal in length to the circumference of the cylinder.
- If the base of the cylinder is perpendicular to the axis, its rim will roll out to form the straight line









Management System ISO 9001:2015

TÜVRheinland GERTIFIED WWW.tux.com to 9100652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Cylinder

- In developing a cylinder, imagine that it is actually a many-sided prism.
 - Each side forms an edge called an element.
 - Because there are so many elements, however, they seem to form a smooth curve on the surface of the cylinder.
 - Imagining the cylinder in this way will help you find the length of the stretchout line.





Management
System
ISO 9001:2015
CERTIFIED
Www.tux.com
ID 910862785

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Cylinder

- This length will equal the total of the distances between all of the elements.
 - Technically, of course, the elements are infinite in number.
- For your purposes, however, you need to mark off elements at convenient equal spaces only around the circumference of the cylinder.
 - Then add up these spaces to make the stretchout line.
- This must equal the circumference of the cylinder.






Management System ISO 9001:2015

TÜVRheinland CERTIFIED Www.tux.com ID 9108652185

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Various Ways of Dividing a Circle




Dividing A Circle





Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Truncated Right Cylinder



Development Of A Pattern For A Truncated Right Cylinder








CAVITE CAMPUS

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines
Email: cavite@tup.edu.ph / Website: www.tup.edu.ph

Examples: Cone



Development of a Pattern For A Cone



REPUBLIC OF THE PHILIPPINES TECHNOLOGICAL UNIVERSITY OF THE PHILIPPINES



CAVITE CAMPUS

Carlos Q. Trinidad Ave., Salawag, Dasmariñas City, Cavite, Philippines Email: cavite@tup.e

Examples: Cone

Development of a Pattern For a Truncated Right Circular Cone

