

On pose:
$$N = 16 \text{ bits}$$

$$F_s = 50 \text{ MHz}$$

$$N_o = 12 \text{ bits}$$

- 1) What is DDS?
- 2) Different ways to reduce Rom Size
- 3) Taylor Series Linear Interpolation
 - wo How
 - Why
 - -> Performence