Servo motor

DO | PICO BLOCKS | OUTPUT | MOVEMENT

What does it do?

A positional servo moves its arm, called a horn, to a chosen position and holds it there.

Short pulses on its signal wire set the position. The motor and position control are built into the case.


Use it for steering, pointing or opening a flap. A continuous-rotation servo controls speed instead; it cannot use this example to choose an angle.

Uses



Radio-controlled steering

DETECT Read steering command → **DECIDE** Which way should it turn? → **DO** Set the steering position



Cardboard chomping monster

DETECT Read feeding button → **DECIDE** Is the monster hungry? → **DO** Open its cardboard jaw




Horn	Signal	Power	Ground
Attach a light moving part	Usually orange, yellow or white	Usually red; separate supply	Brown or black; join grounds

Raspberry Pi Foundation

Blocks

MicroLab


getmicrolab.com



> Try 0 or 180 degrees to swing the arm to each end.

Wiring

PICO



GP7 (pin 10) → signal; **GND** (pin 13) → − rail → servo/pack −. Use **4×AA NiMH (4.8 V)**; USB powers the board. Keep pack + off board power pins.