

RAM Reseating Procedure and Observation Report

Objective

To simulate troubleshooting by removing and re-inserting a RAM module (reseating RAM) and documenting the steps, precautions, and any issues observed.

Steps Performed

1. Powered off the computer

- Shut down the system completely.
- Disconnected the power cable from the computer.
- Removed any connected peripherals if necessary.

2. Prepared the workspace

- Placed the computer on a clean, flat surface.
- Used proper static precautions by touching a grounded metal surface before handling internal components.

3. Opened the computer case

- Removed the side panel of the desktop/laptop access cover according to the device design.
- Located the motherboard area and identified the RAM slots.

4. Identified the RAM module

- Located the RAM sticks installed in the DIMM/SODIMM slots.
- Checked the position and orientation of the module before removal.

5. Removed the RAM module

- Released the locking clips on both sides of the RAM slot.
- Carefully lifted the RAM module straight out of the slot.

- Avoided touching the gold contacts on the module.

6. Inspected the RAM and slot

- Checked the RAM module for visible dust, damage, or contamination.
- Checked the RAM slot for dust or physical damage.

7. Re-inserted the RAM module

- Aligned the notch on the RAM module with the key in the slot.
- Pressed the module firmly and evenly into the slot until the locking clips clicked into place.

8. Closed the system

- Reattached the case panel/access cover.
- Reconnected the power cable and peripherals.

9. Tested the system

- Powered on the computer.
- Confirmed whether the system booted normally.
- Checked that the installed memory was detected correctly.

Result

The RAM module was successfully reseated / required further troubleshooting (select one). The system was tested after reassembly, and the final behavior was recorded above.