

USB Phone Charger Voltage Test

Equipment Used:

- Digital multimeter (or virtual multimeter simulator)
- Standard 5V USB phone charger

Procedure:

1. Set the multimeter to **DC Voltage (20 V range or auto-range)**.
2. Plug the USB charger into a power outlet.
3. Place the **red (positive) probe** on the USB **+5 V pin** (Pin 1).
4. Place the **black (negative) probe** on the USB **Ground (GND) pin** (Pin 4).
5. Read and record the voltage displayed on the multimeter.

Item	Value
Expected USB Output Voltage	4.75 V – 5.25 V DC
Measured Voltage (Example)	5.08 V DC
Within Expected Range?	Yes