

## 1. Connect the Printer

### USB printer

1. Plug the printer into power and turn it on.
2. Connect the USB cable to your computer.

### Network printer (Wi-Fi/Ethernet)

1. Ensure the printer is connected to the same network as your computer.
  2. Note the printer's IP address if available (often shown on the printer's network settings page).
- 

## 2. Install the Correct Driver

### Windows

1. Open Settings → Bluetooth & devices → Printers & scanners.
2. Select Add device.
3. If Windows finds the printer, choose it and install.
4. If not, download the latest driver from the printer manufacturer's website (for example, HP) and run the installer.

## 3. Print a Test Page

### Windows

1. Open **Settings** → **Bluetooth & devices** → **Printers & scanners**.
2. Select your printer.
3. Choose **Printer properties**.
4. Click **Print Test Page**.

## 4. Confirm Success

A successful installation is confirmed if:

- The printer appears in your system's printer list.
- The test page prints correctly.
- No error messages appear in the print queue.