

BIOS/POST Error Message Likely Hardware or Configuration Issue

- | | |
|--|--|
| 1. "CMOS Checksum Error" | Usually points to a dead or weak CMOS battery, incorrect BIOS settings, or corrupted BIOS configuration. Replacing the CMOS battery and resetting BIOS settings often fixes it. |
| 2. "No Boot Device Found" / "Boot Device Not Found" | Indicates the system cannot find a bootable drive. Common causes include a failed HDD/SSD, disconnected storage cable, incorrect boot order, or a missing/corrupted operating system. |
| 3. "Memory Error" / "Memory Size Decreased" / Beep Codes for RAM Failure | Usually points to faulty or improperly seated RAM, incompatible memory modules, or a motherboard memory slot issue. Reseating or testing RAM sticks can help identify the problem. |
| 4. "CPU Fan Error" | Indicates the BIOS is not detecting proper CPU cooling. Causes include a failed CPU fan, loose fan connection, incorrect fan header connection, or incorrect fan speed settings in BIOS. |
| 5. "Keyboard Error" / "Keyboard Not Detected" | Usually caused by a disconnected or faulty keyboard, damaged USB/PS/2 port, or incorrect USB settings in BIOS. |