


DIAMOND AND EXTRUDED BED RAIL INSTRUCTIONS


Attach adhesive backed foam strip to back end of the protective rail. Front end
optional on applications without front cap. Position rail on truck and drill 5/16"
diameter hole a few inches back from front end making sure to miss stake pocket
(where applicable). Attach fastener through this hole and finger tighten. Now
follow this procedure at the middle of the rail and then at the back. Now tighten
all fasteners.



CHEVY AND GMC ONLY


Chevy / GMC 1988-Current C-K Model

1. This bed is designed with a taper in the back portion of the bed. Before drilling the rear hole be sure to push the protector against the outside of the body. Your foam rubber tape will fill the gap left on the inside of the bed.



Chevy / GMC 1973-1987 C-K Model 1988-Current RV Model

1. This is designed with a taper running the length of the bed. A spacer has been provided to aid in proper fit of the protectors. Remove the release paper from the double face tape that is attached to the spacer. Apply spacer to the straight lip of protector 3 or 4 inches from the back end. Then drill and fasten bed rail.



Lund International
800-241-7219 • Visit us at lundinternational.com
© 2012 Lund International, Inc. All rights reserved.
Lund® and the Lund® logo are trademarks of Lund International, Inc.