

# Interceptor

Issue Date: 11/30/99 Revision: 3/27/00

age Contains:

d and hardware pack. (6 Expandable Fasteners)

#### **Tools Needed:**

Soap, Water, Sponge, Tape Measure

## Illation Instructions

e read carefully and completely before starting.

## A. Preparation to install shield.


lean hood of vehicle with hot soapy water, rinse and ry thoroughly.

back painting of shield is desired, see Painting nstructions.


#### B. Shield Installation


lign slotted holes in hood shield with pre-existing oles in under side of hood. **figure 1** 


: Some hoods may have two rubber bumpers in the uter mounting holes, if so, remove and discard.



Starting with the middle slots, insert an expandable astener through hood shield and into hood. Press the nead of the fastener halfway into its base. figure 2








**6.** Insert remaining fasteners and press each threaded plug fully into its base. **figure 4** 

**NOTE:** To remove fasteners, unscrew threaded plunger and lift out remaining portion from hole. **figure 5** 



### Care & Cleaning

- 1. Avoid the use of automatic "brush-style" car washes.
- 2 Do not use cleaning solvents of any kind.

ELDS. paration NOT USE SOLVENT CLEANERS OF ANY KIND TO CLEAN THE SHIELD. THIS WILL DAM-THE SHIELD en preparing the shield for painting, be sure to work on a soft clean surface to ensure the shield not be scratched. he shield needs to be washed thoroughly using a mild liquid dish soap (without grit) and a soft on cloth. inse all traces of soap off with clean water. ry with a soft clean cotton cloth. tion: DO NOT leave any water or soap streaks on the inside of the shield. Mask off the outside face of the shield with masking tape. Frim the tape flush with the outer edge of the shield. Clean out the inside surface again making sure that there is no streaks, finger prints, or imperfecs, because paint will not hide these imperfections. NOT sand or scruff the inside of the shield before painting. The solvents in the paint will adhere ne plastic. nting the Shield NOT USE ACRYLIC LACQUER. The harsh solvents will cause crazing (hair-line cracks in the

Painting Lexan and Acrylic Bug Shields D ALL INSTRUCTIONS CAREFULLY AND COMPLETELY BEFORE STARTING PROCEDURE CK FIT BEFORE PAINTING. LUND WILL NOT WARRANT PAINTING COSTS ON MISFITTING

eld). only the following paints: **Acrylic Enamel Based Paints Urethane Based Paints** xy Based Paints

-Centari by Dupont -Chromabase by Dupont on PC by Dupont -Acrylic Enamel by Martin

eblo by Martin Senour -TEC/Base by Martin Senour -Delstar by PPG -Deltron by PPG nour -Startthane by PPG

-Miracryl 11 by R-M -Solo by R-M athane by R-M

e: Light coats and dry times are a must to prevent crazing. Mix Paint

Spray 1 light dry coat and let dry 10 minutes

Spray 1 light dry coat and let dry 10 minutes

Spray 1 wet coat and let dry 10 minutes Spray 1 wet coat and let dry 10 minutes

Apply 1 final wet coat te: Some metallic paints will appear to be translucent. If the color is translucent you will need to

the state of the second property and the second sec