

#### STEP 1 - PRIOR TO INSTALLATION

- A) Bushwacker only approves installing the Hood Scoop according to these written instructions with the hardware provided. WARNING: Failure to install according to these instructions will invalidate the warranty. This includes, but is not limited to using alternative installation methods, hardware, or materials. DO NOT USE: Loctite, SuperGlue, or similar products on the hardware or the flares.
- **B)** Fit: Verify the fit of the Hood Scoop to vehicle. (Some filing, sanding, or cutting may be necessary to ensure proper fit).
- C) Painting: (Optional) if paint is desired it must be done prior to installing Hood Scoop on vehicle. Clean outer surface with a good grade degreaser. DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER. Wipe outer surface thoroughly with a tack rag prior to paint. Application of plastic adhesion promoter for ABS plastic as per your paint system manufacturer's recommendations is required. Paint Hood Scoop using a high quality enamel, or polyurethane automotive paint. If painting edge trim (not recommended), use a flex additive.

# Jeep<sub>®</sub> Trail Armor<sup>®</sup> Hood Scoop

Rear Part #15001 Rev-3 1/27/2014

For complete fitment info visit: www.bushwacker.com

#### **TOOLS FOR EASY INSTALLATION:**

- · Wiping Cloth
- · Grease Pencil

## LIMITED LIFETIME WARRANTY AGAINST ANY MANUFACTURING DEFECTS

 To claim a warranty, you must provide Proof of Purchase.

### **Included in Hardware Kit:**

1.



AD1-0008, ALCOHOL PREP PAD, 1 pc

### **Hood Scoop Installation Procedures:**



Put a Washer (WA1-0007) on each Bolt (SW1-0032).



Put each Bolt/Washer combination through a pocket hole in the flare, with the Bolt head and Washer on the outside.



Once positioned, use a grease pencil to lightly trace around edges of part.



Remove part and peel red liner partially from tape pads as shown. NOTE: Make sure tabs are folded toward the outside of the part and are accessible to pull once part is repositioned.



Hold the part at an angle to prevent tape from prematurely sticking, and align the part on the hood using marks made in Step 3 as a guide. NOTE: *If* necessary, *lift windshield wiper out of the way.* 



Maintaining part placement, begin pulling tape tabs while applying downward pressure to part.



Press part into place. Apply 30 PSI to the taped areas for proper bond. The tape reaches maximum adhesive bond after 24 hours of contact. Do not wash vehicle for 24 hours.



If desired, adhere supplied Bushwacker Domed labels to outside of part.