CONTENTS:

- (1) Bug Shield
- (1) instruction sheet
- (4) mounting screws
- (4) washers
- (4) Bump-ons

IMPORTANT: Read all instructions carefully before beginning installation. The ideal installation temperature is between 65°-110°F (18°-43°C).

STEP 1: PREPARATION

Clean the Bug Shield mounting location on the underside of the hood with a clean cloth. See **FIGURE 1**

STEP 2: TRIAL FIT

Locate the center line/point of the Bug Shield. Then align the center line/point with the center of the hood and verify placement before proceeding. The Bug Shield should be offset approximately 1/2" from the front edge of the hood. See Diagram A or B.

STEP 3: INSTALLATION

Attach the Bug Shield to the underside of the hood by screwing the (4) self-tapping screws with rubber washers through the predrilled holes in the Bug Shield. A power screw driver is recommended, but once the screw penetrates the sheet metal, use a regular Phillips screwdriver the remainder of the way. Do not overtighten screws. Be sure Bug Shield is properly positioned before using screws to prevent damaging hood. See FIGURE 2

STEP 4: AFTER INSTALLING

To reduce vibration, adhere the rubber Bump-ons at precleaned locations on the painted hood/fender surface where the Bug shield may contact. If the hood does not shut properly it may be necessary to adjust the hood bumper stops (refer to your owner's manual).



